

SIEMENS

SINAMICS

SINAMICS V20 Inverter

Operating Instructions

Preface

Safety instructions

1

Introduction

2

Mechanical installation

3

Electrical installation

4

Commissioning

5

Communicating with the PLC

6

Parameter list

7

Fault and warning codes

8

Technical specifications

A

Options and spare parts

B

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

DANGER

indicates that death or severe personal injury **will** result if proper precautions are not taken.

WARNING

indicates that death or severe personal injury **may** result if proper precautions are not taken.

CAUTION

with a safety alert symbol, indicates that minor personal injury can result if proper precautions are not taken.

CAUTION

without a safety alert symbol, indicates that property damage can result if proper precautions are not taken.

NOTICE

indicates that an unintended result or situation can occur if the relevant information is not taken into account.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions.

Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

WARNING

Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Preface

Purpose of this manual

This manual provides you with information about the proper installation, commissioning, operation, and maintenance of SINAMICS V20 inverters.

SINAMICS V20 user documentation components

| Document | Product | Language |
|----------------------------------|---------------------------------------|--|
| Inverter system | | |
| Operating Instructions | SINAMICS V20 Inverters | Chinese (available as a printed manual) English |
| Getting Started ¹⁾ | SINAMICS V20 Inverters | Chinese - English bilingual |
| Options ²⁾ | | |
| Product Information | Parameter Loaders | Chinese - English bilingual |
| Product Information | Dynamic Braking Modules | Chinese - English bilingual |
| Product Information | External Basic Operator Panels (BOPs) | Chinese - English bilingual |
| Product Information | BOP Interface Modules | Chinese - English bilingual |
| Product Information | Screening Plate Kits | Chinese - English bilingual |
| Spare parts ²⁾ | | |
| Product Information | Replacement Fans | Chinese - English bilingual |

¹⁾ The Getting Started is included in the delivery of the inverter.

²⁾ The Product Information is included in the delivery of individual options or spare parts.

Technical support

| Country | Hotline |
|--|----------------------|
| China | +86 400 810 4288 |
| Germany | +49 (0) 911 895 7222 |
| Italy | +39 (02) 24362000 |
| Brazil | +55 11 3833 4040 |
| India | +91 22 2760 0150 |
| Korea | +82 2 3450 7114 |
| Turkey | +90 (216) 4440747 |
| USA | +1 423 262 5710 |
| Further service contact information: Support contacts (http://support.automation.siemens.com/WW/view/en/16604999) | |

Table of contents

| | |
|--|----|
| Preface | 3 |
| 1 Safety instructions | 7 |
| 2 Introduction..... | 13 |
| 2.1 Components of the inverter system | 13 |
| 2.2 Inverter rating plate | 14 |
| 3 Mechanical installation..... | 15 |
| 3.1 Mounting orientation and clearance..... | 15 |
| 3.2 Cabinet panel mounting (frame sizes A ... D)..... | 16 |
| 3.3 Push-through mounting (frame sizes B ... D)..... | 18 |
| 4 Electrical installation | 21 |
| 4.1 Typical system connections | 21 |
| 4.2 Terminal description..... | 23 |
| 4.3 EMC-compliant installation | 27 |
| 4.4 EMC-compliant cabinet design | 28 |
| 5 Commissioning | 29 |
| 5.1 The built-in Basic Operator Panel (BOP)..... | 29 |
| 5.1.1 Introduction to the built-in BOP | 29 |
| 5.1.2 Inverter menu structure | 31 |
| 5.1.3 Viewing inverter status | 32 |
| 5.1.4 Editing parameters | 32 |
| 5.1.5 Screen displays..... | 34 |
| 5.1.6 LED states..... | 36 |
| 5.2 Checking before power-on..... | 36 |
| 5.3 Setting the 50 / 60 Hz selection menu | 37 |
| 5.4 Starting the motor for test run | 38 |
| 5.5 Quick commissioning | 38 |
| 5.5.1 Quick commissioning through the setup menu..... | 38 |
| 5.5.1.1 Structure of the setup menu | 38 |
| 5.5.1.2 Setting motor data..... | 40 |
| 5.5.1.3 Setting connection macros..... | 41 |
| 5.5.1.4 Setting application macros..... | 52 |
| 5.5.1.5 Setting common parameters..... | 55 |
| 5.5.2 Quick commissioning through the parameter menu | 56 |
| 5.6 Function commissioning | 59 |
| 5.6.1 Overview of inverter functions..... | 59 |
| 5.6.2 Commissioning basic functions..... | 61 |
| 5.6.2.1 Selecting the stop mode | 61 |
| 5.6.2.2 Running the inverter in JOG mode | 63 |
| 5.6.2.3 Setting the voltage boost | 64 |

| | | |
|-------------------|---|------------|
| 5.6.2.4 | Setting the PID controller | 67 |
| 5.6.2.5 | Setting the braking function..... | 69 |
| 5.6.2.6 | Setting the ramp time | 77 |
| 5.6.2.7 | Setting the I _{max} controller | 79 |
| 5.6.2.8 | Setting the V _{dc} controller..... | 81 |
| 5.6.2.9 | Setting the load torque monitoring function | 82 |
| 5.6.3 | Commissioning advanced functions | 83 |
| 5.6.3.1 | Starting the motor in super torque mode | 83 |
| 5.6.3.2 | Starting the motor in hammer start mode | 85 |
| 5.6.3.3 | Starting the motor in blockage clearing mode..... | 87 |
| 5.6.3.4 | Running the inverter in economy mode | 89 |
| 5.6.3.5 | Setting the UL508C-compliant motor overtemperature protection | 90 |
| 5.6.3.6 | Setting the free function blocks (FFBs)..... | 91 |
| 5.6.3.7 | Setting the flying start function..... | 92 |
| 5.6.3.8 | Setting the automatic restart function | 93 |
| 5.6.3.9 | Running the inverter in frost protection mode..... | 94 |
| 5.6.3.10 | Running the inverter in condensation protection mode | 95 |
| 5.6.3.11 | Running the inverter in sleep mode | 96 |
| 5.6.3.12 | Setting the wobble generator | 97 |
| 5.6.3.13 | Running the inverter in motor staging mode | 98 |
| 5.6.3.14 | Running the inverter in cavitation protection mode | 101 |
| 5.6.3.15 | Setting the user default parameter set..... | 102 |
| 5.6.3.16 | Setting the dual ramp function | 103 |
| 5.7 | Restoring to defaults | 104 |
| 6 | Communicating with the PLC..... | 105 |
| 6.1 | USS communication..... | 105 |
| 6.2 | MODBUS communication | 109 |
| 7 | Parameter list | 117 |
| 7.1 | Introduction to parameters | 117 |
| 7.2 | Parameter list | 121 |
| 8 | Fault and warning codes..... | 233 |
| A | Technical specifications | 243 |
| B | Options and spare parts | 247 |
| B.1 | Options | 247 |
| B.1.1 | Parameter Loader | 247 |
| B.1.2 | External BOP and BOP Interface Module..... | 251 |
| B.1.3 | Connecting cable (external BOP to BOP Interface Module). | 256 |
| B.1.4 | Dynamic braking module..... | 257 |
| B.1.5 | Braking resistor | 259 |
| B.1.6 | Input choke..... | 259 |
| B.1.7 | Output choke..... | 260 |
| B.1.8 | Screening plate kit..... | 260 |
| B.1.9 | Memory card | 264 |
| B.1.10 | User documentation | 264 |
| B.2 | Spare parts - replacement fans..... | 264 |
| Index..... | | 267 |

Safety instructions

Before installing and putting this equipment into operation, read the following safety instructions and all warning labels attached to the equipment carefully. Make sure the warning labels are kept in a legible condition and replace missing or damaged labels.

General

DANGER

Dangerous voltage

Do not touch any terminals within five minutes after the power supply for the inverter has been switched off. Hazardous voltage remains present in the internal DC link capacitors when the power is removed. Failure to follow this instruction could cause electric shocks.

Protective earthing conductor current

As the earth leakage for the inverter can be greater than AC 3.5 mA, a fixed earth connection is required and the minimum size of the protective earth conductor shall comply with the local safety regulations for high leakage current equipment.

The inverter can cause a DC current in the protective earthing conductor.

WARNING

This equipment contains dangerous voltages and controls potentially dangerous rotating mechanical parts. Loss of life, severe personal injury, or property damage could result if the instructions contained in this manual are not followed.

Only suitable qualified personnel should work on this equipment, and only after becoming familiar with all safety instructions, installation, commissioning, operation, and maintenance procedures contained in this manual.

Any unauthorized modifications of the equipment are not allowed.

Protection in case of direct contact by means of voltages < 60 V (PELV = Protective Extra Low Voltage according to EN 61800-5-1) is only permissible in areas with equipotential bonding and in dry indoor rooms. If these conditions are not fulfilled, other protective measures against electric shock must be applied e.g. protective insulation.

The inverter must always be grounded. If the inverter is not correctly grounded, this can lead to extremely hazardous conditions which, under certain circumstances, can result in death.

The device must be disconnected from the electrical power supply before any connections with the device are established or in any way altered.

Install the inverter on a metal mounting plate in a control cabinet. The mounting plate has to be unpainted and with a good electrical conductivity.

It is strictly prohibited for any mains disconnection to be performed on the motor-side of the system, if the inverter is in operation and the output current is not zero.

Take particular notice of the general and regional installation and safety regulations regarding work on dangerous voltage installations (e.g. 61800-5-1) as well as the relevant regulations regarding the correct use of tools and personal protective equipment (PPE).

CAUTION

Static discharges on surfaces or interfaces (e.g. terminal or connector pins) can cause malfunctions or defects. Therefore, when working with inverters or inverter components, ESD protective measures should be observed.

Transport and storage

CAUTION

Protect the equipment from physical shocks or vibration during transport and storage. It is important that the equipment is protected from water (rainfall) and excessive temperatures.

Installation

WARNING

Only permanently-wired input power connections are allowed. The equipment must be earthed (IEC 536 Class 1, NEC and other applicable standards).

Wherever faults occurring in the control equipment can lead to substantial material damage or even grievous bodily injury (that is, potentially dangerous faults), additional external precautions must be taken or facilities provided to ensure or enforce safe operation, even when a fault occurs (e.g. independent limit switches, mechanical interlocks, etc.).

Make sure the motor is configured for the correct supply voltage.

Mount the inverter vertically to a flat and non-combustible surface.

Requirements for United States / Canadian installations (UL/cUL)

Suitable for use on a circuit capable of delivering not more than 40000 rms Symmetrical Amperes, 480 Vac maximum, when protected by UL/cUL-certified Class J fuses only. For each frame size A to D use class 1 75 °C copper wire only.

This equipment is capable of providing internal motor overload protection according to UL508C. In order to comply with UL508C, parameter P0610 must not be changed from its factory setting of 6.

For applications where UL approval is required, only AC voltage can be applied to the Relay Output (DO2) terminals (maximum 250 V).

For Canadian (cUL) installations the inverter mains supply must be fitted with any external recommended suppressor with the following features:

- Surge-protective devices; device shall be a Listed Surge-protective device (Category code VZCA and VZCA7)
- Rated nominal voltage 480/277 VAC, 50/60 Hz, 3-phase
- Clamping voltage VPR = 2000 V, IN = 3 kA min, MCOV = 550 VAC, SCCR = 40 kA
- Suitable for Type 1 or Type 2 SPD application
- Clamping shall be provided between phases and also between phase and ground

⚠ CAUTION

Separate the control cables from the power cables as much as possible.

Keep the connecting cables away from rotating mechanical parts.

Commissioning

⚠ WARNING

The following terminals can carry dangerous voltages even if the inverter is not operating:

- The mains input terminals L1, L2, L3, and PE
- The motor terminals U, V, W, and output earth terminal
- The DC link terminals DC+ and DC-
- The braking resistor terminals R1 and R2 (Frame size D only)

This equipment must not be used as an "emergency stop" mechanism (*see EN 60204, 9.2.5.4*).

It is not allowed to open, connect or disconnect the equipment during its operation.

Operation

⚠ WARNING

Certain parameter settings may cause the inverter to restart automatically after an input power failure, for example, the automatic restart function.

Motor parameters must be accurately configured for motor overload protection to operate correctly.

Use of mobile radio devices (e.g. telephones, walkie-talkies) in the immediate vicinity of the devices (< 1.8 m) can interfere with the functioning of the equipment.

Risk of fire

If an unsuitable braking resistor is used, this could result in a fire and severely damage, people, property and equipment. Use the adequate braking resistor and install it correctly.

The temperature of a braking resistor increases significantly during operation. Avoid coming into direct contact with braking resistors.



⚠ WARNING

During operation and for a short time after switching off the inverter, the marked surfaces of the inverter can reach a high temperature. Avoid coming into direct contact with these surfaces.

! CAUTION

This equipment is suitable for use in a power system up to 40,000 symmetrical amperes (rms), for the maximum rated voltage + 10 % when protected by an appropriate standard fuse.

Repair

! WARNING

Repairs on equipment may only be carried out by Siemens Service, by repair centers authorized by Siemens or by authorized personnel who are thoroughly acquainted with all the warnings and operating procedures contained in this manual.

Any defective parts or components must be replaced using parts contained in the relevant spare parts lists.

Disconnect the power supply before opening the equipment for access.

Dismantling and disposal

CAUTION

The packaging of the inverter is re-usable. Retain the packaging for future use.

Easy-to-release screw and snap connectors allow you to break the unit down into its component parts. You can recycle these component parts, dispose of them in accordance with local requirements or return them to the manufacturer.

Residual risks

CAUTION

The control and drive components of a power drive system (PDS) are approved for industrial and commercial use in industrial line supplies. Their use in public line supplies requires a different configuration and/or additional measures.

These components may only be operated in closed housings or in higher-level control cabinets with protective covers that are closed, and when all of the protective devices are used.

These components may only be handled by qualified and trained technical personnel who are knowledgeable and observe all of the safety information and instructions on the components and in the associated technical user documentation.


When carrying out a risk assessment of a machine in accordance with the EU Machinery Directive, the machine manufacturer must consider the following residual risks associated with the control and drive components of a PDS.

1. Unintentional movements of driven machine components during commissioning, operation, maintenance, and repairs caused by, for example:
 - Hardware defects and / or software errors in the sensors, controllers, actuators, and connection technology
 - Response times of the controller and drive
 - Operating and/or ambient conditions not within the scope of the specification
 - Condensation / conductive contamination
 - Parameterization, programming, cabling, and installation errors
 - Use of radio devices / cellular phones in the immediate vicinity of the controller
 - External influences / damage
2. Exceptional temperatures as well as emissions of noise, particles, or gas caused by, for example:
 - Component malfunctions
 - Software errors
 - Operating and/or ambient conditions not within the scope of the specification
 - External influences / damage
3. Hazardous shock voltages caused by, for example:
 - Component malfunctions
 - Influence of electrostatic charging
 - Induction of voltages in moving motors
 - Operating and/or ambient conditions not within the scope of the specification
 - Condensation / conductive contamination
 - External influences / damage
4. Electrical, magnetic and electromagnetic fields generated in operation that can pose a risk to people with a pacemaker, implants or metal replacement joints, etc. if they are too close.
5. Release of environmental pollutants or emissions as a result of improper operation of the system and/or failure to dispose of components safely and correctly.

Introduction

2.1 Components of the inverter system

The SINAMICS V20 is a range of inverters designed for controlling the speed of three phase asynchronous motors. The inverter is available in four frame sizes.




3 AC 400 V variants

| Component | Rated output power | Rated output current | Order number | |
|-----------------------------------|--------------------|----------------------|--------------------|--------------------|
| | | | unfiltered | filtered |
| Frame size A (without fan) | 0.37 kW | 1.3 A | 6SL3210-5BE13-7UV0 | 6SL3210-5BE13-7CV0 |
| | 0.55 kW | 1.7 A | 6SL3210-5BE15-5UV0 | 6SL3210-5BE15-5CV0 |
| | 0.75 kW | 2.2 A | 6SL3210-5BE17-5UV0 | 6SL3210-5BE17-5CV0 |
| Frame size A (with single fan) | 1.1 kW | 3.1 A | 6SL3210-5BE21-1UV0 | 6SL3210-5BE21-1CV0 |
| | 1.5 kW | 4.1 A | 6SL3210-5BE21-5UV0 | 6SL3210-5BE21-5CV0 |
| | 2.2 kW | 5.6 A | 6SL3210-5BE22-2UV0 | 6SL3210-5BE22-2CV0 |
| Frame size B (with single fan) | 3.0 kW | 7.3 A | 6SL3210-5BE23-0UV0 | 6SL3210-5BE23-0CV0 |
| | 4.0 kW | 8.8 A | 6SL3210-5BE24-0UV0 | 6SL3210-5BE24-0CV0 |
| Frame size C (with single fan) | 5.5 kW | 12.5 A | 6SL3210-5BE25-5UV0 | 6SL3210-5BE25-5CV0 |
| Frame size D (with two fans) | 7.5 kW | 16.5 A | 6SL3210-5BE27-5UV0 | 6SL3210-5BE27-5CV0 |
| | 11 kW | 25 A | 6SL3210-5BE31-1UV0 | 6SL3210-5BE31-1CV0 |
| | 15 kW | 31 A | 6SL3210-5BE31-5UV0 | 6SL3210-5BE31-5CV0 |

Options and spare parts

For detailed information of the options and spare parts, refer to Appendices "Options (Page 247)" and "Spare parts - replacement fans (Page 264)".

2.2 Inverter rating plate




Mechanical installation

3.1 Mounting orientation and clearance

The inverter must be mounted in an enclosed electrical operating area or a control cabinet.


Mounting orientation

Always mount the inverter in an upright position.



Mounting clearance

| | |
|--------|---|
| Top | ≥ 100 mm |
| Bottom | ≥ 100 mm (for frame sizes B ... D, and frame size A without fan) ≥ 85 mm (for fan-cooled frame size A) |
| Side | ≥ 0 mm |



Mechanical installation

3.2 Cabinet panel mounting (frame sizes A ... D)





3.2 Cabinet panel mounting (frame sizes A ... D)

You can mount the inverter directly on the surface of the cabinet panel.







An additional mounting method is also available for different frame sizes. For more details, refer to the following section:

- Push-through mounting (frame sizes B ... D) (Page 18)

Outline dimensions and drill patterns

| Dimensions (mm) | Drill pattern (mm) |
|--|--|
| Frame size A  ¹⁾ Height of frame size A with fan |  Fixings: 4 x M4 screws 4 x M4 nuts 4 x M4 washers Tightening torque: 1.8 Nm ± 10% |
| Frame size B  |  Fixings: 4 x M4 screws 4 x M4 nuts 4 x M4 washers Tightening torque: 1.8 Nm ± 10% |

3.2 Cabinet panel mounting (frame sizes A ... D)

| Dimensions (mm) | Drill pattern (mm) |
|---|---|
| <p>Frame size C</p>   |  <p>Fixings: 4 x M5 screws 4 x M5 nuts 4 x M5 washers Tightening torque: 2.5 Nm ± 10%</p> |
| <p>Frame size D</p>   |  <p>Fixings: 4 x M5 screws 4 x M5 nuts 4 x M5 washers Tightening torque: 2.5 Nm ± 10%</p> |

Mechanical installation

3.3 Push-through mounting (frame sizes B ... D)





3.3 Push-through mounting (frame sizes B ... D)

The frame sizes B to D are designed to be compatible with "push-through" applications, allowing you to mount the heatsink of the inverter through the back of the cabinet panel. When the inverter is mounted as the push-through variant, no higher IP rating is achieved. Make sure that the required IP rating for the enclosure is maintained.



An additional mounting method is also available for different frame sizes. For more details, refer to the following section:

- Cabinet panel mounting (frame sizes A ... D) (Page 16)

Outline dimensions, drill patterns, and cut-outs

| Dimensions (mm) | Drill pattern and cut-out (mm) |
|--|---|
| Frame size B   |  <p>Cut-out area</p> <p>Fixings: 4 x M4 screws Tightening torque: 1.8 Nm ± 10%</p> |
| Frame size C   |  <p>Cut-out area</p> <p>Fixings: 4 x M5 screws Tightening torque: 2.5 Nm ± 10%</p> |

3.3 Push-through mounting (frame sizes B ... D)


| Dimensions (mm) | Drill pattern and cut-out (mm) |
|---|--|
| <p>Frame size D</p>  |  <p>Cut-out area</p> <p>Fixings: 4 x M5 screws Tightening torque: 2.5 Nm ± 10%</p> |

¹⁾ Depth inside the cabinet

Mechanical installation

3.3 Push-through mounting (frame sizes B ... D)

Mounting



1 Push one side of the heatsink through the back of the cabinet panel.


2 Move the heatsink towards the edge of the cut-out area until the concaved slot of the heatsink engages with the edge of the cut-out area.

3 Push the other side of the heatsink through the back of the cabinet panel.

4 Move the heatsink towards the edge of the cut-out area until sufficient space for pushing the entire heatsink through the back of the cabinet panel is left.


5 Push the entire heatsink through the back of the cabinet panel.

6 Align the four mounting holes in the inverter with the corresponding holes in the cabinet panel. Fix the aligned holes with four screws.



NOTICE


A gap is reserved at the bottom of the cut-out area to allow fan removal from outside the cabinet without removing the inverter.



Electrical installation

4.1 Typical system connections

Typical system connections for 400 V variants




4.1 Typical system connections

Recommended fuse types

| Frame size | Recommended fuse type | |
|------------|-------------------------|-----------------------|
| | CE-compliant (Siba URZ) | UL-compliant |
| 400 V | | |
| A | 50 124 34 (16 A) | 15 A 600 VAC, class J |
| B | 50 124 34 (20 A) | 20 A 600 VAC, class J |
| C | 50 140 34 (30 A) | 30 A 600 VAC, class J |
| D | 50 140 34 (63 A) | 60 A 600 VAC, class J |

Wiring diagram




See also

Setting connection macros (Page 41)

4.2 Terminal description

Terminal layout - 400 V variants



User terminals:

| | Transistor output | | | | Relay output | | | | | | | | | | | | | | | |
|---|-------------------|------|------|------|--------------|-----|-----|------|------|------|------|------|------|-----|-------|-------|------|---------|---------|--------|
| | 10 V | AI 1 | AI 2 | AO 1 | 0 V | P + | N - | DI 1 | DI 2 | DI 3 | DI 4 | DI C | 24 V | 0 V | DO 1+ | DO 1- | DO 2 | DO 2 NC | DO 2 NO | DO 2 C |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | | |

Annotations below the table:

- Analog inputs: 1-3
- RS-485: 6-7
- Reference potential for analog I/O: 5
- Analog output: 4
- Digital inputs: 8-12
- Reference potential for digital inputs: 14
- Digital outputs: 15-19

Electrical installation

4.2 Terminal description

Recommended cable cross-sections and screw tightening torques


| Frame size | Rated output power | Cable cross-section | Screw tightening torque (tolerance: $\pm 10\%$) | |
|------------|--------------------|---------------------|--|--|
| | | | Mains and PE terminals | Motor / DC / braking resistor / output earth terminals |
| 400 V | | | | |
| A | 0.37 ... 0.75 kW | 1.0 mm ² | 1.0 Nm | 1.0 Nm |
| | 1.1 ... 2.2 kW | 1.5 mm ² | | 1.5 Nm |
| B | 3.0 ... 4.0 kW | 2.5 mm ² | | |
| C | 5.5 kW | 4.0 mm ² | 2.4 Nm | |
| D | 7.5 kW | 6.0 mm ² | | |
| | 11 ... 15 kW | 10 mm ² | | |

Maximum motor cable lengths

| Frame size | Maximum cable length | |
|---------------|----------------------|----------------|
| | Unshielded cable | Shielded cable |
| A, unfiltered | 50 m | 25 m |
| A, filtered | 50 m | 10 m |
| B | 50 m | 25 m |
| C | 50 m | 25 m |
| D | 50 m | 25 m |

Star-delta connection of the motor

Select delta connection if either a 230 / 400 V motor on a 400 V inverter or a 120 / 230 V motor on a 230 V inverter is supposed to operate at 87 Hz instead of 50 Hz.



User terminals

| | | | | | | | | | | | | | | | | | | |
|------|------|------|------|-----|-----|-----|------|------|------|------|------|------|-----|-------|-------|---------|---------|--------|
| 10 V | AI 1 | AI 2 | AO 1 | 0 V | P + | N - | DI 1 | DI 2 | DI 3 | DI 4 | DI C | 24 V | 0 V | DO 1+ | DO 1- | DO 2 NC | DO 2 NO | DO 2 C |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 |

| | No. | Terminal marking | Description | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------|--------------------------|----------------------------------|---|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| | 1 | 10V | 10 V output (tolerance $\pm 5\%$) referred to 0V, maximum 11 mA, short circuit protected | | | | | | | | | | | | | | | | | | | | | | | | |
| Analog inputs | 2 | AI1 AI2 | Mode: | | | | | AI1: Single-ended, bipolar current and voltage mode AI2: Single-ended, unipolar current and voltage mode | | | | | | | | | | | | | | | | | | | |
| | | | Isolation to control circuit: | | | | | None | | | | | | | | | | | | | | | | | | | |
| | 3 | | Voltage range: | | | | | AI1: -10 ... 10 V; AI2: 0 ... 10 V | | | | | | | | | | | | | | | | | | | |
| | | | Current range: | | | | | 0 ... 20 mA (4 ... 20 mA software selectable) | | | | | | | | | | | | | | | | | | | |
| | | | Voltage mode accuracy: | | | | | $\pm 5\%$ full scale | | | | | | | | | | | | | | | | | | | |
| | | | Current mode accuracy: | | | | | $\pm 5\%$ full scale | | | | | | | | | | | | | | | | | | | |
| | | | Input impedance: | | | | | Voltage mode: > 30 K Current mode: 235 R | | | | | | | | | | | | | | | | | | | |
| | | | Resolution: | | | | | 10-bit | | | | | | | | | | | | | | | | | | | |
| | | | Wire break detect: | | | | | Yes | | | | | | | | | | | | | | | | | | | |
| | | | Threshold 0 \Rightarrow 1 (used as DIN): | | | | | 4.0 V | | | | | | | | | | | | | | | | | | | |
| | | | Threshold 1 \Rightarrow 0 (used as DIN): | | | | | 1.6 V | | | | | | | | | | | | | | | | | | | |
| | | | Response time (digital input mode): | | | | | 4 ms \pm 4 ms | | | | | | | | | | | | | | | | | | | |
| Analog output | 4 | AO1 | Mode: | | | | | Single-ended, unipolar current mode | | | | | | | | | | | | | | | | | | | |
| | | | Isolation to control circuit: | | | | | None | | | | | | | | | | | | | | | | | | | |
| | | | Current range: | | | | | 0 ... 20 mA (4 ... 20 mA - software selectable) | | | | | | | | | | | | | | | | | | | |
| | | | Accuracy (0 ... 20 mA): | | | | | $\pm 1\text{ mA}$ | | | | | | | | | | | | | | | | | | | |
| | | | Output capability: | | | | | 20 mA into 500 R | | | | | | | | | | | | | | | | | | | |
| | 5 | 0V | Overall reference potential for RS485 communication and analog inputs / output | | | | | | | | | | | | | | | | | | | | | | | | |
| | 6 | P+ | RS485 P + | | | | | | | | | | | | | | | | | | | | | | | | |
| | 7 | N- | RS485 N - | | | | | | | | | | | | | | | | | | | | | | | | |
| Digital inputs | 8 9 10 11 12 | DI1 DI2 DI3 DI4 DI C | Mode: | | | | | PNP (reference terminal low) NPN (reference terminal high) Characteristics values are inverted for NPN mode. | | | | | | | | | | | | | | | | | | | |
| | | | Isolation to control circuit: | | | | | 100 V DC (functional low voltage) | | | | | | | | | | | | | | | | | | | |
| | | | Absolute maximum voltage: | | | | | $\pm 35\text{ V}$ for 500 ms every 50 seconds | | | | | | | | | | | | | | | | | | | |
| | | | Operating voltage: | | | | | - 3 V ... 30 V | | | | | | | | | | | | | | | | | | | |
| | | | Threshold 0 \Rightarrow 1 (maximum): | | | | | 11 V | | | | | | | | | | | | | | | | | | | |
| | | | Threshold 1 \Rightarrow 0 (minimum): | | | | | 5 V | | | | | | | | | | | | | | | | | | | |
| | | | Input current (guaranteed off): | | | | | 0.6 ... 2 mA | | | | | | | | | | | | | | | | | | | |
| | | | Input current (maximum on): | | | | | 15 mA | | | | | | | | | | | | | | | | | | | |
| | | | 2-wire Bero compatibility: | | | | | No | | | | | | | | | | | | | | | | | | | |

4.2 Terminal description

| | No. | Terminal marking | Description |
|-----------------------------|-----|------------------|--|
| | | | Response time: 4 ms ± 4 ms |
| | | | Pulse train input: No |
| | 13 | 24V | 24 V output (tolerance - 15 % ... + 20 %) referred to 0 V, maximum 50 mA, non-isolated |
| | 14 | 0V | Overall reference potential for digital inputs |
| Digital output (transistor) | 15 | DO1 + | Mode: Normally open voltage-free terminals, polarised |
| | 16 | DO1 - | Isolation to control circuit: 100 V DC (functional low voltage) |
| | | | Maximum voltage across terminals: ± 35 V |
| | | | Maximum load current: 100 mA |
| | | | Response time: 4 ms ± 4 ms |
| Digital output (relay) | 17 | DO2 NC | Mode: Change-over voltage-free terminals, unpolarised |
| | 18 | DO2 NO | Isolation to control circuit: 4 kV (230 V mains) |
| | 19 | DO2 C | Maximum voltage across terminals: 240 V AC / 30 V DC + 10 % |
| | | | Maximum load current: 0.5 A @ 250 V AC, resistive 0.5 A @ 30 V DC, resistive |
| | | | Response time: Open: 7 ms ± 7 ms Close: 10 ms ± 9 ms |



I/O Terminals 1... 16 are safety extra low voltage (SELV) and must only be connected to low voltage supplies.

Permissible I/O terminal cable cross sections

| Cable type | Permissible cable cross section |
|-----------------------------------|---------------------------------|
| Solid or stranded cable | 0.5 ... 1.5 mm ² |
| Ferrule without insulating sleeve | 0.5 ... 1.0 mm ² |
| Ferrule with insulating sleeve | 0.5 mm ² |

Expansion port

The expansion port is designed for connecting the inverter to the external option module - BOP Interface Module or Parameter Loader, in order to realize the following functions:

- Operating the inverter from the external BOP
- Cloning parameters between the inverter and a standard MMC / SD card
- Powering the inverter from the Parameter Loader, when mains power is not available


For more information about these two option modules, refer to the topics "Parameter Loader (Page 247)" and "External BOP and BOP Interface Module (Page 251)".

4.3 EMC-compliant installation

EMC-compliant installation of the inverter


The screening plate kit is supplied as an option for each frame size (For more information about this option, see Appendix "Screening plate kit (Page 260)".). It allows easy and efficient connection of the necessary screening to achieve EMC-compliant installation of the inverter. If no screening plate kit is used, you can alternatively mount the device and additional components on a metal mounting plate with excellent electrical conductivity and a large contact area. This mounting plate must be connected to the cabinet panel and the PE or EMC bus bar.

The following diagram shows an example of EMC-compliant installation of the inverter frame size B/C.



Screening method

The following illustration shows an example with and without the screening plate.




4.4 EMC-compliant cabinet design

The most cost-effective method of implementing interference suppression measures within the control cabinet is to ensure that interference sources and potentially susceptible equipment are installed separately from each other.

The control cabinet has to be divided into EMC zones and the devices within the control cabinet have to be assigned to these zones following the rules below.

- The different zones must be electromagnetically decoupled by using separate metallic housings or grounded separation plates.
- If necessary, filters and/or coupling modules should be used at the interfaces of the zones.
- Cables connecting different zones must be separated and must not be routed within the same cable harness or cable channel.
- All communication (e.g. RS485) and signal cables leaving the cabinet must be shielded.



5


Commissioning

NOTICE

For a detailed description of parameter settings for the quick commissioning, refer to the topic "Quick commissioning (Page 38)".

5.1 The built-in Basic Operator Panel (BOP)

5.1.1 Introduction to the built-in BOP



Button functions

| | | |
|--|--|--|
| | Stops the inverter | |
| | Single press | OFF1 stop reaction: the inverter brings the motor to a standstill in the ramp-down time set in parameter P1121. Note: If configured to be an OFF1 stop, this button is inactive in AUTO mode. |
| | Double press (< 2 s) or long press (> 3 s) | OFF2 stop reaction: the inverter allows the motor to coast to a standstill without using any ramp-down timings. |
| | Starts the inverter | |
| | If the inverter is started in HAND / JOG mode, the inverter running icon (●) displays. | |
| | Note: This button is inactive if the inverter is configured for control from terminals (P0700 = 2, P1000 = 2) and is in AUTO mode. | |

Commissioning

5.1 The built-in Basic Operator Panel (BOP)

| | | |
|----------------------|--|--|
| | Multi-function button | |
| M | Short press (< 2 s) | <ul style="list-style-type: none"> Enters the parameter setting menu or moves to the next screen Restarts the digit by digit editing on the selected item If pressed twice in digit by digit editing, returns to the previous screen without changing the item being edited |
| | Long press (> 2 s) | <ul style="list-style-type: none"> Returns to the status screen Enters the setup menu |
| OK | Short press (< 2 s) | <ul style="list-style-type: none"> Switches between status values Enters edit value mode or change to the next digit Clears faults |
| | Long press (> 2 s) | <ul style="list-style-type: none"> Quick parameter number or value edit |
| M + OK | Hand / Jog / Auto Press to switch between different modes: | <pre> graph LR A[Auto mode (No icon)] -- "M + OK" --> B[Hand mode (With hand icon)] B -- "M + OK" --> C[Jog mode (With flashing hand icon)] </pre> <p>Note: Jog mode is only available if the motor is stopped.</p> |
| ▲ | <ul style="list-style-type: none"> When navigating a menu, it moves the selection up through the screens available. When editing a parameter value, it increases the displayed value. When the inverter is in RUN mode, it increases the speed. Long press (> 2 s) of the key quickly scrolls up through parameter numbers, indices, or values. | |
| ▼ | <ul style="list-style-type: none"> When navigating a menu, it moves the selection down through the screens available. When editing a parameter value, it decreases the displayed value. When the inverter is in RUN mode, it decreases the speed. Long press (> 2 s) of the key quickly scrolls down through parameter numbers, indices, or values. | |
| ▲ + ▼ | Reverses the direction of rotation of the motor. Pressing the two keys once activates reverse motor rotation. Pressing the two keys once again deactivates reverse rotation of the motor. The reserve icon (↔) on the display indicates that the output speed is opposite to the setpoint. | |


Inverter status icons

| | | |
|----------|--|---|
| ✗ | Inverter has at least one pending fault. | |
| ⚠ | Inverter has at least one pending alarm. | |
| ● | ● : | Inverter is running (motor frequency may be 0 rpm). |
| | ● (flashing): | Inverter may be energized unexpectedly (for example, in frost protection mode). |
| ⟳ | Motor rotates in the reversed direction. | |
| ↷ | ↷ : | Inverter is in HAND mode. |
| | ↷ (flashing): | Inverter is in JOG mode. |

5.1.2 Inverter menu structure

Inverter menu structure

| Menu | Description |
|--------------------------------|---|
| 50 / 60 Hz selection menu | This menu is visible only on first power-up or after a factory reset. |
| Main menu | |
| Display menu (default display) | Basic monitoring view of key parameters such as frequency, voltage, current, DC-link voltage, and so on |
| Setup menu | Access to parameters for quick commissioning of the inverter system |
| Parameter menu | Access to all available inverter parameters |




Commissioning

5.1 The built-in Basic Operator Panel (BOP)

5.1.3 Viewing inverter status

The display menu provides a basic monitoring view of some key parameters such as frequency, voltage, current, and so on.



5.1.4 Editing parameters

This section describes how to edit parameters.

Parameter types

| Parameter type | Description | |
|--------------------------|--|---|
| CDS-dependent parameters | <ul style="list-style-type: none">Dependent on Command Data Set (CDS)Always indexed with [0...2]Available for CDS switching via P0810 and P0811 | |
| DDS-dependent parameters | <ul style="list-style-type: none">Dependent on Inverter Data Set (DDS)Always indexed with [0...2]Available for DDS switching via P0820 and P0821 | |
| Other parameters | Multi-indexed parameters | These parameters are indexed with the range of indices dependent on the individual parameter. |
| | Index-free parameters | These parameters are not indexed. |

Normal editing of parameters

NOTICE

Pressing  or  for longer than two seconds to quickly increase or decrease the parameter numbers or indexes is only possible in the parameter menu.

This editing method is best suited when small changes are required to parameter numbers, indexes, or values.

- To increase or decrease the parameter number, index, or value, press  or  for less than two seconds.
- To quickly increase or decrease the parameter number, index, or value, press  or  for longer than two seconds.
- To confirm the setting, press .
- To cancel the setting, press .

Digit-by-digit editing


NOTICE

Digit-by-digit editing of parameter numbers or indexes is only possible in the parameter menu.

Digit-by-digit editing can be performed on parameter numbers, parameter indexes, or parameter values. This editing method is best suited when large changes are required to parameter numbers, indexes, or values. For information about the inverter menu structure, refer to Section "Inverter menu structure (Page 31)".


- In any edit or scroll mode, digit-by-digit editing is entered by a long press (> 2 s) on .
- The digit-by-digit editing always starts with the rightmost digit.
- Each digit is selected in turn by pressing .
- Pressing  once moves the cursor to the rightmost digit of the current item.
- Pressing  twice in succession exits the digit-by-digit mode without changing the item being edited.
- Pressing  on a digit when there are no further digits to the left saves the value.
- **If more digits are required to the left, then these must be added by scrolling the existing leftmost digit above 9 to add more digits to the left.**
- Pressing  or  for longer than two seconds enters fast digit scrolling.

5.1 The built-in Basic Operator Panel (BOP)



5.1.5 Screen displays

The following two tables show you basic screen displays:

| Screen information | Display | Meaning |
|--------------------|---|---|
| "8 8 8 8 8" |  | Inverter is busy with internal data processing. |
| "- - - -" |  | Action not completed or not possible |
| "Pxxxx" |  | Writable parameter |
| "xxxxx" |  | Read-only parameter |
| "inxxx" |  | Indexed parameter |

| Screen information | Display | Meaning |
|--------------------|-------------------|--|
| Hexadecimal number | E b 3 1 | Parameter value in hex format |
| "bxx x" | b 0 6 0 | Parameter value in bit format bit number signal state: 0: Low 1: High |
| "Fxxx" | F 3 9 5 | Fault code |
| "Axxx" | A 9 3 0 | Alarm code |
| "Cnxxx" | C n 0 0 1 | Settable connection macro |
| "-Cnxxx" | -C n 0 1 1 | Current selected connection macro |
| "APxxx" | R P 0 3 0 | Settable application macro |
| "-APxxx" | -R P 0 1 0 | Current selected application macro |

| | | | | | | | |
|---------|----------------------------|-----|----------|-----|----------|-----|----------|
| "A" | R | "G" | 9 | "N" | ? | "T" | L |
| "B" | b | "H" | h | "O" | o | "U" | u |
| "C" | c | "I" | i | "P" | p | "V" | v |
| "D" | d | "J" | j | "Q" | q | "X" | x |
| "E" | e | "L" | l | "R" | r | "Y" | y |
| "F" | f | "M" | m | "S" | s | "Z" | z |
| 0 ... 9 | 0 1 2 3 4 5 6 7 8 9 | | | | | "?" | . |

5.1.6 LED states

The SINAMICS V20 only has one LED for status indications. The LED can display orange, green, or red.

If more than one inverter state exists, the LED displays in the following priority order:

- Parameter cloning
- Commissioning mode
- All faults
- Ready (no fault)

For example, if there is an active fault when the inverter is in the commissioning mode, the LED flashes green at 0.5 Hz.

| Inverter state | LED color | |
|--------------------|-------------------------------|--|
| Power up | Orange | |
| Ready (no fault) | Green | |
| Commissioning mode | Slow flashing green at 0.5 Hz | |
| All faults | Fast flashing red at 2 Hz | |
| Parameter cloning | Flashing orange at 1 Hz | |

5.2 Checking before power-on

Perform the following checks before you power on the inverter system:

- Check that all cables have been connected correctly and that all relevant product and plant/location safety precautions have been complied with.
- Ensure that the motor and the inverter are configured for the correct supply voltage.
- Tighten all screws to the specified tightening torque.

5.3 Setting the 50 / 60 Hz selection menu

NOTICE


The 50 / 60 Hz selection menu is visible only on first power-up or after a factory reset (P0970). You can make a selection using the BOP or exit the menu without making a selection and the menu will not be displayed unless a factory reset is performed.

The motor base frequency can also be selected by changing P0100 to the desired value.

Functionality

This menu is used to set the motor base frequency according to which region of the world that the motor is used. The menu determines whether power settings (for example, rated motor power P0307) are expressed in [kW] or [hp].

| Parameter | Value | Description |
|-----------|-------|--|
| P0100 | 0 | Motor base frequency is 50 Hz (default) → Europe [kW] |
| | 1 | Motor base frequency is 60 Hz → United States / Canada [hp] |
| | 2 | Motor base frequency is 60 Hz → United States / Canada [kW] |



5.4 Starting the motor for test run

This section explains how to start the motor for a test run to check that the motor speed and rotation direction are correct.

NOTICE

To run the motor, the inverter must be in the display menu (default display) and power-on default state with P0700 (selection of command source) = 1.

If you are now in the setup menu (the inverter displays "P0304"), press **M** for longer than two seconds to exit the setup menu and enter the display menu.

You can start the motor in HAND or JOG mode.

Starting the motor in HAND mode

1. Press **I** to start the motor.
2. Press **O** to stop the motor.

Starting the motor in JOG mode

1. Press **M** + **OK** to switch from HAND to JOG mode (the  icon flashes).
2. Press **I** to start the motor. Release **I** to stop the motor.

5.5 Quick commissioning

5.5.1 Quick commissioning through the setup menu


5.5.1.1 Structure of the setup menu

Functionality of the setup menu

The setup menu guides you through the main steps required for quick commissioning of the inverter system. It consists of the following four sub-menus:

| | Sub-menu | Functionality |
|---|-----------------------------|---|
| 1 | Motor data | Sets nominal motor parameters for quick commissioning |
| 2 | Connection macro selection | Sets macros required for standard wiring arrangements |
| 3 | Application macro selection | Sets macros required for certain common applications |
| 4 | Common parameter selection | Sets parameters necessary for inverter performance optimization |

Menu structure



5.5.1.2 Setting motor data

Functionality

This menu is designed for easy setup of nominal motor nameplate data.

Text menu

If you set P8553 to 1, parameter numbers in this menu are replaced with short text.

Setting parameters

| NOTICE | |
|--|--|
| In the table below, "●" indicates that the value of this parameter must be entered according to the rating plate of the motor. | |

| Parameter | Access level | Function | Text menu (if P8553 = 1) |
|------------|--------------|---|--|
| P0100 | 1 | 50 / 60 Hz selection =0: Europe [kW], 50 Hz (factory default) =1: North America [hp], 60 Hz =2: North America [kW], 60 Hz | E U - U S (EU - US) |
| P0304[0] ● | 1 | Rated motor voltage [V] Note that the input of rating plate data must correspond with the wiring of the motor (star / delta) | N o t e V (MOT V) |
| P0305[0] ● | 1 | Rated motor current [A] Note that the input of rating plate data must correspond with the wiring of the motor (star / delta) | N o t e A (MOT A) |
| P0307[0] ● | 1 | Rated motor power [kW / hp] If P0100 = 0 or 2, motor power unit = [kW] If P0100 = 1, motor power unit = [hp] | P0100 = 0 or 2: N o t e P (MOT P) P0100 = 1: N o t e h P (MOT HP) |
| P0308[0] ● | 1 | Rated motor power factor (cosφ) Visible only when P0100 = 0 or 2 | N C o S (M COS) |
| P0309[0] ● | 1 | Rated motor efficiency [%] Visible only when P0100 = 1 Setting 0 causes internal calculation of value. | N E F F (M EFF) |
| P0310[0] ● | 1 | Rated motor frequency [Hz] | N F r E q (M FREQ) |

| Parameter | Access level | Function | Text menu (if P8553 = 1) |
|------------|--------------|--|---|
| P0311[0] • | 1 | Rated motor speed [RPM] |  |
| P1900 | 2 | Select motor data identification = 0: Disabled = 2: Identification of all parameters in standstill |  |

See also

Parameter list (Page 117)

5.5.1.3 Setting connection macros

CAUTION

When commissioning the inverter, the connection macro setting is a one-off setting. Make sure that you proceed as follows before you change the connection macro setting to a value different from your last setting:

1. Do a factory reset (P0010 = 30, P0970 = 1)
2. Repeat the quick commissioning and change the connection macro

Failure to observe may cause the inverter to accept the parameter settings from both the currently and the previously selected macros, which may lead to undefined and unexplainable inverter operation.

However, communication parameters P2010, P2011, P2021 and P2023 for connection macros Cn010 and Cn011 are not reset automatically after a factory reset. If necessary, reset them manually.

After changing P2023 setting for Cn010 or Cn011, power-cycle the inverter. During the power-cycle, wait until LED has gone off or the display has gone blank (may take a few seconds) before re-applying power.

Functionality

This menu selects which macro is required for standard wiring arrangements. The default one is "Cn000" for connection macro 0.

All connection macros only change the CDS0 (command data set 0) parameters. The CDS1 parameters are used for the BOP control.


| Connection macro | Description | Display example |
|------------------|--|---|
| Cn000 | Factory default setting. Makes no parameter changes. |  |
| Cn001 | BOP as the only control source |  |
| Cn002 | Control from terminals (PNP / NPN) | |
| Cn003 | Fixed speeds | |
| Cn004 | Fixed speed binary mode | |
| Cn005 | Analog input and fixed frequency | |
| Cn006 | External push button control | The minus sign indicates that this macro is the currently selected macro. |

Commissioning


5.5 Quick commissioning

| Connection macro | Description | Display example |
|------------------|--|-----------------|
| Cn007 | External push button with analog setpoint | |
| Cn008 | PID control with analog input reference | |
| Cn009 | PID control with the fixed value reference | |
| Cn010 | USS control | |
| Cn011 | MODBUS RTU control | |

Setting connection macros



Connection macro Cn001 - BOP as the only control source





Connection macro settings:

| Parameter | Description | Factory default | Default for Cn001 | Remarks |
|-----------|----------------------------------|-----------------|-------------------|-----------------------|
| P0700[0] | Selection of command source | 1 | 1 | BOP |
| P1000[0] | Selection of frequency | 1 | 1 | BOP MOP |
| P0731[0] | BI: Function of digital output 1 | 52.3 | 52.2 | Inverter running |
| P0732[0] | BI: Function of digital output 2 | 52.7 | 52.3 | Inverter fault active |
| P0771[0] | Cl: Analog output | 21 | 21 | Actual frequency |
| P0810[0] | BI: CDS bit 0 (Hand/Auto) | 0 | 0 | Hand mode |

Connection macro Cn002 - Control from terminals (PNP / NPN)

External control - Potentiometer with setpoint

- Hand / Auto switch between the BOP and terminals by pressing **M** + **OK**
- Both NPN and PNP can be realized with the same parameters. You can change the connection of the digital input common terminal to 24 V or 0 V to decide the mode.



Connection macro settings:

| Parameter | Description | Factory default | Default for Cn002 | Remarks |
|-----------|-----------------------------|-----------------|-------------------|----------------------------|
| P0700[0] | Selection of command source | 1 | 2 | Terminal as command source |
| P1000[0] | Selection of frequency | 1 | 2 | Analog as speed setpoint |
| P0701[0] | Function of digital input 1 | 0 | 1 | ON / OFF |
| P0702[0] | Function of digital input 2 | 0 | 12 | Reverse |

Commissioning


5.5 Quick commissioning

| Parameter | Description | Factory default | Default for Cn002 | Remarks |
|-----------|----------------------------------|-----------------|-------------------|-----------------------|
| P0703[0] | Function of digital input 3 | 9 | 9 | Fault acknowledgement |
| P0704[0] | Function of digital input 4 | 15 | 10 | JOG forward |
| P0771[0] | CI: Analog output | 21 | 21 | Actual frequency |
| P0731[0] | BI: Function of digital output 1 | 52.3 | 52.2 | Inverter running |
| P0732[0] | BI: Function of digital output 2 | 52.7 | 52.3 | Inverter fault active |

Connection macro Cn003 - Fixed speeds

Three fixed speeds with ON / OFF

- Hand / Auto switch between the BOP and terminal by pressing **M** + **OK**
- If more than one fixed frequency is selected at the same time, the selected frequencies are summed, e.g. FF1 + FF2 + FF3



Connection macro settings:


| Parameter | Description | Factory default | Default for Cn003 | Remarks |
|-----------|-------------------------------------|-----------------|-------------------|----------------------------|
| P0700[0] | Selection of command source | 1 | 2 | Terminal as command source |
| P1000[0] | Selection of frequency | 1 | 3 | Fixed frequency |
| P0701[0] | Function of digital input 1 | 0 | 1 | ON / OFF |
| P0702[0] | Function of digital input 2 | 0 | 15 | Fixed speed bit 0 |
| P0703[0] | Function of digital input 3 | 9 | 16 | Fixed speed bit 1 |
| P0704[0] | Function of digital input 4 | 15 | 17 | Fixed speed bit 2 |
| P1016[0] | Fixed frequency mode | 1 | 1 | Direct selection mode |
| P1020[0] | BI: Fixed frequency selection bit 0 | 722.3 | 722.1 | DI2 |
| P1021[0] | BI: Fixed frequency selection bit 1 | 722.4 | 722.2 | DI3 |
| P1022[0] | BI: Fixed frequency selection bit 2 | 722.5 | 722.3 | DI4 |
| P1001[0] | Fixed frequency 1 | 10 | 10 | Speed low |
| P1002[0] | Fixed frequency 2 | 15 | 15 | Speed middle |

| Parameter | Description | Factory default | Default for Cn003 | Remarks |
|-----------|----------------------------------|-----------------|-------------------|-----------------------|
| P1003[0] | Fixed frequency 3 | 25 | 25 | Speed high |
| P0771[0] | Cl: Analog output | 21 | 21 | Actual frequency |
| P0731[0] | Bl: Function of digital output 1 | 52.3 | 52.2 | Inverter running |
| P0732[0] | Bl: Function of digital output 2 | 52.7 | 52.3 | Inverter fault active |

Connection macro Cn004 - Fixed speeds in binary mode

Fixed speeds with ON command in binary mode

- Up to 16 different fixed frequency values (0 Hz, P1001 ... P1015) can be selected by the fixed frequency selectors (P1020 ... P1023)



Connection macro settings:

| Parameter | Description | Factory default | Default for Cn004 | Remarks |
|-----------|-------------------------------------|-----------------|-------------------|---|
| P0700[0] | Selection of command source | 1 | 2 | Terminals as command source |
| P1000[0] | Selection of frequency | 1 | 3 | Fixed frequency |
| P0701[0] | Function of digital input 1 | 0 | 15 | Fixed speed bit 0 |
| P0702[0] | Function of digital input 2 | 0 | 16 | Fixed speed bit 1 |
| P0703[0] | Function of digital input 3 | 9 | 17 | Fixed speed bit 2 |
| P0704[0] | Function of digital input 4 | 15 | 18 | Fixed speed bit 3 |
| P1016[0] | Fixed frequency mode | 1 | 2 | Binary mode |
| P0840[0] | Bl: ON / OFF1 | 19.0 | 1025.0 | Inverter starts at the fixed speed selected |
| P1020[0] | Bl: Fixed frequency selection bit 0 | 722.3 | 722.0 | DI1 |
| P1021[0] | Bl: Fixed frequency selection bit 1 | 722.4 | 722.1 | DI2 |
| P1022[0] | Bl: Fixed frequency selection bit 2 | 722.5 | 722.2 | DI3 |
| P1023[0] | Bl: Fixed frequency selection bit 3 | 722.6 | 722.3 | DI4 |
| P0771[0] | Cl: Analog output | 21 | 21 | Actual frequency |
| P0731[0] | Bl: Function of digital output 1 | 52.3 | 52.2 | Inverter running |

Commissioning


5.5 Quick commissioning

| Parameter | Description | Factory default | Default for Cn004 | Remarks |
|-----------|----------------------------------|-----------------|-------------------|-----------------------|
| P0732[0] | BI: Function of digital output 2 | 52.7 | 52.3 | Inverter fault active |

Connection macro Cn005 - Analog input and fixed frequency


The analog input works as an additional setpoint.

- If DI2 and DI3 are active together, the selected frequencies are summed, i.e. FF1 + FF2



Function diagram

When the fixed speed is selected, the additional setpoint channel from the analog is disabled. If there is no fixed speed setpoint, the setpoint channel connects to the analog input.




Connection macro settings:

| Parameter | Description | Factory default | Default for Cn005 | Remarks |
|-----------|-----------------------------|-----------------|-------------------|-----------------------------------|
| P0700[0] | Selection of command source | 1 | 2 | Terminals as command source |
| P1000[0] | Selection of frequency | 1 | 23 | Fixed frequency + analog setpoint |
| P0701[0] | Function of digital input 1 | 0 | 1 | ON / OFF |
| P0702[0] | Function of digital input 2 | 0 | 15 | Fixed speed bit 0 |
| P0703[0] | Function of digital input 3 | 9 | 16 | Fixed speed bit 1 |

| Parameter | Description | Factory default | Default for Cn005 | Remarks |
|-----------|-------------------------------------|-----------------|-------------------|-------------------------------------|
| P0704[0] | Function of digital input 4 | 15 | 9 | Fault acknowledgement |
| P1016[0] | Fixed frequency mode | 1 | 1 | Direct selection mode |
| P1020[0] | BI: Fixed frequency selection bit 0 | 722.3 | 722.1 | DI2 |
| P1021[0] | BI: Fixed frequency selection bit 1 | 722.4 | 722.2 | DI3 |
| P1001[0] | Fixed frequency 1 | 10 | 10 | Fixed speed 1 |
| P1002[0] | Fixed frequency 2 | 15 | 15 | Fixed speed 2 |
| P1074[0] | BI: Disable additional setpoint | 0 | 1025.0 | FF disables the additional setpoint |
| P0771[0] | CI: Analog output | 21 | 21 | Actual frequency |
| P0731[0] | BI: Function of digital output 1 | 52.3 | 52.2 | Inverter running |
| P0732[0] | BI: Function of digital output 2 | 52.7 | 52.3 | Inverter fault active |

Connection macro Cn006 - External push button control

Note that the command sources are pulse signals.



Connection macro settings:

| Parameter | Description | Factory default | Default for Cn006 | Remarks |
|-----------|----------------------------------|-----------------|-------------------|--|
| P0700[0] | Selection of command source | 1 | 2 | Terminals as command source |
| P1000[0] | Selection of frequency | 1 | 1 | BOP MOP |
| P0701[0] | Function of digital input 1 | 0 | 2 | OFF1 / hold |
| P0702[0] | Function of digital input 2 | 0 | 1 | ON pulse |
| P0703[0] | Function of digital input 3 | 9 | 13 | MOP up pulse |
| P0704[0] | Function of digital input 4 | 15 | 14 | MOP down pulse |
| P0727[0] | Selection of 2 / 3-wire method | 0 | 3 | 3-wire ON pulse + OFF1 / HOLD + Reverse |
| P0771[0] | CI: Analog output | 21 | 21 | Actual frequency |
| P0731[0] | BI: Function of digital output 1 | 52.3 | 52.2 | Inverter running |



Commissioning

5.5 Quick commissioning

| Parameter | Description | Factory default | Default for Cn006 | Remarks |
|-----------|----------------------------------|-----------------|-------------------|---|
| P0732[0] | BI: Function of digital output 2 | 52.7 | 52.3 | Inverter fault active |
| P1040[0] | Setpoint of the MOP | 5 | 0 | Initial frequency |
| P1047[0] | MOP ramp-up time of the RFG | 10 | 10 | Ramp-up time from zero to maximum frequency |
| P1048[0] | MOP ramp-down time of the RFG | 10 | 10 | Ramp-down time from maximum frequency to zero |

Connection macro Cn007 - External push buttons with analog control

Note that the command sources are pulse signals.




Connection macro settings:

| Parameter | Description | Factory default | Default for Cn007 | Remarks |
|-----------|-----------------------------|-----------------|-------------------|-----------------------------|
| P0700[0] | Selection of command source | 1 | 2 | Terminals as command source |
| P1000[0] | Selection of frequency | 1 | 2 | Analog |
| P0701[0] | Function of digital input 1 | 0 | 1 | OFF hold |
| P0702[0] | Function of digital input 2 | 0 | 2 | Forward pulse + ON |
| P0703[0] | Function of digital input 3 | 9 | 12 | Reverse pulse + ON |
| P0704[0] | Function of digital input 4 | 15 | 9 | Fault acknowledgement |

| Parameter | Description | Factory default | Default for Cn007 | Remarks |
|-----------|----------------------------------|-----------------|-------------------|--|
| P0727[0] | Selection of 2 / 3-wire method | 0 | 2 | 3-wire STOP + Forward pulse + Reverse pulse |
| P0771[0] | CI: Analog output | 21 | 21 | Actual frequency |
| P0731[0] | BI: Function of digital output 1 | 52.3 | 52.2 | Inverter running |
| P0732[0] | BI: Function of digital output 2 | 52.7 | 52.3 | Inverter fault active |

Connection macro Cn008 - PID control with analog reference



NOTICE

If a negative setpoint for the PID control is desired, change the setpoint and feedback wiring as needed.

When you switch to Hand mode from PID control mode, P2200 becomes 0 to disable the PID control. When you switch it back to Auto mode, P2200 becomes 1 to enable the PID control again.

Connection macro settings:


| Parameter | Description | Factory default | Default for Cn008 | Remarks |
|-----------|-----------------------------|-----------------|-------------------|-------------------------------|
| P0700[0] | Selection of command source | 1 | 2 | Terminals as command source |
| P0701[0] | Function of digital input 1 | 0 | 1 | ON / OFF |
| P0703[0] | Function of digital input 3 | 9 | 9 | Fault acknowledgement |
| P2200[0] | Enable PID controller | 0 | 1 | Enable PID |
| P2253[0] | CI: PID setpoint | 0 | 755.0 | PID setpoint = Analog input 1 |
| P2264[0] | CI: PID feedback | 755.0 | 755.1 | PID feedback = Analog input 2 |
| P0756[1] | Type of AI | 0 | 2 | Analog input 2 0 ... 20 mA |
| P0771[0] | CI: Analog output | 21 | 21 | Actual frequency |

Commissioning

5.5 Quick commissioning

| Parameter | Description | Factory default | Default for Cn008 | Remarks |
|-----------|----------------------------------|-----------------|-------------------|-----------------------|
| P0731[0] | BI: Function of digital output 1 | 52.3 | 52.2 | Inverter running |
| P0732[0] | BI: Function of digital output 2 | 52.7 | 52.3 | Inverter fault active |


Connection macro Cn009 - PID control with the fixed value reference



Connection macro settings:


| Parameter | Description | Factory default | Default for Cn009 | Remarks |
|-----------|-------------------------------------|-----------------|-------------------|-----------------------------|
| P0700[0] | Selection of command source | 1 | 2 | Terminals as command source |
| P0701[0] | Function of digital input 1 | 0 | 1 | ON / OFF |
| P0702[0] | Function of digital input 2 | 0 | 15 | DI2 = PID fixed value 1 |
| P0703[0] | Function of digital input 3 | 9 | 16 | DI3 = PID fixed value 2 |
| P0704[0] | Function of digital input 4 | 15 | 17 | DI4 = PID fixed value 3 |
| P2200[0] | Enable PID controller | 0 | 1 | Enable PID |
| P2216[0] | Fixed PID setpoint mode | 1 | 1 | Direct selection |
| P2220[0] | BI: Fixed PID setpoint select bit 0 | 722.3 | 722.1 | BICO connection DI2 |
| P2221[0] | BI: Fixed PID setpoint select bit 1 | 722.4 | 722.2 | BICO connection DI3 |
| P2222[0] | BI: Fixed PID setpoint select bit 2 | 722.5 | 722.3 | BICO connection DI4 |
| P2253[0] | CI: PID setpoint | 0 | 2224 | PID setpoint = fixed value |
| P2264[0] | CI: PID feedback | 755.0 | 755.1 | PID feedback = AI2 |

Connection macro Cn010 - USS control



| Parameter | Description | Factory default | Default for Cn010 | Remarks |
|-----------|--------------------------------|-----------------|-------------------|-----------------------------|
| P0700[0] | Selection of command source | 1 | 5 | RS485 as the command source |
| P1000[0] | Selection of frequency | 1 | 5 | RS485 as the speed setpoint |
| P2023[0] | RS485 protocol selection | 1 | 1 | USS protocol |
| P2010[0] | USS / MODBUS baudrate | 8 | 8 | Baudrate 38400 bps |
| P2011[0] | USS address | 0 | 1 | USS address for inverter |
| P2012[0] | USS PZD length | 2 | 2 | Number of PZD words |
| P2013[0] | USS PKW length | 127 | 127 | Variable PKW words |
| P2014[0] | USS / MODBUS telegram off time | 2000 | 500 | Time to receive data |

Connection macro Cn011 - MODBUS RTU control



Connection macro settings:

| Parameter | Description | Factory default | Default for Cn011 | Remarks |
|-----------|-----------------------------|-----------------|-------------------|-----------------------------|
| P0700[0] | Selection of command source | 1 | 5 | RS485 as the command source |
| P1000[0] | Selection of frequency | 1 | 5 | RS485 as the speed setpoint |
| P2023[0] | RS485 protocol selection | 1 | 2 | MODBUS RTU protocol |
| P2010[0] | USS / MODBUS baudrate | 8 | 6 | Baudrate 9600 bps |

5.5 Quick commissioning

| Parameter | Description | Factory default | Default for Cn011 | Remarks |
|-----------|--------------------------------|-----------------|-------------------|---|
| P2021[0] | MODBUS address | 1 | 1 | MODBUS address for inverter |
| P2022[0] | MODBUS reply timeout | 1000 | 1000 | Maximum time to send reply back to the master |
| P2014[0] | USS / MODBUS telegram off time | 2000 | 100 | Time to receive data |

5.5.1.4 Setting application macros**CAUTION**

When commissioning the inverter, the application macro setting is a one-off setting. Make sure that you proceed as follows before you change the application macro setting to a value different from your last setting:

1. Do a factory reset (P0010 = 30, P0970 = 1)
2. Repeat the quick commissioning and change the application macro

Failure to observe may cause the inverter to accept the parameter settings from both the currently and the previously selected macros, which may lead to undefined and unexplainable operation.


Functionality

This menu defines certain common applications. Each application macro provides a set of parameter settings for a specific application. After you select an application macro, the corresponding settings are applied to the inverter to simplify the commissioning process.

The default application macro is "AP000" for application macro 0. If none of the application macros fits your application, select the one that is the closest to your application and make further parameter changes as desired.

| Application macro | Description | Display example |
|-------------------|--|---|
| AP000 | Factory default setting. Makes no parameter changes. | -AP000 |
| AP010 | Simple pump applications | |
| AP020 | Simple fan applications | |
| AP021 | Compressor applications | AP010 |
| AP030 | Conveyor applications | The minus sign indicates that this macro is the currently selected macro. |

Setting application macros



Application macro AP010 - Simple pump applications

| Parameter | Description | Factory default | Default for AP010 | Remarks |
|-----------|---|-----------------|-------------------|---|
| P1080[0] | Minimum frequency | 0 | 15 | Inverter running at a lower speed inhibited |
| P1300[0] | Control mode | 0 | 7 | Quadratic V/f |
| P1110[0] | BI: Inhibit negative frequency setpoint | 0 | 1 | Reverse pump rotation inhibited |
| P1210[0] | Automatic restart | 1 | 2 | Fault acknowledgement at power-on |
| P1120[0] | Ramp-up time | 10 | 10 | Ramp-up time from zero to maximum frequency |
| P1121[0] | Ramp-down time | 10 | 10 | Ramp-down time from maximum frequency to zero |

Application macro AP020 - Simple fan applications

| Parameter | Description | Factory default | Default for AP020 | Remarks |
|-----------|---|-----------------|-------------------|---|
| P1110[0] | BI: Inhibit negative frequency setpoint | 0 | 1 | Reverse fan rotation inhibited |
| P1300[0] | Control mode | 0 | 7 | Quadratic V/f |
| P1200[0] | Flying start | 0 | 2 | Search for the speed of the running motor with a heavy inertia load so that the motor runs up to the setpoint |
| P1210[0] | Automatic restart | 1 | 2 | Fault acknowledgement at power-on |

Commissioning

5.5 Quick commissioning

| Parameter | Description | Factory default | Default for AP020 | Remarks |
|-----------|-------------------|-----------------|-------------------|---|
| P1080[0] | Minimum frequency | 0 | 20 | Inverter running at a lower speed inhibited |
| P1120[0] | Ramp-up time | 10 | 10 | Ramp-up time from zero to maximum frequency |
| P1121[0] | Ramp-down time | 10 | 20 | Ramp-down time from maximum frequency to zero |

Application macro AP021 - Compressor applications

| Parameter | Description | Factory default | Default for AP021 | Remarks |
|-----------|--------------------|-----------------|-------------------|--|
| P1300[0] | Control mode | 0 | 0 | Linear V/f |
| P1080[0] | Minimum frequency | 0 | 10 | Inverter running at a lower speed inhibited |
| P1312[0] | Starting boost | 0 | 30 | Boost only effective when accelerating for the first time (standstill) |
| P1311[0] | Acceleration boost | 0 | 0 | Boost only effective when accelerating or braking |
| P1310[0] | Continuous boost | 50 | 50 | Additional boost over the complete frequency range |
| P1120[0] | Ramp-up time | 10 | 10 | Ramp-up time from zero to maximum frequency |
| P1121[0] | Ramp-down time | 10 | 10 | Ramp-down time from maximum frequency to zero |

Application macro AP030 - Conveyor applications

| Parameter | Description | Factory default | Default for AP030 | Remarks |
|-----------|----------------|-----------------|-------------------|--|
| P1300[0] | Control mode | 0 | 1 | V/f with FCC |
| P1312[0] | Starting boost | 0 | 30 | Boost only effective when accelerating for the first time (standstill) |
| P1120[0] | Ramp-up time | 10 | 5 | Ramp-up time from zero to maximum frequency |
| P1121[0] | Ramp-down time | 10 | 5 | Ramp-down time from maximum frequency to zero |

5.5.1.5 Setting common parameters

Functionality

This menu provides some common parameters for inverter performance optimization.

Text menu

If you set P8553 to 1, parameter numbers in this menu are replaced with short text.

Setting parameters

| Parameter | Access level | Function | Text menu (if P8553 = 1) |
|-----------|--------------|----------------------------|-----------------------------|
| P1080[0] | 1 | Minimum motor frequency | Мин РП (MN RPM) |
| P1082[0] | 1 | Maximum motor frequency | Макс РП (MX RPM) |
| P1120[0] | 1 | Ramp-up time | РП РУП (RMP UP) |
| P1121[0] | 1 | Ramp-down time | РП РДН (RMP DN) |
| P1058[0] | 2 | JOG frequency | ДОГР (JOG P) |
| P1060[0] | 2 | JOG ramp-up time | ДОГРУП (JOG UP) |
| P1001[0] | 2 | Fixed frequency setpoint 1 | Ф1 HF1 (FIX F1) |
| P1002[0] | 2 | Fixed frequency setpoint 2 | Ф2 HF2 (FIX F2) |

Commissioning

5.5 Quick commissioning

| Parameter | Access level | Function | Text menu (if P8553 = 1) |
|-----------|--------------|--------------------------------|-----------------------------|
| P1003[0] | 2 | Fixed frequency setpoint 3 | F , HF3 (FIX F3) |
| P2201[0] | 2 | Fixed PID frequency setpoint 1 | P , dF1 (PID F1) |
| P2202[0] | 2 | Fixed PID frequency setpoint 2 | P , dF2 (PID F2) |
| P2203[0] | 2 | Fixed PID frequency setpoint 3 | P , dF3 (PID F3) |

5.5.2 Quick commissioning through the parameter menu

As an alternative to quick commissioning through the setup menu, commissioning using the parameter menu provides the other solution for quick commissioning. This would be helpful for those who are used to commissioning the inverter in this way.

Setting parameters

NOTICE

In the table below, "●" indicates that the value of this parameter must be entered according to the rating plate of the motor.

| Parameter | Function | Setting |
|------------|-------------------------|--|
| P0003 | User access level | = 3 (Expert access level) |
| P0010 | Commissioning parameter | = 1 (quick commissioning) |
| P0100 | 50 / 60 Hz selection | Set a value, if necessary: =0: Europe [kW], 50 Hz (factory default) =1: North America [hp], 60 Hz =2: North America [kW], 60 Hz |
| P0304[0] ● | Rated motor voltage [V] | Range: 10 ... 2000 Note: The input of rating plate data must correspond with the wiring of the motor (star / delta) |

| Parameter | Function | Setting |
|--------------|---|--|
| P0305[0] • | Rated motor current [A] | <p>Range: 0.01 ... 10000</p> <p>Note: The input of rating plate data must correspond with the wiring of the motor (star / delta)</p> |
| P0307[0] • | Rated motor power [kW / hp] | <p>Range: 0.01 ... 2000.0</p> <p>Note: If P0100 = 0 or 2, motor power unit = [kW] If P0100 = 1, motor power unit = [hp]</p> |
| P0308[0] • | Rated motor power factor ($\cos\phi$) | <p>Range: 0.000 ... 1.000</p> <p>Note: This parameter is visible only when P0100 = 0 or 2</p> |
| P0309[0] • | Rated motor efficiency [%] | <p>Range: 0.0 ... 99.9</p> <p>Note: Visible only when P0100 = 1 Setting 0 causes internal calculation of value.</p> |
| P0310[0] • | Rated motor frequency [Hz] | Range: 12.00 ... 599.00 |
| P0311[0] • | Rated motor speed [RPM] | Range: 0 ... 40000 |
| P0335[0] | Motor cooling | <p>Set according to the actual motor cooling method</p> <ul style="list-style-type: none"> = 0: Self-cooled (factory default) = 1: Force-cooled = 2: Self-cooled and internal fan = 3: Force-cooled and internal fan |
| P0640[0] | Motor overload factor [%] | <p>Range: 10.0 ... 400.0 (factory default: 150.0)</p> <p>Note: The parameter defines motor overload current limit relative to P0305 (rated motor current).</p> |
| P0700[0...2] | Selection of command source | <ul style="list-style-type: none"> = 0: Factory default setting = 1: Operator panel (factory default) = 2: Terminal = 5: USS / MODBUS on RS485 |
| P1000[0] | Selection of frequency setpoint | <p>Range: 0 ... 77 (factory default: 1)</p> <ul style="list-style-type: none"> = 0: No main setpoint = 1: MOP setpoint = 2: Analog setpoint = 3: Fixed frequency = 5: USS on RS485 = 7: Analog setpoint 2 <p>For additional settings, see Chapter "Parameter list (Page 117)".</p> |
| P1080[0] | Minimum frequency [Hz] | <p>Range: 0.00 ... 599.00 (factory default: 0.00)</p> <p>Note: The value set here is valid for both clockwise and counter-clockwise rotation.</p> |

Commissioning

5.5 Quick commissioning

| Parameter | Function | Setting |
|-----------|----------------------------------|---|
| P1082[0] | Maximum frequency [Hz] | <p>Range: 0.00 ... 599.00 (factory default: 50.00)</p> <p>Note: The value set here is valid for both clockwise and counter-clockwise rotation</p> |
| P1120[0] | Ramp-up time [s] | <p>Range: 0.00 ... 650.00 (factory default: 10.00)</p> <p>Note: The value set here means the time taken for motor to accelerate from standstill up to the maximum motor frequency (P1082) when no rounding is used.</p> |
| P1121[0] | Ramp-down time [s] | <p>Range: 0.00 ... 650.00 (factory default: 10.00)</p> <p>Note: The value set here means the time taken for motor to decelerate from the maximum motor frequency (P1082) down to standstill when no rounding is used.</p> |
| P1300[0] | Control mode | <ul style="list-style-type: none"> = 0: V/f with linear characteristic (factory default) = 1: V/f with FCC = 2: V/f with quadratic characteristic = 3: V/f with programmable characteristic = 4: V/f with linear eco = 5: V/f for textile applications = 6: V/f with FCC for textile applications = 7: V/f with quadratic eco = 19: V/f control with independent voltage setpoint |
| P3900 | End of quick commissioning | <ul style="list-style-type: none"> = 0: No quick commissioning (factory default) = 1: End quick commissioning with factory reset = 2: End quick commissioning = 3: End quick commissioning only for motor data <p>Note: After completion of calculation, P3900 and P0010 are automatically reset to their original value 0. The inverter displays "8.8.8.8.8" which indicates that it is busy with internal data processing.</p> |
| P1900 | Select motor data identification | <ul style="list-style-type: none"> = 0: Disabled = 2: Identification of all parameters in standstill |

5.6 Function commissioning

5.6.1 Overview of inverter functions

The list below provides an overview of the main functions that the SINAMICS V20 supports. For detailed description of individual parameters, see Chapter "Parameter list (Page 117)".

- User access level control (P0003)
- 50 / 60 Hz customization (P0100) (see also "Setting the 50 / 60 Hz selection menu (Page 37)".)
- Text menu display (P8553) (see also "Setting motor data (Page 40)" and "Setting common parameters (Page 55)".)
- Protection of user-defined parameters (P0011, P0012, P0013)
- Pre-configured connection macros and application macros (P0507, P0717) (see also "Setting connection macros (Page 41)" and "Setting application macros (Page 52)".)
- Energy consumption monitoring (r0039, P0040, P0042, P0043)
- Inverter keep-running operation (P0503)
- Motor frequency display scaling (P0511, r0512)
- DI terminal function control (P0701 ... P0713, r0722, r0724)
- AI terminal function control (P0712, P0713, r0750 ... P0762)
- DO terminal function control (P0731, P0732, P0747, P0748)
- AO terminal function control (P0773 ... r0785)
- 2 / 3 wire control (P0727)
- Parameter cloning (P0802 ... P0804, P8458) (see also "Parameter Loader (Page 247)".)
- Command data set (CDS) and inverter data set (DDS) (r0050, r0051, P0809 ... P0821)
- Various stop mode selection (P0840 ... P0886, see also "Selecting the stop mode (Page 61)".)
- Command and setpoint source selection (P0700, P0719, P1000 ... r1025, P1070 ... r1084)
- Fault and warning reaction setting (r0944 ... P0952, P2100 ... P2120, r3113, P3981)
- Motorized potentiometer (MOP) mode selection (P1031 ... r1050)
- JOG mode operation (P1055 ... P1061, see also "Running the inverter in JOG mode (Page 63)".)
- Skip frequency and resonance damping (P1091 ... P1101, P1338)
- Dual ramp operation (r1119 ... r1199, P2150 ... P2166, see also "Setting the dual ramp function (Page 103)".)
- Flying start (P1200 ... r1204, see also "Setting the flying start function (Page 92)".)
- Automatic restart (P1210, P1211, see also "Setting the automatic restart function (Page 93)".)

5.6 Function commissioning

- Motor brake controls (holding brake, DC brake, compound brake and dynamic brake) (P1212 ... P1237, see also "Setting the braking function (Page 69)".)
- DC-link voltage control (P0210, P1240 ... P1257, see also "Setting the Vdc controller (Page 81)".)
- I_{max} control (P1340 ... P1346, see also "Setting the I_{max} controller (Page 79)".)
- Continuous boost, acceleration boost and starting boost level control (P1310 ... P1316, see also "Setting the voltage boost (Page 64)".)
- Programmable V/f coordinates (P1320 ... P1333)
- Slip compensation (P1334 ... P1338)
- Economy mode (see "Running the inverter in economy mode (Page 89)".)
- Super torque mode (see "Starting the motor in super torque mode (Page 83)".)
- Hammer start mode (see "Starting the motor in hammer start mode (Page 85) ".)
- Blockage clearing mode (see "Starting the motor in blockage clearing mode (Page 87)"")
- Adjustable PWM modulation (P1800 ... P1803)
- USS / MODBUS communication on RS485 (P2010 ... P2037)
- Cavitation protection (P2360 ... P2362, see also "Running the inverter in cavitation protection mode (Page 101)".)
- Sleep (hibernation) mode (P2365 ... P2367, see also "Running the inverter in sleep mode (Page 96)".)
- Motor staging (P2370 ... P2380, see also "Running the inverter in motor staging mode (Page 98)".)
- PID controller (P2200 ... P2355, see also "Setting the PID controller (Page 67)".)
- Motor blocking, load missing, belt failure detection (P2177 ... r2198, see also "Setting the load torque monitoring function (Page 82)".)
- Free function blocks (FFBs) (P2800 ... P2890, see also "Setting the free function blocks (FFBs) (Page 91)".)
- Frost protection (P3852, P3853, see also "Running the inverter in frost protection mode (Page 94)".)
- Condensation protection (P3854, see also "Running the inverter in condensation protection mode (Page 95)".)
- Wobble function (P2940 ... r2955, see also "Setting the wobble generator (Page 97)".)
- BICO function (r3978)

5.6.2 Commissioning basic functions


5.6.2.1 Selecting the stop mode

Functionality

Both the inverter and the user have to respond to a wide range of situations and stop the inverter if needed. Thus operating requirements as well as inverter protective functions (e.g. electrical or thermal overload), or rather man-machine protective functions, have to be taken into account. Due to the different OFF functions (OFF1, OFF2, OFF3) the inverter can flexibly respond to the mentioned requirements. Note that after an OFF2 / OFF3 command, the inverter is in the state "ON inhibit". To switch the motor on again, you need a signal low → high of the ON command.

OFF1

The OFF1 command is closely coupled to the ON command. When the ON command is withdrawn, then OFF1 is directly activated. The inverter is braked by OFF1 with the ramp-down time P1121. If the output frequency falls below the parameter value P2167 and if the time in P2168 has expired, then the inverter pulses are cancelled.




NOTICE

- OFF1 can be entered using a wide range of command sources via BICO parameter P0840 (BI: ON / OFF1) and P0842 (BI: ON / OFF1 with reversing).
- BICO parameter P0840 is pre-assigned by defining the command source using P0700.
- The ON and the following OFF1 command must have the same source.
- If the ON / OFF1 command is set for more than one digital input, then only the digital input, that was last set, is valid.
- OFF1 is active low.
- When simultaneously selecting the various OFF commands, the following priority applies: OFF2 (highest priority) – OFF3 – OFF1.
- OFF1 can be combined with DC current braking or compound braking.
- When the motor holding brake MHB (P1215) is activated, for an OFF1, P2167 and P2168 are not taken into account.

OFF2

The inverter pulses are immediately cancelled by the OFF2 command. Thus the motor coasts down and it is not possible to stop in a controlled fashion.




NOTICE

- The OFF2 command can have one or several sources. The command sources are defined using BICO parameters P0844 (BI: 1. OFF2) and P0845 (BI: 2. OFF2).
- As a result of the pre-assignment (default setting), the OFF2 command is set to the BOP. This source is still available even if another command source is defined (e.g. terminal as command source → P0700 = 2 and OFF2 is selected using DI2 → P0702 = 3).
- OFF2 is active low.
- When simultaneously selecting the various OFF commands, the following priority applies: OFF2 (highest priority) – OFF3 – OFF1.

OFF3

The braking characteristics of OFF3 are identical with those of OFF1 with the exception of the independent OFF3 ramp-down time P1135. If the output frequency falls below parameter value P2167 and if the time in P2168 has expired, then the inverter pulses are cancelled as for the OFF1 command.



NOTICE

- OFF3 can be entered using a wide range of command sources via BICO parameters P0848 (BI: 1. OFF3) and P0849 (BI: 2. OFF3).
- OFF3 is active low.
- When simultaneously selecting the various OFF commands, the following priority applies: OFF2 (highest priority) – OFF3 – OFF1

5.6.2.2 Running the inverter in JOG mode


Functionality

The JOG function can be controlled by either the (built-in) BOP or the digital inputs. When controlled by the BOP, pressing the RUN button will cause the motor to start and rotate at the pre-set JOG frequency (P1058). The motor stops when the RUN button is released.

When using the digital inputs as the JOG command source, the JOG frequency is set by P1058 for JOG right and P1059 for JOG left.

The JOG function allows:

- to check the functionality of the motor and inverter after commissioning has been completed (first traversing motion, checking the direction of rotation, etc.)
- to bring a motor or a motor load into a specific position
- to traverse a motor, e.g. after a program has been interrupted



Setting parameters

| Parameter | Function | Setting |
|------------------|-------------------------|--|
| P1055[0..2] | BI: Enable JOG right | This parameter defines source of JOG right when P0719 = 0 (Auto selection of command / setpoint source). Factory default: 19.8 |
| P1056[0..2] | BI: Enable JOG left | This parameter defines source of JOG left when P0719 = 0 (Auto selection of command / setpoint source). Factory default: 0 |
| P1057 | JOG enable | = 1: Jogging is enabled (default) |
| P1058[0..2] | JOG frequency [Hz] | This parameter determines the frequency at which the inverter will run while jogging is active. Range: 0.00 ... 599.00 (factory default: 5.00) |
| P1059[0..2] | JOG frequency left [Hz] | This parameter determines the frequency at which the inverter will run while JOG left is selected. Range: 0.00 ... 599.00 (factory default: 5.00) |
| P1060[0..2] | JOG ramp-up time [s] | This parameter sets jog ramp-up time which is used while jogging is active. Range: 0.00 ... 650.00 (factory default: 10.00) |
| P1061[0..2] | JOG ramp-down time [s] | This parameter sets jog ramp-down time which is used while jogging is active. Range: 0.00 ... 650.00 (factory default: 10.00) |

5.6.2.3 Setting the voltage boost**Functionality**

For low output frequencies, the V/f characteristics only give a low output voltage. The ohmic resistances of the stator winding play a role at low frequencies, which are neglected when determining the motor flux in V/f control. This means that the output voltage can be too low in order to:

- implement the magnetization of the asynchronous motor
- hold the load
- overcome losses in the system.

The output voltage can be increased (boosted) in the inverter using the parameters as shown in the table below.

| Parameter | Boost type | Description |
|-----------|------------------------|--|
| P1310 | Continuous boost [%] | <p>This parameter defines boost level relative to P0305 (rated motor current) applicable to both linear and quadratic V/f curves.</p> <p>Range: 0.0 ... 250.0 (factory default: 50.0)</p> <p>The voltage boost is effective over the complete frequency range whereby the value continually decreases at high frequencies.</p> |
| P1311 | Acceleration boost [%] | <p>This parameter applies boost relative to P0305 (rated motor current) following a positive setpoint change and drops back out once the setpoint is reached.</p> <p>Range: 0.0 ... 250.0 (factory default: 0.0)</p> <p>The voltage boost is only effective when accelerating or braking.</p> |


5.6 Function commissioning

| Parameter | Boost type | Description |
|-----------|--------------------|--|
| P1312 | Starting boost [%] | <p>This parameter applies a constant linear offset relative to P0305 (rated motor current) to active V/f curve (either linear or quadratic) after an ON command and is active until:</p> <ul style="list-style-type: none"> • ramp output reaches setpoint for the first time respectively • setpoint is reduced to less than present ramp output <p>Range: 0.0 ... 250.0 (factory default: 0.0)</p> <p>The voltage boost is only effective when accelerating for the first time (standstill).</p> |

5.6.2.4 Setting the PID controller

Functionality

The integrated PID controller (technology controller) supports all kinds of simple process control tasks, e.g. controlling pressures, levels, or flowrates. The PID controller specifies the speed setpoint of the motor in such a way that the process variable to be controlled corresponds to its setpoint.



Setting parameters

| Parameter | Function | Setting |
|--------------------------|-------------------------------|---|
| Main function parameters | | |
| P2200[0...2] | BI: Enable PID controller | This parameter allows user to enable / disable the PID controller. Setting to 1 enables the PID closed-loop controller. Setting 1 automatically disables normal ramp times set in P1120 and P1121 and the normal frequency setpoints. Factory default: 0 |
| P2235[0...2] | BI: Enable PID-MOP (UP-cmd) | This parameter defines source of UP command. Possible sources: 19.13 (BOP), 722.x (Digital Input), 2036.13 (USS on RS485) |
| P2236[0...2] | BI: Enable PID-MOP (DOWN-cmd) | This parameter defines source of DOWN command. Possible sources: 19.14 (BOP), 722.x (Digital Input), 2036.14 (USS on RS485) |

Commissioning

5.6 Function commissioning

| Parameter | Function | Setting |
|-------------------------------------|---------------------------------------|--|
| Additional commissioning parameters | | |
| P2251 | PID mode | = 0: PID as setpoint (factory default) = 1: PID as trim source |
| P2253[0..2] | CI: PID setpoint | This parameter defines setpoint source for PID setpoint input. Possible sources: 755[0] (Analog input 1), 2018.1 (USS PZD 2), 2224 (Actual fixed PID setpoint), 2250 (Output setpoint of PID-MOP) |
| P2254[0..2] | CI: PID trim source | This parameter selects trim source for PID setpoint. Possible sources: 755[0] (Analog input 1), 2018.1 (USS PZD 2), 2224 (Actual fixed PID setpoint), 2250 (Output setpoint of PID-MOP) |
| P2255 | PID setpoint gain factor | Range: 0.00 ... 100.00 (factory default: 100.00) |
| P2256 | PID trim gain factor | Range: 0.00 ... 100.00 (factory default: 100.00) |
| P2257 | Ramp-up time for PID setpoint [s] | Range: 0.00 ... 650.00 (factory default: 1.00) |
| P2258 | Ramp-down time for PID setpoint [s] | Range: 0.00 ... 650.00 (factory default: 1.00) |
| P2263 | PID controller type | = 0: D component on feedback signal (factory default) = 1: D component on error signal |
| P2264[0..2] | CI: PID feedback | Possible sources: 755[0] (Analog input 1), 2224 (Actual fixed PID setpoint), 2250 (Output setpoint of PID-MOP) Factory default: 755[0] |
| P2265 | PID feedback filter time constant [s] | Range: 0.00 ... 60.00 (factory default: 0.00) |
| P2267 | Maximum value for PID feedback [%] | Range: -200.00 ... 200.00 (factory default: 100.00) |
| P2268 | Minimum value for PID feedback [%] | Range: -200.00 ... 200.00 (factory default: 0.00) |
| P2269 | Gain applied to PID feedback | Range: 0.00 ... 500.00 (factory default: 100.00) |
| P2270 | PID feedback function selector | = 0: Disabled (factory default) = 1: Square root (root(x)) = 2: Square (x*x) = 3: Cube (x*x*x) |
| P2271 | PID transducer type | = 0 : Disabled (factory default) = 1: Inversion of PID feedback signal |
| P2274 | PID derivative time [s] | Range: 0.000 ... 60.000 Factory default: 0.000 (the derivative time does not have any effect) |
| P2280 | PID proportional gain | Range: 0.000 ... 65.000 (factory default: 3.000) |
| P2285 | PID integral time [s] | Range: 0.000 ... 60.000 (factory default: 0.000) |
| P2291 | PID output upper limit [%] | Range: -200.00 ... 200.00 (factory default: 100.00) |
| P2292 | PID output lower limit [%] | Range: -200.00 ... 200.00 (factory default: 0.00) |
| P2293 | Ramp-up / -down time of PID limit [s] | Range: 0.00 ... 100.00 (factory default: 1.00) |
| P2295 | Gain applied to PID output | Range: -100.00 ... 100.00 (factory default: 100.00) |
| P2350 | PID autotune enable | = 0: PID autotuning disabled (factory default) = 1: PID autotuning via Ziegler Nichols (ZN) standard = 2: PID autotuning as 1 plus some overshoot (O/S) = 3: PID autotuning as 2 little or no overshoot (O/S) = 4: PID autotuning PI only, quarter damped response |
| P2354 | PID tuning timeout length [s] | Range: 60 ... 65000 (factory default: 240) |

| Parameter | Function | Setting |
|---------------|--|---|
| P2355 | PID tuning offset [%] | Range: 0.00 ... 20.00 (factory default: 5.00) |
| Output values | | |
| r2224 | CO: Actual fixed PID setpoint [%] | |
| r2225.0 | BO: PID fixed frequency status | |
| r2245 | CO: PID-MOP input frequency of the RFG [%] | |
| r2250 | CO: Output setpoint of PID-MOP [%] | |
| r2260 | CO: PID setpoint after PID-RFG [%] | |
| P2261 | PID setpoint filter time constant [s] | |
| r2262 | CO: Filtered PID setpoint after RFG [%] | |
| r2266 | CO: PID filtered feedback [%] | |
| r2272 | CO: PID scaled feedback [%] | |
| r2273 | CO: PID error [%] | |
| r2294 | CO: Actual PID output [%] | |

5.6.2.5 Setting the braking function

Functionality

The motor can be electrically or mechanically braked by the inverter via the following brakes:

- Electrical brakes
 - DC brake
 - Compound brake
 - Dynamic brake
- Mechanical brake
 - Motor holding brake

DC braking

DC braking causes the motor to stop rapidly by applying a DC braking current (current applied also holds shaft stationary). For DC braking, a DC current is impressed in the stator winding which results in a significant braking torque for an asynchronous motor.

DC braking is selected as follows:


- ① After OFF1 or OFF3 (the DC brake is released via P1233)
- ② Directly selected using BICO parameter P1230

Sequence 1

1. Enabled using P1233
2. DC braking is activated with the OFF1 or OFF3 command (see figure below)
3. The inverter frequency is ramped down along the parameterized OFF1 or OFF3 ramp down to the frequency at which DC braking is to start - P1234.
4. The inverter pulses are inhibited for the duration of the de-magnetizing time P0347.
5. The required braking current P1232 is then impressed for the selected braking time P1233. The status is displayed using signal r0053 bit 00.


5.6 Function commissioning

The inverter pulses are inhibited after the braking time has expired.



Sequence 2

- Enabled and selected using BICO parameter P1230 (see figure below).
- The inverter pulses are inhibited for the duration of the de-magnetizing time P0347.
- The requested braking current P1232 is impressed for the time selected and the motor is braked. This state is displayed using signal r0053 bit 00.
- After DC braking has been cancelled, the inverter accelerates back to the setpoint frequency until the motor speed matches the inverter output frequency.



Setting parameters

| Parameter | Function | Setting |
|--------------|---------------------------------|--|
| P1230[0...2] | Bl: Enable DC braking | This parameter enables DC braking via a signal applied from an external source. The function remains active while external input signal is active. Factory default: 0 |
| P1232[0...2] | DC braking current [%] | This parameter defines level of DC current relative to rated motor current (P0305). Range: 0 ... 250 (factory default: 100) |
| P1233[0...2] | Duration of DC braking [s] | This parameter defines duration for which DC braking is active following an OFF1 or OFF3 command. Range: 0.00 ... 250.00 (factory default: 0.00) |
| P1234[0...2] | DC braking start frequency [Hz] | This parameter sets the start frequency for DC braking. Range: 0.00 ... 599.00 (factory default: 599.00) |
| P0347[0...2] | Demagnetization time [s] | This parameter changes time allowed after OFF2 / fault condition, before pulses can be re-enabled. Range: 0.000 ... 20.000 (factory default: 1.000) |

NOTICE

The "DC braking" function is only practical for induction motors.

DC braking is not suitable to hold suspended loads.


For DC current braking, the motor kinetic energy is converted into thermal energy in the motor. If braking lasts too long, then the motor can overheat.

While DC braking, there is no other way of influencing the inverter speed using an external control. When parameterizing and setting the inverter system, then as far as possible, it should be tested using real loads.

5.6 Function commissioning

Compound braking

For compound braking (enabled using P1236), DC braking is superimposed with regenerative braking (where the inverter regenerates into the DC-link supply as it brakes along a ramp). Effective braking is obtained without having to use additional components by optimizing the ramp-down time (P1121 for OFF1 or when braking from f1 to f2, P1135 for OFF3) and using compound braking P1236.



Setting parameters

| Parameter | Function | Setting |
|--------------|----------------------------------|---|
| P1236[0...2] | Compound braking current [%] | This parameter defines DC level superimposed on AC waveform after exceeding DC-link voltage threshold of compound braking. The value is entered in [%] relative to rated motor current (P0305). Range: 0 ... 250 (factory default: 0) |
| P1254 | Auto detect Vdc switch-on levels | This parameter enables / disables auto-detection of switch-on levels for Vdc_max controller. = 0: Disabled = 1: Enabled (factory default) It is recommended to set P1254 = 1 (auto detection of Vdc switch-on levels enabled). Note that auto detection only works when the inverter has been in standby for over 20s. |

WARNING

For compound braking, regenerative braking is superimposed on the DC braking (braking along a ramp). This means that components of the kinetic energy of the motor and motor load are converted into thermal energy in the motor. This can cause the motor to overheat if this power loss is too high or if the brake operation takes too long!


NOTICE

The compound braking depends on the DC link voltage only (see threshold in the above diagram). This will happen on OFF1, OFF3 and any regenerative condition. Compound braking is deactivated, if:


- flying start is active
- DC braking is active.

Dynamic braking

Dynamic braking converts the regenerative energy, which is released when the motor decelerates, into heat. An internal braking chopper or an external dynamic braking module, which can control an external braking resistor, is required for dynamic braking. The inverter or the external dynamic braking module controls the dynamic braking depending on the DC link voltage. Contrary to DC and compound braking, this technique requires that an external braking resistor is installed.

Frame size A / B / C

For more information about the dynamic braking module, refer to the Appendix "Dynamic braking module (Page 257)".


Frame size D

5.6 Function commissioning

The continuous power P_{DB} and the duty cycle for the braking resistor can be modified using the dynamic braking module (for frame size A / B / C) or parameter P1237 (for frame size D).

⚠ WARNING

The average power of the braking chopper cannot exceed the power rating of the braking resistor.



| Duty cycle | t_{ON} (s) | t_{OFF} (s) | t_{cycle} (s) | P_{DB} |
|------------|--------------|---------------|-----------------|----------|
| 5% | 12.0 | 228.0 | 240.0 | 0.05 |
| 10% | 12.6 | 114.0 | 126.6 | 0.10 |
| 20% | 14.2 | 57.0 | 71.2 | 0.20 |
| 50% | 22.8 | 22.8 | 45.6 | 0.50 |
| 100% | Infinite | 0 | Infinite | 1.00 |

Setting parameters

| Parameter | Function | Setting |
|-------------|---------------------------------|---|
| P1237 | Dynamic braking | <p>This parameter defines the rated duty cycle of the braking resistor (chopper resistor). Dynamic braking is active when the function is enabled and DC-link voltage exceeds the dynamic braking switch-on level.</p> <p>= 0: Disabled (factory default) = 1: 5% duty cycle = 2: 10% duty cycle = 3: 20% duty cycle = 4: 50% duty cycle = 5: 100% duty cycle</p> <p>Note: This parameter is only applicable for inverters of frame size D. For frame sizes A to C, the duty cycle of the braking resistor can be selected with the dynamic braking module.</p> |
| P1240[0..2] | Configuration of Vdc controller | <p>This parameter enables / disables Vdc controller.</p> <p>= 0: Vdc controller disabled</p> <p>Note: This parameter must be set to 0 (Vdc controller disabled) to activate the dynamic braking.</p> |

| Parameter | Function | Setting |
|-----------|----------------------------------|--|
| P1254 | Auto detect Vdc switch-on levels | <p>This parameter enables / disables auto-detection of switch-on levels for Vdc_max controller.</p> <p>= 0: Disabled = 1: Enabled (factory default)</p> <p>It is recommended to set P1254 = 1 (auto detection of Vdc switch-on levels enabled). Note that auto detection only works when the inverter has been in standby for over 20s. When P1240 = 0, P1254 is only applicable for frame size D inverters.</p> |


⚠️ WARNING

Braking resistors, which are to be mounted on the inverter, must be designed so that they can tolerate the power dissipated. If an unsuitable braking resistor is used, there is a danger of fire and the associated inverter will be significantly damaged.

Motor holding brake


The motor holding brake prevents the motor from undesirable turning when the inverter is switched-off. The inverter has internal logic to control a motor holding brake.

ON / OFF1 / OFF3:



Commissioning

5.6 Function commissioning




Setting parameters

| Parameter | Function | Setting |
|-----------|----------------------------------|--|
| P1215 | Holding brake enable | This parameter enables / disables holding brake function. The motor holding brake (MHB) is controlled via status word 1 r0052 bit 12. = 0: Motor holding brake disabled (factory default) = 1: Motor holding brake enabled |
| P1216 | Holding brake release delay[s] | This parameter defines period during which inverter runs at minimum frequency P1080 before ramping up. Range: 0.0 ... 20.0 (factory default: 1.0) |
| P1217 | Holding time after ramp down [s] | This parameter defines time for which inverter runs at minimum frequency (P1080) after ramping down. Range: 0.0 ... 20.0 (factory default: 1.0) |

Connecting the motor holding brake

The motor holding brake can be connected to the inverter via digital outputs (DO 1 / DO 2). An additional relay is also required to allow the digital output to enable or disable the motor holding brake.



WARNING

If the inverter controls the motor holding brake, then a commissioning may not be carried out for potentially hazardous loads (e.g. suspended loads for crane applications) unless the load has been secured.

It is not permissible to use the motor holding brake as operating brake. The reason for this is that generally it is only designed for a limited number of emergency braking operations.


5.6.2.6 Setting the ramp time

Functionality

The ramp-function generator in the setpoint channel limits the speed of setpoint changes. This causes the motor to accelerate and decelerate more smoothly, thereby protecting the mechanical components of the driven machine.

Setting ramp-up / down time

The ramp-up and ramp-down times can be set independently of each other by P1120 and P1121.




Setting parameters

| Parameter | Function | Setting |
|-------------|------------------------|---|
| P1082[0..2] | Maximum frequency [Hz] | This parameter sets maximum motor frequency at which motor will run irrespective of the frequency setpoint. Range: 0.00 ... 599.00 (factory default: 50.00) |
| P1120[0..2] | Ramp-up time [s] | This parameter sets the time taken for motor to accelerate from standstill up to maximum motor frequency (P1082) when no rounding is used. Range: 0.00 ... 650.00 (factory default: 10.00) |
| P1121[0..2] | Ramp-down time [s] | This parameter sets the time taken for motor to decelerate from maximum motor frequency (P1082) down to standstill when no rounding is used. Range: 0.00 ... 650.00 (factory default: 10.00) |

Setting ramp-up / down rounding time

Rounding times are recommended, since they prevent an abrupt response, thus avoiding detrimental effects on the mechanics.

Rounding times are not recommended when analog inputs are used, since they would result in overshoot / undershoot in the inverter response.



$$t_{up} = \frac{1}{2} (P1130 + P1131) + \frac{f_2 - f_1}{P1082} \cdot P1120$$

$$t_{down} = \frac{1}{2} (P1132 + P1133) + \frac{f_2 - f_1}{P1082} \cdot P1121$$


Setting parameters

| Parameter | Function | Setting |
|-------------|-------------------------------------|--|
| P1130[0..2] | Ramp-up initial rounding time [s] | This parameter defines rounding time at start of ramp-up. Range: 0.00 ... 40.00 (factory default: 0.00) |
| P1131[0..2] | Ramp-up final rounding time [s] | This parameter defines rounding time at end of ramp-up. Range: 0.00 ... 40.00 (factory default: 0.00) |
| P1132[0..2] | Ramp-down initial rounding time [s] | This parameter defines rounding time at start of ramp-down. Range: 0.00 ... 40.00 (factory default: 0.00) |
| P1133[0..2] | Ramp-down final rounding time [s] | This parameter defines rounding time at end of ramp-down. Range: 0.00 ... 40.00 (factory default: 0.00) |

5.6.2.7 Setting the I_{max} controller

Functionality

If ramp-up time is too short, the inverter may display the alarm A501 which means the output current is too high. The I_{max} controller reduces inverter current if the output current exceeds the maximum output current limit (r0067). This is achieved by reducing the inverter's output frequency or output voltage.



Commissioning

5.6 Function commissioning

Setting parameters


You only have to change the factory default settings of the Imax controller if the inverter tends to oscillate when it reaches the current limit or it is shut down due to overcurrent.

| Parameter | Function | Setting |
|-------------|---|--|
| P0305[0..2] | Rated motor current [A] | This parameter defines the nominal motor current from rating plate. |
| P0640[0..2] | Motor overload factor [%] | This parameter defines motor overload current limit relative to P0305 (rated motor current). |
| P1340[0..2] | I _{max} controller proportional gain | This parameter defines the proportional gain of the I _{max} controller. Range: 0.000 ... 0.499 (factory default: 0.030) |
| P1341[0..2] | I _{max} controller integral time [s] | This parameter defines the integral time constant of the I _{max} controller. Setting P1341 to 0 disables the I _{max} controller. Range: 0.000 ... 50.000 (factory default: 0.300) |
| P1345[0..2] | I _{max} voltage controller proportional gain | This parameter sets the proportional gain of I _{max} voltage controller. If the output current (r0068) exceeds the maximum current (r0067), the inverter is dynamically controlled by reducing the output voltage. Range: 0.000 ... 5.499 (factory default: 0.250) |
| P1346[0..2] | I _{max} voltage controller integral time [s] | This parameter defines the integral time constant of the I _{max} voltage controller. Range: 0.000 ... 50.000 (factory default: 0.300) |
| r0056.13 | Status of motor control: I _{max} controller active | |

5.6.2.8 Setting the Vdc controller

Functionality

If ramp-down time is too short, the inverter may display the alarm A911 which means the DC link voltage is too high. The Vdc controller dynamically controls the DC link voltage to prevent overvoltage trips on high inertia systems.



Commissioning

5.6 Function commissioning

Setting parameters

| Parameter | Function | Setting |
|-------------|---------------------------------|--|
| P1240[0..2] | Configuration of Vdc controller | <p>This parameter enables / disables Vdc controller.</p> <p>= 0: Vdc controller disabled</p> <p>= 1: Vdc_max controller enabled (factory default)</p> <p>= 2: Kinetic buffering (Vdc_min controller) enabled</p> <p>= 3: Vdc_max controller and kinetic buffering (KIB) enabled</p> <p>Note: This parameter must be set to 0 (Vdc controller disabled) if a braking resistor is used.</p> |
| P0210 | Supply voltage [V] | <p>This parameter defines the supply voltage. Its default value depends upon the type of inverter.</p> <p>Range: 0 ... 1000</p> |

5.6.2.9 Setting the load torque monitoring function

Functionality

The load torque monitoring function allows the mechanical force transmission between the motor and driven load to be monitored. This function can detect whether the driven load is blocked or the force transmission has been interrupted.

The inverter monitors the load torque of the motor in different ways:

- Motor blocking detection
- Load missing detection
- Belt failure detection

Setting parameters

| Parameter | Function | Setting |
|-------------|--|--|
| P2177[0..2] | Delay time for motor is blocked [ms] | Defines the delay time for identifying that the motor is blocked. Range: 0 ... 10000 (factory default: 10) |
| P2179 | Current limit for no load identified [%] | This parameter defines the threshold current for A922 (load missing) relative to P0305 (rated motor current). Range: 0.0 ... 10.0 (factory default: 3.0) |
| P2180 | Delay time for load missing [ms] | Defines the delay time for identifying that the load is missing. Range: 0 ... 10000 (factory default: 2000) |
| P2181[0..2] | Belt failure detection mode | <p>The belt failure detection is achieved by comparing the actual frequency / torque curve with a programmed envelope (defined by parameters P2182 ... P2190). If the curve falls outside the envelope, a warning or trip is generated.</p> <p>= 0: Belt failure detection disabled (factory default)</p> <p>= 1: Warning: Low torque / frequency</p> <p>= 2: Warning: High torque / frequency</p> <p>= 3: Warning: High / low torque / frequency</p> <p>= 4: Trip: Low torque / frequency</p> <p>= 5: Trip: High torque / frequency</p> <p>= 6: Trip: High / low torque / frequency</p> |

| Parameter | Function | Setting |
|--------------|---------------------------------|--|
| P2182[0...2] | Belt threshold frequency 1 [Hz] | Range: 0.00 ... 599.00 (factory default: 5.00) |
| P2183[0...2] | Belt threshold frequency 2 [Hz] | Range: 0.00 ... 599.00 (factory default: 30.00) |
| P2184[0...2] | Belt threshold frequency 3 [Hz] | Range: 0.00 ... 599.00 (factory default: 30.00) |
| P2185[0...2] | Upper torque threshold 1 [Nm] | Range: 0.0 ... 99999.0 (factory default: value in r0333) |
| P2186[0...2] | Lower torque threshold 1 [Nm] | Range: 0.0 ... 99999.0 (factory default: 0.0) |
| P2187[0...2] | Upper torque threshold 2 [Nm] | Range: 0.0 ... 99999.0 (factory default: value in r0333) |
| P2188[0...2] | Lower torque threshold 2 [Nm] | Range: 0.0 ... 99999.0 (factory default: 0.0) |
| P2189[0...2] | Upper torque threshold 3 [Nm] | Range: 0.0 ... 99999.0 (factory default: value in r0333) |
| P2190[0...2] | Lower torque threshold 3 [Nm] | Range: 0.0 ... 99999.0 (factory default: 0.0) |
| P2192[0...2] | Time delay for belt failure [s] | Range: 0 ... 65 (factory default: 10) |

5.6.3 Commissioning advanced functions

5.6.3.1 Starting the motor in super torque mode

Functionality

This startup mode applies a torque pulse for a given time to help start the motor.

Typical application field

Sticky pumps

Setting parameters

| Parameter | Function | Setting |
|--------------|---------------------------|--|
| P3350[0...2] | Super torque mode | = 1: Enable super torque mode Note: When the value of P3350 is changed, the value of P3353 is changed as follows: <ul style="list-style-type: none">• P3350 = 2: P3353 = 0.0s• P3350 ≠ 2: P3353 = default The ramp time of 0s gives an additional 'kicking' effect when hammer start is in use. |
| P3351[0...2] | BI: Super torque enable | This parameter defines the source of the super torque enable. The setting is effective when P3352 = 2. Factory default: 0 (never enabled) |
| P3352[0...2] | Super torque startup mode | This parameter defines when the super torque function becomes active. = 0: Enabled on first run after power-up = 1: Enabled on every run = 2: Enabled by digital input (enable source is defined by P3351; 0 = never enabled, 1 = enabled on every run) |

5.6 Function commissioning


| Parameter | Function | Setting |
|-------------|------------------------------|--|
| P3353[0..2] | Super torque ramp time [s] | This parameter defines the ramp time to be used when ramping up to the super torque frequency. Range: 0.0 ... 650.0 (factory default: 5.0) |
| P3354[0..2] | Super torque frequency [Hz] | This parameter defines the frequency at which the additional boost is applied for super torque mode. Range: 0.0 ... 599.0 (factory default: 5.0) |
| P3355[0..2] | Super torque boost level [%] | This parameter sets the temporary boost level for super torque mode. It applies boost in [%] relative to P0305 (rated motor current) once the super torque frequency has been reached for the time specified in P3356. Range: 0.0 ... 200.0 (factory default: 150.0) |
| P3356[0..2] | Super torque boost time [s] | This parameter sets the time for which the additional boost is applied, when the output frequency is held at P3354. Range: 0.0 ... 20.0 (factory default: 5.0) |

Function diagram

Description:

The Super Torque mode is enabled when an ON command is issued, and the following sequence is performed:

- Ramps up to P3354 Hz with the boost level specified by P1310, P1311, and P1312
- Maintains for P3356 s with the boost level specified by P3355
- Reverts boost level to that specified by P1310, P1311, and P1312
- Reverts to "normal" setpoint and allows output to ramp using P1120



5.6.3.2 Starting the motor in hammer start mode

Functionality

This startup mode applies a sequence of torque pulses to start the motor.

Typical application field

Very sticky pumps

Setting parameters

| Parameter | Function | Setting |
|--------------|------------------------------|--|
| P3350[0...2] | Super torque mode | = 2: Enable hammer start mode Note: When the value of P3350 is changed, the value of P3353 is changed as follows: <ul style="list-style-type: none">• P3350 = 2: P3353 = 0.0s• P3350 ≠ 2: P3353 = default The ramp time of 0s gives an additional 'kicking' effect when hammer start is in use. |
| P3351[0...2] | BI: Super torque enable | This parameter defines the source of the super torque enable. The setting is effective when P3352 = 2. Factory default: 0 (never enabled) |
| P3352[0...2] | Super torque startup mode | This parameter defines when the super torque function becomes active. = 0: Enabled on first run after power-up = 1: Enabled on every run = 2: Enabled by digital input (enable source is defined by P3351; 0 = never enabled, 1 = enabled on every run) |
| P3353[0...2] | Super torque ramp time [s] | This parameter defines the ramp time to be used when ramping up to the super torque frequency. Range: 0.0 ... 650.0 (factory default: 5.0) |
| P3354[0...2] | Super torque frequency [Hz] | This parameter defines the frequency at which the additional boost is applied for super torque mode. Range: 0.0 ... 599.0 (factory default: 5.0) |
| P3357[0...2] | Hammer start boost level [%] | This parameter sets the temporary boost level for hammer start mode. It applies boost in [%] relative to P0305 (rated motor current) once the super torque frequency has been reached for the time specified in P3356. Range: 0.0 ... 200.0 (factory default: 150.0) |
| P3358[0...2] | Number of hammer cycles | This parameter defines the number of times the hammer start boost level is applied. Range: 1 - 10 (factory default: 5) |

5.6 Function commissioning


| Parameter | Function | Setting |
|--------------|----------------------|---|
| P3359[0...2] | Hammer on time [ms] | This parameter sets the time for which the additional boost is applied for each repetition (must be at least 3 x motor magnetization time). Range: 0 ... 1000 (factory default: 300) |
| P3360[0...2] | Hammer off Time [ms] | This parameter sets the time for which the additional boost is removed for each repetition (must be at least 3 x motor magnetization time). Range: 0 ... 1000 (factory default: 100) |

Function diagram

Description:

The hammer start mode is enabled when an ON command is issued, and the following sequence is performed:

- Ramp up to P3354 Hz with the boost level specified by P1310, P1311, and P1312
- Revert boost level to that specified by P1310, P1311, and P1312
- Revert to "normal" setpoint and allow output to ramp using P1120



5.6.3.3 Starting the motor in blockage clearing mode

Functionality

This startup mode momentarily reverses the motor rotation to clear a pump blockage.

Typical application field

Pump clearing

Setting parameters

| Parameter | Function | Setting |
|--------------|------------------------------------|---|
| P3350[0...2] | Super torque mode | = 3: Enable blockage clearing mode Note: When the value of P3350 is changed, the value of P3353 is changed as follows: <ul style="list-style-type: none">• P3350 = 2: P3353 = 0.0s• P3350 ≠ 2: P3353 = default The ramp time of 0s gives an additional 'kicking' effect when hammer start is in use. If blockage clearing mode is enabled (P3350 = 3), make sure that reverse direction is not inhibited, i.e. P1032 = P1110 = 0. |
| P3351[0...2] | BI: Super torque enable | This parameter defines the source of the super torque enable. The setting is effective when P3352 = 2. Factory default: 0 (never enabled) |
| P3352[0...2] | Super torque startup mode | This parameter defines when the super torque function becomes active. = 0: Enabled on first run after power-up = 1: Enabled on every run = 2: Enabled by digital input (enable source is defined by P3351; 0 = never enabled, 1 = enabled on every run) |
| P3353[0...2] | Super torque ramp time [s] | This parameter defines the ramp time to be used when ramping up to the super torque frequency. Range: 0.0 ... 650.0 (factory default: 5.0) |
| P3361[0...2] | Blockage clearing frequency [Hz] | This parameter defines the frequency at which the inverter runs in the opposite direction to the setpoint during the blockage clearing reverse sequence. Range: 0.0 ... 599.0 (factory default: 5.0) |
| P3362[0...2] | Blockage clearing reverse time [s] | This parameter sets the time for which the inverter runs in the opposite direction to the setpoint during the reverse sequence. Range: 0.0 ... 20.0 (factory default: 5.0) |

5.6 Function commissioning


| Parameter | Function | Setting |
|--------------|------------------------------------|--|
| P3363[0...2] | Enable rapid ramp | This parameter selects whether the inverter ramps to, or starts directly from, the blockage clearing frequency = 0: Disable rapid ramp for blockage clearing (use ramp time specified in P3353) = 1: Enable rapid ramp for blockage clearing (jump to the reverse frequency - this introduces a "kicking" effect which helps to clear the blockage) Range: 0 ... 1 (factory default: 0) |
| P3364[0...2] | Number of blockage clearing cycles | This parameter sets the number of times the blockage clearing reversing cycle is repeated. Range: 1 ... 10 (factory default: 1) |

Function diagram

Description:

The blockage clearing mode is enabled when an ON command is issued, and the following sequence is performed:

- Ramp or step (depending on P3363) to P3361 Hz in opposite direction to the setpoint
- For P3364 repetitions:
 - Ramp down to 0 Hz using normal ramp time as specified in P1121
 - Ramp or step (depending on P3363) to P3361 Hz in opposite direction to the setpoint
- Revert to "normal" setpoint and allow output to ramp using P1120.



5.6.3.4 Running the inverter in economy mode

Functionality

Economy mode works by slightly changing the output voltage either up or down in order to find the minimum input power.

NOTICE

The economy mode optimization is only active when operating at the requested frequency setpoint. The optimization algorithm becomes active 5 seconds after the setpoint has been reached, and is disabled on a setpoint change or if the I_{max} or V_{max} controller is active.


Typical applications

Motors with stable or slowly changing loads

Setting parameters

| Parameter | Function | Setting |
|--------------|-------------------------|--|
| P1300[0...2] | Control mode | = 4: V/f Eco Mode with linear characteristic = 7: V/f Eco Mode with quadratic characteristic |
| r1348 | Economy mode factor [%] | This parameter displays the calculated economy mode factor (range 80%-120%) applied to the demanded output voltage. If this value is too low, the system may become unstable. |

Function diagram



5.6.3.5 Setting the UL508C-compliant motor overtemperature protection**Functionality**

The function protects the motor from overtemperature. The function defines the reaction of the inverter when motor temperature reaches warning threshold. The inverter can remember the current motor temperature on power-down and reacts on the next power-up based on the setting in P0610. Setting any value in P0610 other than 0 will cause the inverter to trip (F11) if the motor temperature is 10% above the warning threshold P0604.

Setting parameters


| Parameter | Function | Setting |
|--------------|-----------------------------------|---|
| P0610[0...2] | Motor I^2t temperature reaction | <p>This parameter defines reaction when motor temperature reaches warning threshold.</p> <p>Settings 0 to 2 do not recall the motors temperature (stored at power-down) on power-up:</p> <ul style="list-style-type: none">= 0: Warning only= 1: Warning with Imax control (motor current reduced) and trip (F11)= 2: Warning and trip (F11) <p>Settings 4 to 6 recall the motors temperature (stored at power-down) on power-up:</p> <ul style="list-style-type: none">= 4: Warning only= 5: Warning with Imax control (motor current reduced) and trip (F11)= 6: Warning and trip (F11) |

5.6.3.6 Setting the free function blocks (FFBs)

Functionality

Additional signal interconnections in the inverter can be established by means of free function blocks (FFBs). Every digital and analog signal available via BICO technology can be routed to the appropriate inputs of the free function blocks. The outputs of the free function blocks are also interconnected to other functions using BICO technology.

Example



Setting parameters

| Parameter | Function | Setting | |
|-----------|----------------------------------|--|--|
| P0702 | Function of digital input 2 | = 99: Enable BICO parameterization for digital input 2 | |
| P0703 | Function of digital input 3 | = 99: Enable BICO parameterization for digital input 3 | |
| P2800 | Enable FFBs | = 1: Enable (general enable for all free function blocks) | |
| P2810[0] | Activate FFBs | = 1: Enable AND 1 | |
| P2810[0] | BI: AND 1 | = 722.1 | P2810[0] and P2810[1] define inputs of AND 1 element, and output is r2811.0. |
| P2810[1] | | = 722.2 | |
| P0731 | BI: Function of digital output 1 | This parameter defines source of digital output 1. = r2811.0: Use the AND (DI2, DI3) to switch on LED | |


For more information about FFBs and additional settings of individual parameter, see Chapter "Parameter list (Page 117)".

5.6.3.7 Setting the flying start function

Functionality

The flying start function (enabled using P1200) allows the inverter to be switched onto a motor which is still spinning by rapidly changing the output frequency of the inverter until the actual motor speed has been found. Then, the motor runs up to setpoint using the normal ramp time.

Flying start must be used in cases where the motor may still be turning (e.g. after a short mains break) or can be driven by the load. Otherwise, overcurrent trips will occur.



Setting parameters

| Parameter | Function | Setting |
|-------------|---------------------------------|---|
| P1200 | Flying start | Settings 1 to 3 search in both directions: = 0: Flying start disabled = 1: Flying start always active = 2: Flying start active after power on, fault, OFF2 = 3: Flying start active after fault, OFF2 Settings 4 to 6 search only in the direction of the setpoint: = 4: Flying start always active = 5: Flying start active after power on, fault, OFF2 = 6: Flying start active after fault, OFF2 |
| P1202[0..2] | Motor-current: flying start [%] | This parameter defines search current used for flying start. Range: 10 ... 200 (factory default: 100) Note: Search current settings in P1202 that are below 30% (and sometimes other settings in P1202 and P1203) may cause motor speed to be found prematurely or too late, which can result in F1 or F2 trips. |
| P1203[0..2] | Search rate: flying start [%] | This parameter sets factor (in V/f mode only) by which the output frequency changes during flying start to synchronize with turning motor. Range: 10 ... 500 (factory default: 100) Note: A higher value produces a flatter gradient and thus a longer search time. A lower value has the opposite effect. |

5.6.3.8 Setting the automatic restart function

Functionality

After a power failure (F3 "Undervoltage"), the automatic restart function (enabled using P1210) automatically switches on the motor if an ON command is active. Any faults are automatically acknowledged by the inverter.

When it comes to power failures (line supply failure), then a differentiation is made between the following conditions:

- "Line undervoltage (mains brownout)" is a situation where the line supply is interrupted and returns before the built-in BOP display has gone dark (this is an extremely short line supply interruption where the DC link hasn't completely collapsed).
- "Line failure (mains blackout)" is a situation where the built-in BOP display has gone dark (this represents a longer line supply interruption where the DC link has completely collapsed) before the line supply returns.


Setting parameters

| Parameter | Function | Setting |
|-----------|----------------------------|--|
| P1210 | Automatic restart | <p>This parameter configures automatic restart function.</p> <p>= 0: Disabled = 1: Trip reset after power on, P1211 disabled = 2: Restart after mains blackout, P1211 disabled = 3: Restart after mains brownout or fault, P1211 enabled = 4: Restart after mains brownout, P1211 enabled = 5: Restart after mains blackout and fault, P1211 disabled = 6: Restart after mains brown / blackout or fault, P1211 enabled = 7: Restart after mains brown / blackout or fault, trip when P1211 expires</p> |
| P1211 | Number of restart attempts | <p>This parameter specifies number of times inverter will attempt to restart if automatic restart P1210 is activated.</p> <p>Range: 0 ... 10 (factory default: 3)</p> |

5.6.3.9 Running the inverter in frost protection mode

Functionality

If the ambient temperature falls below a given threshold, motor turns automatically to prevent freezing.



- OFF1 / OFF3: The frost protection function is disabled when OFF3 is activated and enabled again when OFF1 is activated.
- OFF2 / fault: The motor stops and the frost protection is deactivated.


Setting parameters

| Parameter | Function | Setting |
|-------------|---------------------------------|--|
| P3852[0..2] | Bl: Enable frost protection | <p>This parameter defines command source of protection enable command. If binary input is equal to one, then protection will be initiated (factory default: 0).</p> <p>If $P3853 \neq 0$, frost protection is applied by applying the given frequency to the motor.</p> <p>Note that the protection function may be overridden under the following circumstances:</p> <ul style="list-style-type: none"> • If inverter is running and protection signal becomes active, signal is ignored • If inverter is turning motor due to active protection signal and a RUN command is received, RUN command overrides frost signal • Issuing an OFF command while protection is active will stop the motor |
| P3853[0..2] | Frost protection frequency [Hz] | <p>This parameter specifies the frequency applied to the motor when frost protection is active.</p> <p>Range: 0.00 ... 599.00 (factory default: 5.00)</p> |

5.6.3.10 Running the inverter in condensation protection mode

Functionality

If an external condensation sensor detects excessive condensation, the inverter applies a DC current to keep the motor warm to prevent condensation.



- OFF1 / OFF3: The condensation protection function is disabled when OFF3 is activated and enabled again when OFF1 is activated.
- OFF2 / fault: The motor stops and the condensation protection is deactivated.

Setting parameters


| Parameter | Function | Setting |
|--------------|-------------------------------------|--|
| P3852[0...2] | BI: Enable frost protection | <p>This parameter defines command source of protection enable command. If binary input is equal to one, then protection will be initiated (factory default: 0).</p> <p>If P3853 = 0, and P3854 ≠ 0, condensation protection is applied by applying the given current to the motor.</p> <p>Note that the protection function may be overridden under the following circumstances:</p> <ul style="list-style-type: none"> • If inverter is running and protection signal becomes active, signal is ignored • If inverter is turning motor due to active protection signal and a RUN command is received, RUN command overrides frost signal • Issuing an OFF command while protection is active will stop the motor |
| P3854[0...2] | Condensation protection current [%] | <p>This parameter specifies the DC current (as a percentage of nominal current) which is applied to the motor when condensation protection is active.</p> <p>Range: 0 ... 250 (factory default: 100)</p> |

5.6.3.11 Running the inverter in sleep mode

Functionality

The motor is turned off if demand falls below threshold, and turned on if demand rises above threshold.

Required response of simple hibernation (sleep mode)




Setting parameters

| Parameter | Function | Setting |
|-------------|---------------------------------|---|
| P2365[0..2] | Hibernation enable / disable | This parameter enables or disables the hibernation functionality. = 0: Disabled (factory default) = 1: Enabled |
| P2366[0..2] | Delay before stopping motor [s] | With hibernation enabled, this parameter defines the delay before the inverter goes into sleep mode. Range: 0 ... 254 (factory default: 5) |
| P2367[0..2] | Delay before starting motor [s] | With hibernation enabled, this parameter defines the delay before the inverter comes out of sleep mode. Range: 0 ... 254 (factory default: 2) |
| P1080[0..2] | Minimum frequency [Hz] | Sets minimum motor frequency at which motor will run irrespective of frequency setpoint. Value set here is valid both for clockwise and for anticlockwise rotation. Range: 0.00 ... 599.00 (factory default: 0.00) |

5.6.3.12 Setting the wobble generator

Functionality

The wobble generator executes predefined periodical disruptions superimposed on the main setpoint for technological usage in the fiber industry. The wobble function can be activated via P2940. It is independent of the setpoint direction, thus only the absolute value of the setpoint is relevant. The wobble signal is added to the main setpoint as an additional setpoint. During the change of the setpoint the wobble function is inactive. The wobble signal is also limited by the maximum frequency (P1082).



Setting parameters

| Parameter | Function | Setting |
|-----------|------------------------------|--|
| P2940 | Bl: Release wobble function | This parameter defines the source to release the wobble function. Factory default: 0.0 |
| P2945 | Wobble signal frequency [Hz] | This parameter sets the frequency of the wobble signal. Range: 0.001 ... 10.000 (factory default: 1.000) |
| P2946 | Wobble signal amplitude [%] | This parameter sets the value for the amplitude of the wobble-signal as a proportion of the present ramp function generator (RFG) output. Range: 0.000 ... 0.200 (factory default: 0.000) |

Commissioning

5.6 Function commissioning


| Parameter | Function | Setting |
|-----------|-------------------------------|---|
| P2947 | Wobble signal decrement step | This parameter sets the value for decrement step at the end of the positive signal period. Range: 0.000 ... 1.000 (factory default: 0.000) |
| P2948 | Wobble signal increment step | This parameter sets the value for the increment step at the end of the negative signal period. Range: 0.000 ... 1.000 (factory default: 0.000) |
| P2949 | Wobble signal pulse width [%] | This parameter sets the relative widths of the rising and falling pulses. Range: 0 ... 100 (factory default: 50) |

5.6.3.13 Running the inverter in motor staging mode


Functionality

Motor staging allows the control of up to 2 additional staged pumps or fans, based on a PID control system. The complete system consists of one pump controlled by the inverter and up to 2 further pumps / fans controlled from contactors or motor starters. The contactors or motor starter are controlled by digital outputs from the inverter.

The diagram below shows a typical pumping system.



Staging:




Condition for staging:

- ④ $f_{act} \geq P1082$
- ⑤ $\Delta_{PID} \geq P2373$
- ⑥ $t_{④⑤} > P2374$

$$t_y = \left(1 - \frac{P2378}{100}\right) \cdot P1121$$

Destaging:



Condition for destaging:

- ④ $f_{act} \leq P1080$
- ⑤ $\Delta_{PID} \leq -P2373$
- ⑥ $t_{④⑤} > P2375$

$$t_x = \left(\frac{P2378}{100} - \frac{P1080}{P1082}\right) \cdot P1120$$

Commissioning

5.6 Function commissioning


Setting parameters

| Parameter | Function | Setting |
|-------------|------------------------------------|---|
| P2370[0..2] | Motor staging stop mode | This parameter selects stop mode for external motors when motor staging is in use. = 0: Normal stop (factory default) = 1: Sequence stop |
| P2371[0..2] | Motor staging configuration | This parameter selects configuration of external motors (M1, M2) used for motor staging feature. = 0: Motor staging disabled = 1: M1 = 1 x MV, M2 = Not fitted = 2: M1 = 1 x MV, M2 = 1 x MV = 3: M1 = 1 x MV, M2 = 2 x MV |
| P2372[0..2] | Motor staging cycling | This parameter enables motor cycling for the motor staging feature. = 0: Disabled (factory default) = 1: Enabled |
| P2373[0..2] | Motor staging hysteresis [%] | P2373 as a percentage of PID setpoint that PID error P2273 must be exceeded before staging delay starts. Range: 0.0 ... 200.0 (factory default: 20.0) |
| P2374[0..2] | Motor staging delay [s] | This parameter defines the time that PID error P2273 must exceed motor staging hysteresis P2373 before staging occurs. Range: 0 ... 650 (factory default: 30) |
| P2375[0..2] | Motor destaging delay [s] | This parameter defines the time that PID error P2273 must exceed motor staging hysteresis P2373 before destaging occurs. Range: 0 ... 650 (factory default: 30) |
| P2376[0..2] | Motor staging delay override [%] | P2376 as a percentage of PID setpoint. When the PID error P2273 exceeds this value, a motor is staged / destaged irrespective of the delay timers. Range: 0.0 ... 200.0 (factory default: 25.0) Note: The value of this parameter must always be larger than staging hysteresis P2373. |
| P2377[0..2] | Motor staging lockout timer [s] | This parameter defines the time for which delay override is prevented after a motor has been staged or destaged. Range: 0 ... 650 (factory default: 30) |
| P2378[0..2] | Motor staging frequency f_st [%] | This parameter sets the frequency at which the digital output (DO) is switched during a (de) staging event, as the inverter ramps from maximum to minimum frequency (or vice versa). Range: 0.0 ... 120.0 (factory default: 50.0) |
| r2379.0...1 | CO / BO: Motor staging status word | This parameter displays output word from the motor staging feature that allows external connections to be made. Bit 00: Start motor 1 (yes for 1, no for 0) Bit 01: Start motor 2 (yes for 1, no for 0) |
| P2380[0..2] | Motor staging hours run [h] | This parameter displays hours run for external motors. Index: [0]: Motor 1 hrs run [1]: Motor 2 hrs run [2]: Not used Range: 0.0 ... 4294967295 (factory default: 0.0) |

5.6.3.14 Running the inverter in cavitation protection mode

Functionality

The cavitation protection will generate a fault / warning when cavitation conditions are deemed to be present. If the inverter gets no feedback from the pump transducer, it will trip to stop cavitation damage.



Cavitation Protection Logic Diagram

Setting parameters

| Parameter | Function | Setting |
|--------------|--------------------------------|--|
| P2360[0...2] | Enable cavitation protection | This parameter enables the cavitation protection function. = 1: Fault = 2: Warn |
| P2361[0...2] | Cavitation threshold [%] | This parameter defines the feedback threshold over which a fault / warning is triggered, as a percentage (%). Range: 0.00 ... 200.00 (factory default: 40.00) |
| P2362[0...2] | Cavitation protection time [s] | This parameter sets the time for which cavitation conditions have to be present before a fault / warning is triggered. Range: 0 ... 65000 (factory default: 30) |

5.6.3.15 Setting the user default parameter set

Functionality

The user default parameter set allows a modified set of defaults, different to the factory defaults, to be stored. Following a parameter reset these modified default values would be used. An additional factory reset mode would be required to erase the user defaults and restore the inverter to factory default parameter set.

Creating the user default parameter set

1. Parameterize the inverter as required.
2. Set P0971 = 21, and the current inverter state is now stored as the user default.

Modifying the user default parameter set

1. Return the inverter to the default state by setting P0010 = 30 and P0970 = 1. The inverter is now in the user default state if configured, else factory default state.
2. Parameterize the inverter as required.
3. Set P0971 = 21 to store current state as the user default.

Setting parameters

| Parameter | Function | Setting |
|-----------|----------------------------------|---|
| P0010 | Commissioning parameter | This parameter filters parameters so that only those related to a particular functional group are selected. It must be set to 30 in order to store or delete user defaults. = 30: Factory setting |
| P0970 | Factory reset | This parameter resets all parameters to their user default / factory default values. = 1: Parameter reset to user defaults if stored else factory defaults = 21: Parameter reset to factory defaults deleting user defaults if stored |
| P0971 | Transfer data from RAM to EEPROM | This parameter transfers values from RAM to EEPROM. = 1: Start transfer = 21: Start transfer and store parameter changes as user default values |

For information about restoring the inverter to factory defaults, refer to Section "Restoring to defaults (Page 104)".

5.6.3.16 Setting the dual ramp function

Functionality


The dual ramp function allows the user to parameterize the inverter so that it can switch from one ramp rate to another when ramping up or down to a setpoint. This may be useful for delicate loads, where starting to ramp with a fast ramp-up or ramp-down time may cause damage. The function works as follows:

Ramp up:

- Inverter starts ramp-up using ramp time from P1120
- When $f_{act} > P2157$, switch to ramp time from P1060

Ramp down:

- Inverter starts ramp-down using ramp time from P1061
- When $f_{act} < P2159$, switch to ramp time from P1121



Note that the dual ramp algorithm uses r2198 bits 1 and 2 to determine ($f_{act} > P2157$) and ($f_{act} < P2159$).

5.7 Restoring to defaults**Setting parameters**

| Parameter | Function | Setting |
|-------------|------------------------------|---|
| P1175[0..2] | BI: Dual ramp enable | This parameter defines command source of dual ramp enable command. If binary input is equal to one, then the dual ramp will be applied. The factory default value is 0. |
| P1060[0..2] | JOG ramp-up time [s] | This parameter sets the JOG ramp-up time. Range: 0.00 ... 650.00 (factory default: 10.00) |
| P1061[0..2] | JOG ramp-down time [s] | This parameter sets the JOG ramp-down time. Range: 0.00 ... 650.00 (factory default: 10.00) |
| P1120[0..2] | Ramp-up time [s] | This parameter sets the time taken for motor to accelerate from standstill up to maximum frequency (P1082) when no rounding is used. Range: 0.00 ... 650.00 (factory default: 10.00) |
| P1121[0..2] | Ramp-down time [s] | This parameter sets the time taken for motor to decelerate from maximum frequency (P1082) down to standstill when no rounding is used. Range: 0.00 ... 650.00 (factory default: 10.00) |
| P2157[0..2] | Threshold frequency f_2 [Hz] | This parameter defines threshold_2 for comparing speed or frequency to thresholds. Range: 0.00 ... 599.00 (factory default: 30.00) |
| P2159[0..2] | Threshold frequency f_3 [Hz] | This parameter defines threshold_3 for comparing speed or frequency to thresholds. Range: 0.00 ... 599.00 (factory default: 30.00) |

5.7 Restoring to defaults**Restoring to factory defaults**

| Parameter | Function | Setting |
|-----------|-------------------------|--|
| P0003 | User access level | = 1 (standard user access level) |
| P0010 | Commissioning parameter | = 30 (factory setting) |
| P0970 | Factory reset | = 21: parameter reset to factory defaults deleting user defaults if stored |

Restoring to user defaults

| Parameter | Function | Setting |
|-----------|-------------------------|--|
| P0003 | User access level | = 1 (standard user access level) |
| P0010 | Commissioning parameter | = 30 (factory setting) |
| P0970 | Factory reset | = 1: parameter reset to user defaults if stored, else factory defaults |


After the setting for P0970, the inverter displays "8 8 8 8 8" and then the screen shows "P0970". P0970 and P0010 are automatically reset to their original value 0.

6

Communicating with the PLC

The SINAMICS V20 supports communication with Siemens PLCs over USS on RS485. You can parameterize whether the RS485 interface shall apply USS or MODBUS RTU protocol. USS is the default bus setting. A screened twisted pair cable is recommended for the RS485 communication.

Make sure that you terminate the bus correctly by fitting a 120 R bus termination resistor between the bus terminals (P+, N-) of the device at one end of the bus and a termination network between the bus terminals of the device at the other end of the bus. The termination network should be a 1.5 k resistor from 10 V to P+, 120 R from P+ to N- and 470 R from N- to 0 V. A suitable termination network is available from your Siemens dealer.




6.1 USS communication

Overview


One PLC (master) can connect a maximum of 31 inverters (slaves) through the serial link and control them with the USS serial bus protocol. A slave can never transmit without first being initiated by the master so that direct information transfer between individual slaves is not possible.

Data exchanging:



6.1 USS communication

The messages are always sent in the following format (half-duplex communication):



- Response delay time: 20 ms
- Start delay time: depends on baud rate (minimum operation time for 2-character string: 0.12 ... 2.3 ms)
- Message transfer sequence:
 - master polls slave 1, then slave 1 responds
 - master polls slave 2, then slave 2 responds
- Fixed framing characters that can not be altered:
 - 8 data bits
 - 1 parity-even bit
 - 1 stop bit

| Abbreviation | Significance | Size | Explanation |
|--------------|-----------------------|------------------|---|
| STX | Start of text | ASCII characters | 02 hex |
| LGE | Telegram length | 1 byte | Contains the telegram length |
| ADR | Address | 1 byte | Contains the slave address and the telegram type (binary coded) |
| 1. n. | Net characters | Each 1 byte | Net data, contents are dependent on the request |
| BCC | Block check character | 1 byte | Data security characters |

Request and response IDs

Request and response IDs are written in bits 12 to 15 of the PKW (parameter ID value) part of USS telegram.

Request IDs (master → slave)

| Request ID | Description | Response ID | |
|------------|--------------------------------------|-------------|----------|
| | | positive | negative |
| 0 | No request | 0 | 7 / 8 |
| 1 | Request parameter value | 1 / 2 | 7 / 8 |
| 2 | Modify parameter value (word) | 1 | 7 / 8 |
| 3 | Modify parameter value (double word) | 2 | 7 / 8 |
| 4 | Request descriptive element | 3 | 7 / 8 |
| 6 | Request parameter value (array) | 4 / 5 | 7 / 8 |

| Request ID | Description | Response ID | |
|------------|---|-------------|----------|
| | | positive | negative |
| 7 | Modify parameter value (array, word) | 4 | 7 / 8 |
| 8 | Modify parameter value (array, double word) | 5 | 7 / 8 |
| 9 | Request number of array elements | 6 | 7 / 8 |
| 11 | Modify parameter value (array, double word) and store in EEPROM | 5 | 7 / 8 |
| 12 | Modify parameter value (array, word) and store in EEPROM | 4 | 7 / 8 |
| 13 | Modify parameter value (double word) and store in EEPROM | 2 | 7 / 8 |
| 14 | Modify parameter value (word) and store in EEPROM | 1 | 7 / 8 |

Response IDs (slave → master)

| Response ID | Description |
|-------------|--|
| 0 | No response |
| 1 | Transfer parameter value (word) |
| 2 | Transfer parameter value (double word) |
| 3 | Transfer descriptive element |
| 4 | Transfer parameter value (array, word) |
| 5 | Transfer parameter value (array, double word) |
| 6 | Transfer number of array elements |
| 7 | Request cannot be processed, task cannot be executed (with error number) |
| 8 | No master controller status / no parameter change rights for PKW interface |

Error numbers in response ID 7 (request cannot be processed)

| No. | Description |
|-----|--|
| 0 | Illegal PNU (illegal parameter number; parameter number not available) |
| 1 | Parameter value cannot be changed (parameter is read-only) |
| 2 | Lower or upper limit violated (limit exceeded) |
| 3 | Wrong sub-index |
| 4 | No array |
| 5 | Wrong parameter type / incorrect data type |
| 6 | Setting is not allowed (parameter value can only be reset to zero) |
| 7 | The descriptive element is not changeable and can only be read |
| 9 | Descriptive data not available |
| 10 | Access group incorrect |
| 11 | No parameter change rights. See parameter P0927. Must have status as master control. |
| 12 | Incorrect password |
| 17 | The current inverter operating status does not permit the request processing |
| 18 | Other error |
| 20 | Illegal value. Change request for a value which is within the limits, but it is not allowed for other reasons (parameter with defined single values) |
| 101 | Parameter is currently deactivated; parameter has no function in the present inverter status |
| 102 | Communication channel width is insufficient for response; dependent on the number of PKW and the maximum net data length of the inverter |
| 104 | Illegal parameter value |
| 105 | Parameter is indexed |

6.1 USS communication

| No. | Description |
|-----------|--|
| 106 | Request is not included / task is not supported |
| 109 | PKW request access timeout / number of retries is exceeded / wait for response from CPU side |
| 110 | Parameter value cannot be changed (parameter is locked) |
| 200 / 201 | Changed lower / upper limits exceeded |
| 202 / 203 | No display on the BOP |
| 204 | The available access authorization does not cover parameter changes |
| 300 | Array elements differ |

Basic inverter settings

| Parameter | Function | Setting |
|-----------|-------------------------------------|---|
| P0010 | Commissioning parameter | = 30: restores to factory settings |
| P0970 | Factory reset | Possible settings: = 1: resets all parameters (not user defaults) to their default values = 21: resets all parameters and all user defaults to factory reset state Note: Parameters P2010, P2011, P2023 retain their values after a factory reset. |
| P0003 | User access level | = 3 |
| P0700 | Selection of command source | = 5: USS / MODBUS on RS485 Factory default: 1 (operator panel) |
| P1000 | Selection of frequency setpoint | = 5: USS on RS485 Factory default: 1 (MOP setpoint) |
| P2023 | RS485 protocol selection | = 1: USS (factory default) Note: After changing P2023, powercycle the inverter. During the powercycle, wait until LED has gone off or the display has gone blank (may take a few seconds) before re-applying power. If P2023 has been changed via a PLC, make sure the change has been saved to EEPROM via P0971. |
| P2010[0] | USS / MODBUS baudrate | Possible settings: = 6: 9600 bps = 7: 19200 bps = 8: 38400 bps (factory default) ... = 12: 115200 bps |
| P2011[0] | USS address | Sets the unique address for the inverter. Range: 0 ... 31 (factory default: 0) |
| P2012[0] | USS PZD (process data) length | Defines the number of 16-bit words in PZD part of USS telegram. Range: 0 ... 8 (factory default: 2) |
| P2013[0] | USS PKW (parameter ID value) length | Defines the number of 16-bit words in PKW part of USS telegram. Possible settings: = 0, 3, 4: 0, 3 or 4 words = 127: variable length (factory default) |
| P2014[0] | USS / MODBUS telegram off time [ms] | By default (time set to 0), no fault is generated (i.e. watchdog disabled). |

| Parameter | Function | Setting |
|-----------------------------|------------------------------------|---|
| r2024[0] ... r2031[0] | USS / MODBUS error statistics | The state of the telegram information on RS485 is reported regardless of the protocol set in P2023. |
| r2018[0...7] | CO: PZD from USS / MODBUS on RS485 | Displays process data received via USS / MODBUS on RS485. |
| P2019[0...7] | CI: PZD to USS / MODBUS on RS485 | Displays process data transmitted via USS / MODBUS on RS485. |


6.2 MODBUS communication

Overview

In MODBUS, only the master can start a communication and the slave will answer it. There are two ways of sending a message to a slave. One is unicast mode (address 1 ... 247), where the master addresses the slave directly; the other is broadcast mode (address 0), where the master addresses all slaves.

When a slave has received a message, which was addressed at it, the Function Code tells it what to do. For the task defined by the Function Code, the slave may receive some data. And for error checking a CRC code is also included.

After receiving and processing a unicast message, the MODBUS slave will send a reply, but only if no error was detected in the received message. If a processing error occurs, the slave will reply with an error message. The following fixed framing characters in a message can not be altered: 8 data bits, 1 parity-even bit and 1 stop bit.



Supported Function Codes

The SINAMICS V20 supports only three Function Codes. If a request with an unknown Function Code is received, an error message will be returned.

FC3 - Read Holding Registers

When a message with FC = 0 x 03 is received, then 4 bytes of data are expected, that is, FC3 has 4 bytes of data:

- 2 bytes for the starting address
- 2 bytes for the number of registers

| Byte 1 | Byte 2 | Byte 3 | Byte 4 | Byte 5 | Byte 6 | Byte 7 | Byte 8 |
|---------|-------------|---------------------|---------------------|---------------------------|---------------------------|--------|--------|
| Address | FC (0 x 03) | Start address (MSF) | Start address (LSF) | Number of registers (MSF) | Number of registers (LSF) | CRC | CRC |

FC6 - Write Single Register

When a message with FC = 0 x 06 is received, then 4 bytes of data are expected, that is, FC6 has 4 bytes of data:

- 2 bytes for the register address
- 2 bytes for the register value

| Byte 1 | Byte 2 | Byte 3 | Byte 4 | Byte 5 | Byte 6 | Byte 7 | Byte 8 |
|---------|-------------|------------------------|------------------------|-----------------------------|-----------------------------|--------|--------|
| Address | FC (0 x 06) | Start address (MSF) | Start address (LSF) | New register value (MSF) | New register value (LSF) | CRC | CRC |

FC16 - Write Multiple Registers

When a message with FC = 0 x 10 is received, then 5 + N bytes of data are expected, that is, FC16 has 5 + N bytes of data:

- 2 bytes for the starting address
- 2 bytes for the number of registers
- 1 byte for the byte count
- N bytes for the register values

| Byte 1 | Byte 2 | Byte 3 | Byte 4 | Byte 5 | Byte 6 | Byte 7 | Byte 7 + n | Byte 8 + n | Byte 9 + n | Byte 10 + n |
|---------|-------------|------------------------|------------------------|------------------------------|------------------------------|-----------------|--------------------|--------------------|------------|-------------|
| Address | FC (0 x 10) | Start address (MSF) | Start address (LSF) | Number of registers (MSF) | Number of registers (LSF) | Number of bytes | nth value (MSF) | nth value (LSF) | CRC | CRC |

Exception Responses

If an error is detected through the MODBUS processing, the slave will respond with the FC of the request, but with most significant bit of the FC high and with the Exception Code in the data field. However, any error detected on the global address 0 does not result in a response since all slaves cannot respond at once.

If an error is detected within the received message (for example, parity error, incorrect CRC and so on), then NO response is sent to the master.

Note that if a request with FC16 is received which contains a write that the inverter cannot perform (including write to a zero entry), other valid writes will still be performed even though an exception response is returned.

The following MODBUS Exception Codes are supported by SINAMICS V20:

| Exception Code | MODBUS name | Meaning |
|----------------|-----------------------|---|
| 01 | Illegal function code | The function code is not supported – only FC3, FC6 and FC16 are supported. |
| 02 | Illegal data address | An invalid address was queried. |
| 03 | Illegal data value | An invalid data value was recognized. |
| 04 | Slave device failure | An unrecoverable error occurred while the device was processing the action. |

The table below shows the cases in which an Exception Code is returned:

| Error description | Exception Code |
|--|----------------|
| Unknown Function Code | 01 |
| Read registers, which are out of boundary | 02 |
| Write register, which is out of boundary | 02 |
| Read request of too many registers (>125) | 03 |
| Write request of too many registers (>123) | 03 |
| Incorrect message length | 03 |
| Write to a read-only register | 04 |
| Write register, error in parameter access | 04 |
| Read register, error in Parameter Manager | 04 |
| Write to a zero entry | 04 |
| Unknown error | 04 |

Basic inverter settings

| Parameter | Function | Setting |
|-----------|-------------------------------------|---|
| P0010 | Commissioning parameter | = 30: restores to factory settings |
| P0970 | Factory reset | Possible settings: = 1: resets all parameters (not user defaults) to their default values = 21: resets all parameters and all user defaults to factory reset state Note: Parameters P2010, P2021, P2023 retain their values after a factory reset. |
| P0003 | User access level | = 3 |
| P0700 | Selection of command source | = 5: USS / MODBUS on RS485 Factory default: 1 (operator panel) |
| P2010[0] | USS / MODBUS baudrate | Possible settings: = 6: 9600 bps = 7: 19200 bps = 8: 38400 bps (factory default) ... =12 115200 bps |
| P2014[0] | USS / MODBUS telegram off time [ms] | By default (time set to 0), no fault is generated (i.e. watchdog disabled). |
| P2021 | Modbus address | Sets the unique address for the inverter. Range: 1 ... 247 (factory default: 1) |
| P2022 | Modbus reply timeout [ms] | Range: 0 ... 10000 (factory default: 1000) |
| P2023 | RS485 protocol selection | = 2: Modbus Factory default: 1 (USS) Note: After changing P2023, powercycle the inverter. During the powercycle, wait until LED has gone off or the display has gone blank (may take a few seconds) before re-applying power. If P2023 has been changed via a PLC, make sure the change has been saved to EEPROM via P0971. |

6.2 MODBUS communication

| Parameter | Function | Setting |
|-----------------------------|------------------------------------|---|
| r2024[0] ... r2031[0] | USS / MODBUS error statistics | The state of the telegram information on RS485 is reported regardless of the protocol set in P2023. |
| r2018[0...7] | CO: PZD from USS / MODBUS on RS485 | Displays process data received via USS / MODBUS on RS485. |
| P2019[0...7] | CI: PZD to USS / MODBUS on RS485 | Displays process data transmitted via USS / MODBUS on RS485. |

Mapping table

The SINAMICS V20 inverter supports two sets of registers (40001 ... 40062, 40100 ... 40522) as the table below shows. "R", "W", "R/W" in the column Access stand for read, write, read/write.

| Register No. | Description | Access | Unit | Scaling factor | Range or On/Off text | Read | Write |
|--------------|-------------|---------------|------|----------------|----------------------|------------------|-------------------------|
| Inverter | MODBUS | | | | | | |
| 0 | 40001 | WDOG TIME | R/W | ms | 1 | 0 - 65535 | - |
| 1 | 40002 | WDOG ACTION | R/W | - | 1 | - | - |
| 2 | 40003 | FREQ REF | R/W | % | 100 | 0.00 - 100.00 | HSW |
| 3 | 40004 | RUN ENABLE | R/W | - | 1 | 0 - 1 | STW:3 |
| 4 | 40005 | CMD FWD REV | R/W | - | 1 | 0 - 1 | STW:11 |
| 5 | 40006 | CMD START | R/W | - | 1 | 0 - 1 | STW:0 |
| 6 | 40007 | FAULT ACK | R/W | - | 1 | 0 - 1 | STW:7 |
| 7 | 40008 | PID SETP REF | R/W | % | 100 | -200.0 - 200.0 | P2240 |
| 8 | 40009 | ENABLE PID | R/W | - | 1 | 0 - 1 | r0055.8 (BICO) P2200 |
| 9 | 40010 | CURRENT LMT | R/W | % | 10 | 10.0 - 400.0 | P0640 |
| 10 | 40011 | ACCEL TIME | R/W | s | 100 | 0.00 - 650.0 | P1120 |
| 11 | 40012 | DECCEL TIME | R/W | s | 100 | 0.00 - 650.0 | P1121 |
| 12 | 40013 | (Reserved) | | | | | |
| 13 | 40014 | DIGITAL OUT 1 | R/W | - | 1 | HIGH | LOW |
| 14 | 40015 | DIGITAL OUT 2 | R/W | - | 1 | HIGH | LOW |
| 15 | 40016 | REF FREQ | R/W | Hz | 100 | 1.00 - 599.00 | P2000 |
| 16 | 40017 | PID UP LMT | R/W | % | 100 | -200.0 - 200.0 | P2291 |
| 17 | 40018 | PID LO LMT | R/W | % | 100 | -200.0 - 200.0 | P2292 |
| 18 | 40019 | P GAIN | R/W | - | 1000 | 0.000 - 65.000 | P2280 |
| 19 | 40020 | I GAIN | R/W | s | 1 | 0 - 60 | P2285 |
| 20 | 40021 | D GAIN | R/W | - | 1 | 0 - 60 | P2274 |
| 21 | 40022 | FEEDBK GAIN | R/W | % | 100 | 0.00 - 500.00 | P2269 |
| 22 | 40023 | LOW PASS | R/W | - | 100 | 0.00 - 60.00 | P2265 |
| 23 | 40024 | FREQ OUTPUT | R | Hz | 100 | -327.68 - 327.67 | r0024 |
| 24 | 40025 | SPEED | R | RPM | 1 | -16250 - 16250 | r0022 |
| 25 | 40026 | CURRENT | R | A | 100 | 0 - 163.83 | r0027 |
| 26 | 40027 | TORQUE | R | Nm | 100 | -325.00 - 325.00 | r0031 |
| 27 | 40028 | ACTUAL PWR | R | kW | 100 | 0 - 327.67 | r0032 |
| 28 | 40029 | TOTAL KWH | R | kWh | 1 | 0 - 32767 | r0039 |
| 29 | 40030 | DC BUS VOLTS | R | V | 1 | 0 - 32767 | r0026 |

| Register No. | | Description | Access | Unit | Scaling factor | Range or On/Off text | | Read | Write |
|--------------|--------|----------------|--------|------|----------------|----------------------|-------|----------|--------------|
| Inverter | MODBUS | | | | | | | | |
| 30 | 40031 | REFERENCE | R | Hz | 100 | -327.68 - 327.67 | | r0020 | r0020 |
| 31 | 40032 | RATED PWR | R | kW | 100 | 0 - 327.67 | | r0206 | r0206 |
| 32 | 40033 | OUTPUT VOLTS | R | V | 1 | 0 - 32767 | | r0025 | r0025 |
| 33 | 40034 | FWD REV | R | - | 1 | FWD | REV | ZSW:14 | ZSW:14 |
| 34 | 40035 | STOP RUN | R | - | 1 | STOP | RUN | ZSW:2 | ZSW:2 |
| 35 | 40036 | AT MAX FREQ | R | - | 1 | MAX | NO | ZSW:10 | ZSW:10 |
| 36 | 40037 | CONTROL MODE | R | - | 1 | SERIAL | LOCAL | ZSW:9 | ZSW:9 |
| 37 | 40038 | ENABLED | R | - | 1 | ON | OFF | ZSW:0 | ZSW:0 |
| 38 | 40039 | READY TO RUN | R | - | 1 | READY | OFF | ZSW:1 | ZSW:1 |
| 39 | 40040 | ANALOG IN 1 | R | % | 100 | -300.0 - 300.0 | | r0754[0] | r0754[0] |
| 40 | 40041 | ANALOG IN 2 | R | % | 100 | -300.0 - 300.0 | | r0754[1] | r0754[1] |
| 41 | 40042 | ANALOG OUT 1 | R | % | 100 | -100.0 - 100.0 | | r0774[0] | r0774[0] |
| 43 | 40044 | FREQ ACTUAL | R | % | 100 | -100.0 - 100.0 | | HIW | HIW |
| 44 | 40045 | PID SETP OUT | R | % | 100 | -100.0 - 100.0 | | r2250 | r2250 |
| 45 | 40046 | PID OUTPUT | R | % | 100 | -100.0 - 100.0 | | r2294 | r2294 |
| 46 | 40047 | PID FEEDBACK | R | % | 100 | -100.0 - 100.0 | | r2266 | r2266 |
| 47 | 40048 | DIGITAL IN 1 | R | - | 1 | HIGH | LOW | r0722.0 | r0722.0 |
| 48 | 40049 | DIGITAL IN 2 | R | - | 1 | HIGH | LOW | r0722.1 | r0722.1 |
| 49 | 40050 | DIGITAL IN 3 | R | - | 1 | HIGH | LOW | r0722.2 | r0722.2 |
| 50 | 40051 | DIGITAL IN 4 | R | - | 1 | HIGH | LOW | r0722.3 | r0722.3 |
| 53 | 40054 | FAULT | R | - | 1 | FAULT | OFF | ZSW:3 | ZSW:3 |
| 54 | 40055 | LAST FAULT | R | - | 1 | 0 - 32767 | | r0947[0] | r0947[0] |
| 55 | 40056 | 1. FAULT | R | - | 1 | 0 - 32767 | | r0947[1] | r0947[1] |
| 56 | 40057 | 2. FAULT | R | - | 1 | 0 - 32767 | | r0947[2] | r0947[2] |
| 57 | 40058 | 3. FAULT | R | - | 1 | 0 - 32767 | | r0947[3] | r0947[3] |
| 58 | 40059 | WARNING | R | - | 1 | WARN | OK | ZSW:7 | ZSW:7 |
| 59 | 40060 | LAST WARNING | R | - | 1 | 0 - 32767 | | r2110 | r2110 |
| 60 | 40061 | INVERTER VER | R | - | 100 | 0.00 - 327.67 | | r0018 | r0018 |
| 61 | 40062 | DRIVE MODEL | R | - | 1 | 0 - 32767 | | r0201 | r0201 |
| 99 | 40100 | STW | R/W | - | 1 | | | PZD 1 | PZD 1 |
| 100 | 40101 | HSW | R/W | - | 1 | | | PZD 2 | PZD 2 |
| 109 | 40110 | ZSW | R | - | 1 | | | PZD 1 | PZD 1 |
| 110 | 40111 | HIW | R | - | 1 | | | PZD 2 | PZD 2 |
| 199 | 40200 | DIGITAL OUT 1 | R/W | - | 1 | HIGH | LOW | r0747.0 | (BICO) P0731 |
| 200 | 40201 | DIGITAL OUT 2 | R/W | - | 1 | HIGH | LOW | r0747.1 | (BICO) P0732 |
| 219 | 40220 | ANALOG OUT 1 | R | % | 100 | -100.0 - 100.0 | | r0774[0] | r0774[0] |
| 239 | 40240 | DIGITAL IN 1 | R | - | 1 | HIGH | LOW | r0722.0 | r0722.0 |
| 240 | 40241 | DIGITAL IN 2 | R | - | 1 | HIGH | LOW | r0722.1 | r0722.1 |
| 241 | 40242 | DIGITAL IN 3 | R | - | 1 | HIGH | LOW | r0722.2 | r0722.2 |
| 242 | 40243 | DIGITAL IN 4 | R | - | 1 | HIGH | LOW | r0722.3 | r0722.3 |
| 259 | 40260 | ANALOG IN 1 | R | % | 100 | -300.0 - 300.0 | | r0754[0] | r0754[0] |
| 260 | 40261 | ANALOG IN 2 | R | % | 100 | -300.0 - 300.0 | | r0754[1] | r0754[1] |
| 299 | 40300 | INVERTER MODEL | R | - | 1 | 0 - 32767 | | r0201 | r0201 |
| 300 | 40301 | INVERTER VER | R | - | 100 | 0.00 - 327.67 | | r0018 | r0018 |

6.2 MODBUS communication

| Register No. | Description | | Access | Unit | Scaling factor | Range or On/Off text | Read | Write |
|--------------|-------------|----------------|--------|------|----------------|----------------------|----------|--------------|
| Inverter | MODBUS | | | | | | | |
| 319 | 40320 | RATED PWR | R | kW | 100 | 0 - 327.67 | r0206 | r0206 |
| 320 | 40321 | CURRENT LMT | R/W | % | 10 | 10.0 - 400.0 | P0640 | P0640 |
| 321 | 40322 | ACCEL TIME | R/W | s | 100 | 0.00 - 650.0 | P1120 | P1120 |
| 322 | 40323 | DECCEL TIME | R/W | s | 100 | 0.00 - 650.0 | P1121 | P1121 |
| 323 | 40324 | REF FREQ | R/W | Hz | 100 | 1.00 - 650.0 | P2000 | P2000 |
| 339 | 40340 | REFERENCE | R | Hz | 100 | -327.68 - 327.67 | r0020 | r0020 |
| 340 | 40341 | SPEED | R | RPM | 1 | -16250 - 16250 | r0022 | r0022 |
| 341 | 40342 | FREQ OUTPUT | R | Hz | 100 | -327.68 - 327.67 | r0024 | r0024 |
| 342 | 40343 | OUTPUT VOLTS | R | V | 1 | 0 - 32767 | r0025 | r0025 |
| 343 | 40344 | DC BUS VOLTS | R | V | 1 | 0 - 32767 | r0026 | r0026 |
| 344 | 40345 | CURRENT | R | A | 100 | 0 - 163.83 | r0027 | r0027 |
| 345 | 40346 | TORQUE | R | Nm | 100 | -325.00 - 325.00 | r0031 | r0031 |
| 346 | 40347 | ACTUAL PWR | R | kW | 100 | 0 - 327.67 | r0032 | r0032 |
| 347 | 40348 | TOTAL KWH | R | kWh | 1 | 0 - 32767 | r0039 | r0039 |
| 348 | 40349 | HAND AUTO | R | - | 1 | HAND AUTO | r0807 | r0807 |
| 399 | 40400 | FAULT 1 | R | - | 1 | 0 - 32767 | r0947[0] | r0947[0] |
| 400 | 40401 | FAULT 2 | R | - | 1 | 0 - 32767 | r0947[1] | r0947[1] |
| 401 | 40402 | FAULT 3 | R | - | 1 | 0 - 32767 | r0947[2] | r0947[2] |
| 402 | 40403 | FAULT 4 | R | - | 1 | 0 - 32767 | r0947[3] | r0947[3] |
| 403 | 40404 | FAULT 5 | R | - | 1 | 0 - 32767 | r0947[4] | r0947[4] |
| 404 | 40405 | FAULT 6 | R | - | 1 | 0 - 32767 | r0947[5] | r0947[5] |
| 405 | 40406 | FAULT 7 | R | - | 1 | 0 - 32767 | r0947[6] | r0947[6] |
| 406 | 40407 | FAULT 8 | R | - | 1 | 0 - 32767 | r0947[7] | r0947[7] |
| 407 | 40408 | WARNING | R | - | 1 | 0 - 32767 | r2110[0] | r2110[0] |
| 498 | 40499 | PRM ERROR CODE | R | - | 1 | 0 - 254 | - | - |
| 499 | 40500 | ENABLE PID | R/W | - | 1 | 0 - 1 | r055.8 | (BICO) P2200 |
| 500 | 40501 | PID SETP REF | R/W | % | 100 | -200.0 - 200.0 | P2240 | P2240 |
| 509 | 40510 | LOW PASS | R/W | - | 100 | 0.00 - 60.0 | P2265 | P2265 |
| 510 | 40511 | FEEDBK GAIN | R/W | % | 100 | 0.00 - 500.00 | P2269 | P2269 |
| 511 | 40512 | P GAIN | R/W | - | 1000 | 0.000 - 65.000 | P2280 | P2280 |
| 512 | 40513 | I GAIN | R/W | s | 1 | 0 - 60 | P2285 | P2285 |
| 513 | 40514 | D GAIN | R/W | - | 1 | 0 - 60 | P2274 | P2274 |
| 514 | 40515 | PID UP LMT | R/W | % | 100 | -200.0 - 200.0 | P2291 | P2291 |
| 515 | 40516 | PID LO LMT | R/W | % | 100 | -200.0 - 200.0 | P2292 | P2292 |
| 519 | 40520 | PID SETP OUT | R | % | 100 | -100.0 - 100.0 | r2250 | r2250 |
| 520 | 40521 | PI FEEDBACK | R | % | 100 | -100.0 - 100.0 | r2266 | r2266 |
| 521 | 40522 | PID OUTPUT | R | % | 100 | -100.0 - 100.0 | r2294 | r2294 |

Control data

- HSW (Haupsollwert): speed setpoint
- HIW (Hauptistwert): actual speed
- STW (Steuerwort): control word
- ZSW (Zustandswort): status word

For more information, see parameters r2018 and P2019 in Chapter "Parameter list (Page 117)".

Parameter scaling

Due to the limits of the integer data in the MODBUS protocol, it is necessary to convert the inverter parameters before transmitting them. This is done by scaling, so that a parameter, which has a position after decimal point, is multiplied by a factor, to get rid of the fractional part. The scaling factor is as defined in the above table.

BICO parameters

The updating of BICO parameters will also be done in the parameter processing in the background. Because of the limitations of the register value, it is only possible to write a '0' or a '1' to a BICO parameter. This will set BICO input to a static value of either '0' or '1'. The previous connection to another parameter is lost. Reading the BICO parameter will return the current value of the BICO output.

For example: MODBUS register number 40200. Writing a value 0 or 1 to that register will set the BICO input P0731 statically to that value. Reading will return the BICO output, which is stored in r0747.0.

Fault

A fault (F72) should be triggered if:

- The parameter P2014 (USS / MODBUS telegram off time) is not equal to 0
AND
- Process data has been received from the master since the inverter's start-up
AND
- The time between receipts of two consecutive process data telegrams exceeds the value of P2014.

Parameter list

7.1 Introduction to parameters

Parameter number

Numbers prefixed with an "r" indicate that the parameter is a "read-only" parameter.

Numbers prefixed with a "P" indicate that the parameter is a "writable" parameter.

[index] indicates that the parameter is an indexed parameter and specifies the range of indices available. If the index is [0...2] and the meaning is not listed, then see "Data set".

.0...15 indicates that the parameter has several bits, which can be evaluated or connected individually.

Data set

NOTICE

To view CDS / DDS parameters, see "Index" at the end of this manual.

In the inverter, the parameters which are used to define the sources for commands and setpoints are combined in the **Command Data Set** (CDS), while the parameters for the open and closed-loop control of the motor are combined in the **Inverter Data Set** (DDS).

The inverter can be operated from different signal sources by switching over the command data sets. When switching over the inverter data sets, it is possible to switch between different inverter configurations (control type, motor).

Three independent settings are possible for each data set. These settings can be made using the index [0...2] of the particular parameter.

| Index | CDS | DDS |
|-------|--------------------|---------------------|
| [0] | Command data set 0 | Inverter data set 0 |
| [1] | Command data set 1 | Inverter data set 1 |
| [2] | Command data set 2 | Inverter data set 2 |

SINAMICS V20 has an integrated copy function which is used to transfer data sets. This can be used to copy CDS / DDS parameters corresponding to the particular application.

| Copy CDS | Copy DDS | Remarks |
|----------|----------|---|
| P0809[0] | P0819[0] | The data set which is to be copied (source) |
| P0809[1] | P0819[1] | The data set into which data is to be copied (target) |
| P0809[2] | P0819[2] | = 1: Start copying = 0: Copying completed |

7.1 Introduction to parameters

For example, copying of all values from CDS0 to CDS2 can be accomplished by the following procedure:

1. Set P0809[0] = 0: copy from CDS0
2. Set P0809[1] = 2: copy to CDS2
3. Set P0809[2] = 1: start copy

Command data set

The command data sets are changed over using the BICO parameters P0810 and P0811, whereby the active command data set is displayed in parameter r0050. Changeover is possible in both the "Ready" and the "Run" states.

| | |
|-----------------------------|------|
| P0810 = 0 P0811 = 0 | CDS0 |
| P0810 = 1 P0811 = 0 | CDS1 |
| P0810 = 0 or 1 P0811 = 1 | CDS2 |

Inverter data set

The inverter data sets are changed over using the BICO parameters P0820 and P0821, whereby the active inverter data set is displayed in parameter r0051. Inverter data sets can only be changed over in the "Ready" state.

| | |
|-----------------------------|------|
| P0820 = 0 P0821 = 0 | DDS0 |
| P0820 = 1 P0821 = 0 | DDS1 |
| P0820 = 0 or 1 P0821 = 1 | DDS2 |

BI, BO, CI, CO, CO / BO in parameter names


NOTICE

To view BICO parameters, see "Index" at the end of this manual.

Certain parameter names include the following abbreviated prefixes: BI, BO, CI, CO and CO / BO followed by a colon. These abbreviations have the following meanings:

| | | | |
|---------|---|--|---|
| BI | = | | Binector input: Parameter selects the source of a binary signal |
| BO | = | | Binector output: Parameter connects as a binary signal |
| CI | = | | Connector input: Parameter selects the source of an analog signal |
| CO | = | | Connector output: Parameter connects as an analog signal |
| CO / BO | = | | Connector / binector output: Parameter connects as an analog signal and / or as a binary signal |

BICO example



BICO or the binary interconnection technology can help the user to connect internal function and values to realize more customized features.

BICO functionality is a different, more flexible way of setting and combining input and output functions. It can be used in most cases in conjunction with the simple, access level 2 settings.

The BICO system allows complex functions to be programmed. Boolean and mathematical relationships can be set up between inputs (digital, analog, serial etc.) and outputs (inverter current, frequency, analog output, digital outputs, etc.).

The default parameter that a BI or CI parameter is connected to is shown in the Factory default column of the parameter list.

Access level (P0003)

Defines the level of user access to parameter sets.

| Access level | Description | Remarks |
|--------------|-----------------------------|---|
| 0 | User-defined parameter list | Defines a limited set of parameters to which the end user has access. See P0013 for details on use. |
| 1 | Standard | Allows access into most frequently used parameters. |
| 2 | Extended | Allows extended access to more parameters. |
| 3 | Expert | For expert use only. |
| 4 | Service | Only for use by authorized service personnel, password protected. |

Data type

The data types available are shown in the table below.

| | |
|-------|------------------------------|
| U8 | 8-bit unsigned |
| U16 | 16-bit unsigned |
| U32 | 32-bit unsigned |
| I16 | 16-bit integer |
| I32 | 32-bit integer |
| Float | 32-bit floating point number |

Depending on the data type of the BICO input parameter (signal sink) and BICO output parameter (signal source) the following combinations are possible when creating BICO interconnections:

| BICO output parameter | BICO input parameter | | | BI parameter |
|-----------------------|----------------------|-----------|-----------|--------------|
| | CI parameter | U32 / I16 | U32 / I32 | |
| CO: U8 | √ | √ | - | - |
| CO: U16 | √ | √ | - | - |
| CO: U32 | √ | √ | - | - |
| CO: I16 | √ | √ | - | - |
| CO: I32 | √ | √ | - | - |
| CO: Float | √ | √ | √ | - |
| BO: U8 | - | - | - | √ |
| BO: U16 | - | - | - | √ |
| BO: U32 | - | - | - | √ |
| BO: I16 | - | - | - | √ |
| BO: I32 | - | - | - | √ |
| BO: Float | - | - | - | - |

Legend:
√: BICO interconnection permitted
-: BICO interconnection not permitted

Scaling

Specification of the reference quantity with which the signal value will be converted automatically.

Reference quantities, corresponding to 100 %, are required for the statement of physical units as percentages. These reference quantities are entered in P2000 ... P2004.

In addition to P2000 ... P2004 the following normalizations are used:

- TEMP: 100 °C = 100 %
- PERCENT: 1.0 = 100 %
- 4000H: 4000 hex = 100 %

Can be changed

Inverter state in which the parameter is changeable. Three states are possible:

- Commissioning: C(1)
- Run: U
- Ready to run: T

This indicates when the parameter can be changed. One, two or all three states may be specified. If all three states are specified, this means that it is possible to change this parameter setting in all three inverter states. C(1) shows, that the parameter is only changeable when P0010 = 1 (quick commissioning).

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|-----------|---|--|-----------------|----------------|---------|----------|-----------|------------|
| r0002 | Inverter state | - | - | - | - | - | U16 | 2 |
| | Displays actual inverter state. | | | | | | | |
| | 0 | Commissioning mode (P0010 ≠ 0) | | | | | | |
| | 1 | Inverter ready | | | | | | |
| | 2 | Inverter fault active | | | | | | |
| | 3 | Inverter starting (visible only while pre-charging DC link) | | | | | | |
| | 4 | Inverter running | | | | | | |
| | 5 | Stopping (ramping down) | | | | | | |
| | 6 | Inverter inhibited | | | | | | |
| P0003 | User access level | 0 - 4 | 1 | U, T | - | - | U16 | 1 |
| | Defines user access level to parameter sets. | | | | | | | |
| | 0 | User defined parameter list - see P0013 for details on use | | | | | | |
| | 1 | Standard: Allows access into most frequently used parameters | | | | | | |
| | 2 | Extended: Allows extended access, for example, to inverter I/O functions | | | | | | |
| | 3 | Expert: For expert use only | | | | | | |
| | 4 | Service: Only for use by authorized service, password protected | | | | | | |
| P0004 | Parameter filter | 0 - 22 | 0 | U, T | - | - | U16 | 1 |
| | Filters parameters according to functionality to enable a more focused approach to commissioning. | | | | | | | |
| | 0 | All parameters | | | | | | |
| | 2 | Inverter | | | | | | |
| | 3 | Motor | | | | | | |
| | 5 | Technology application / units | | | | | | |
| | 7 | Commands, binary I/O | | | | | | |
| | 8 | Analog input and analog output | | | | | | |
| | 10 | Setpoint channel / RFG | | | | | | |
| | 12 | Inverter features | | | | | | |
| | 13 | Motor control | | | | | | |
| | 19 | Motor identification | | | | | | |
| | 20 | Communication | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|---|--|-----------------|----------------|---------|----------|-----------|------------|
| | 21 | Warnings / faults / monitoring | | | | | | |
| | 22 | Technology controller | | | | | | |
| P0007 | Backlight delay time | 0 - 2000 | 0 | U, T | - | - | U16 | 3 |
| | Defines time period after which the backlight of the operator panel display turns off if no buttons have been pressed. | | | | | | | |
| | 0 | Backlight always on | | | | | | |
| | 1 - 2000 | Number of seconds after which the backlight turns off. | | | | | | |
| P0010 | Commissioning parameter | 0 - 30 | 0 | T | - | - | U16 | 1 |
| | Filters parameters so that only those related to a particular functional group are selected. | | | | | | | |
| | 0 | Ready | | | | | | |
| | 1 | Quick commissioning | | | | | | |
| | 2 | Inverter | | | | | | |
| | 29 | Download | | | | | | |
| | 30 | Factory setting | | | | | | |
| Dependency: | Reset to 0 for inverter to run. P0003 (user access level) also determines access to parameters. | | | | | | | |
| Note: | <ul style="list-style-type: none"> • P0010 = 1 The inverter can be commissioned very quickly and easily by setting P0010 = 1. After that only the important parameters (e.g.: P0304, P0305, etc.) are visible. The value of these parameters must be entered one after the other. The end of quick commissioning and the start of internal calculation will be done by setting P3900 = 1 - 3. Afterwards parameter P0010 and P3900 will be reset to zero automatically. • P0010 = 2 For service purposes only. • P0010 = 30 When resetting the parameters or user default values of inverter P0010 must be set to 30. Resetting of the parameters will be started by setting parameter P0970 = 1. The inverter will automatically reset all its parameters to their default settings. This can prove beneficial if you experience problems during parameter setup and wish to start again. Resetting of the user default values will be started by setting parameter P0970 = 21. The inverter will automatically reset all its parameters to the factory default settings. Duration of factory setting will take about 60 seconds. | | | | | | | |
| P0011 | Lock for user-defined parameter | 0 - 65535 | 0 | U, T | - | - | U16 | 3 |
| | See P0013 | | | | | | | |
| P0012 | Key for user-defined parameter | 0 - 65535 | 0 | U, T | - | - | U16 | 3 |
| | See P0013 | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|------------------------------|--|----------------|---------|---------------|-----------|------------|
| P0013[0...19] | User-defined parameter | 0 - 65535 | [0...16] 0 [17] 3 [18] 10 [19] 12 | U, T | - | - | U16 | 3 |
| | Defines a limited set of parameters to which the end user has access. | | | | | | | |
| | Instructions for use: <ol style="list-style-type: none"> Set P0003 = 3 (expert user). Go to P0013 indices 0 to 16 (user list) Enter into P0013 index 0 to 16 the parameters required to be visible in the user-defined list. <p>The following values are fixed and cannot be changed:</p> <ul style="list-style-type: none"> - P0013 index 17 = 3 (user access level) - P0013 index 18 = 10 (commissioning parameter filter) - P0013 index 19 = 12 (key for user defined parameter) <ol style="list-style-type: none"> Set P0003 = 0 to activate the user defined parameter. | | | | | | | |
| Index: | [0] | 1st user parameter | | | | | | |
| | [1] | 2nd user parameter | | | | | | |
| | ... | ... | | | | | | |
| | [19] | 20th user parameter | | | | | | |
| Dependency: | First, set P0011 ("lock") to a different value than P0012 ("key") to prevent changes to user-defined parameter. Then, set P0003 to 0 to activate the user-defined list. When locked and the user-defined parameter is activated, the only way to exit the user-defined parameter (and view other parameters) is to set P0012 ("key") to the value in P0011 ("lock"). | | | | | | | |
| P0014[0...2] | Store mode | 0 - 1 | 0 | U, T | - | - | U16 | 3 |
| | Sets the store mode for parameters. The store mode can be configured for all interfaces under "Index". | | | | | | | |
| | 0 | Volatile (RAM) | | | | | | |
| | 1 | Non-volatile (EEPROM) | | | | | | |
| Index: | [0] | USS on RS485 | | | | | | |
| | [1] | USS on RS232 (reserved) | | | | | | |
| | [2] | Reserved | | | | | | |
| Note: | An independent store request may be part of the serial communications (for example, PKE bits 15-12 of USS protocol). See the table below for an influence on the settings of P0014. | | | | | | | |
| | Value of P0014 [x] | Store request via USS | | | | Result | | |
| | RAM | EEPROM | | | | EEPROM | | |
| | EEPROM | EEPROM | | | | EEPROM | | |
| | RAM | RAM | | | | RAM | | |
| | EEPROM | RAM | | | | EEPROM | | |
| | <ol style="list-style-type: none"> P0014 itself will always be stored in the EEPROM. P0014 will not be changed by performing a factory reset (P0010 = 30 and P0970 = 1). <p>When transferring parameter P0014, the inverter uses its processor to carry-out internal calculations. Communications - both via USS as well as Modbus - are interrupted for the time that it takes to make these calculations.</p> | | | | | | | |
| r0018 | Firmware version | - | - | - | - | - | Float | 1 |
| | Displays version number of installed firmware. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|---------------|--|---------------------------------|-----------------|----------------|---------|-----------------|-----------------|------------|
| r0019.0...14 | CO / BO: Operator panel control word | - | - | - | - | - | U16 | 3 |
| | Displays status of operator panel commands. The settings below are used as the "source" codes for keypad control when connecting to BICO input parameters. | | | | | | | |
| | Bit | Signal name | | | | 1 signal | 0 signal | |
| | 00 | ON / OFF1 | | | | Yes | No | |
| | 01 | OFF2: Electrical stop | | | | No | Yes | |
| | 08 | JOG right | | | | Yes | No | |
| | 11 | Reverse (setpoint inversion) | | | | Yes | No | |
| | 13 | Motor potentiometer MOP up | | | | Yes | No | |
| | 14 | Motor potentiometer MOP down | | | | Yes | No | |
| Note: | When BICO technology is used to allocate functions to panel buttons, this parameter displays the actual status of the relevant command. | | | | | | | |
| r0020 | CO: Frequency setpoint before RFG [Hz] | - | - | - | - | - | Float | 3 |
| | Displays actual frequency setpoint (input of ramp function generator). This value is available filtered (r0020) and unfiltered (r1119). The actual frequency setpoint after RFG is displayed in r1170. | | | | | | | |
| r0021 | CO: Actual filtered frequency [Hz] | - | - | - | - | - | Float | 2 |
| | Displays actual inverter output frequency (r0024) excluding slip compensation (and resonance damping, frequency limitation in V/f mode). | | | | | | | |
| r0022 | Actual filtered rotor speed [RPM] | - | - | - | - | - | Float | 3 |
| | Displays calculated rotor speed based on r0021 (filtered output frequency [Hz] x 120 / number of poles). The value is updated every 128 ms. | | | | | | | |
| Note: | This calculation makes no allowance for load-dependent slip. | | | | | | | |
| r0024 | CO: Actual filtered output frequency [Hz] | - | - | - | - | - | Float | 3 |
| | Displays actual filtered output frequency (slip compensation, resonance damping and frequency limitation are included). See also r0021. This value is available filtered (r0024) and unfiltered (r0066). | | | | | | | |
| r0025 | CO: Actual output voltage [V] | - | - | - | - | - | Float | 2 |
| | Displays filtered [rms] voltage applied to motor. This value is available filtered (r0025) and unfiltered (r0072). | | | | | | | |
| r0026[0] | CO: Actual filtered DC-link voltage [V] | - | - | - | - | - | Float | 2 |
| | Displays filtered DC-link voltage. This value is available filtered (r0026) and unfiltered (r0070). | | | | | | | |
| Index: | [0] | Compensation DC voltage channel | | | | | | |
| Note: | r0026[0] = Main DC-link voltage r0026[1] = Decoupled DC-link voltage for internal supply. It depends on the inverter topology. If it is not available it shows the value 0. | | | | | | | |
| r0027 | CO: Actual output current [A] | - | - | - | P2002 | - | Float | 2 |
| | Displays rms value of motor current. This value is available filtered (r0027) and unfiltered (r0068). | | | | | | | |
| r0028 | CO: Motor current modulus | - | - | - | P2002 | - | Float | 4 |
| | Displays estimated rms value of motor current calculated from dclink current. | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|---------------------------------------|-----------------|----------------|---------|----------|-----------|------------|
| r0031 | CO: Actual filtered torque [Nm] | - | - | - | - | - | Float | 2 |
| | Displays electrical torque. This value is available filtered (r0031) and unfiltered (r0080). | | | | | | | |
| Note: | The electrical torque is not the same as the mechanical torque, which can be measured on the shaft. Due to windage and friction a part of the electrical torque is lost in the motor. | | | | | | | |
| r0032 | CO: Actual filtered power | - | - | - | r2004 | - | Float | 2 |
| | Displays (mechanical) shaft power. Value is displayed in [kW] or [hp] depending on setting for P0100 (operation for Europe / North America). P_mech = 2 * Pi * f * M --> r0032[kW] = (2 * Pi / 1000) * (r0022 / 60)[1 / min] * r0031[Nm] r0032[hp] = r0032[kW] / 0.75 | | | | | | | |
| r0035[0...2] | CO: Actual motor temperature [°C] | - | - | - | - | DDS | Float | 2 |
| | Displays calculated motor temperature. | | | | | | | |
| r0036 | CO: Inverter overload utilization [%] | - | - | - | PERCENT | - | Float | 4 |
| | Displays inverter overload utilization calculated via the I ² t model. The actual I ² t value relative to the maximum possible I ² t value supplies utilization in [%]. If the current exceeds the threshold for P0294 (inverter I ² t overload warning), warning A505 (inverter I ² t) is generated and the output current of the inverter reduced via P0290 (inverter overload reaction). If 100 % utilization is exceeded, fault F5 (inverter I ² t) is tripped. | | | | | | | |
| Dependency: | r0036 > 0: If the nominal current (see r0207) of the inverter is exceeded, utilization will be displayed, otherwise, 0% utilization is displayed. | | | | | | | |
| r0037[0...1] | CO: Inverter temperature [°C] | - | - | - | - | - | Float | 3 |
| | Displays measured heat sink temperature and calculated junction temperature of IGBTs based on thermal model. | | | | | | | |
| Index: | [0] | Measured heat sink temperature | | | | | | |
| | [1] | Total Chip Junction Temperature | | | | | | |
| Note: | The values are updated every 128 ms. | | | | | | | |
| r0038 | CO: Filtered power factor | - | - | - | - | - | Float | 3 |
| | Displays the filtered power factor. | | | | | | | |
| r0039 | CO: Energy consumpt. meter [kWh] | - | - | - | - | - | Float | 2 |
| | Displays electrical energy used by inverter since display was last reset (see P0040 - reset energy consumption meter). | | | | | | | |
| Dependency: | Value is reset when P0040 = 1 (reset energy consumption meter). | | | | | | | |
| P0040 | Reset energy consumpt. and energy saved meter | 0 - 1 | 0 | T | - | - | U16 | 2 |
| | Resets value of r0039 (energy consumption meter) and r0043 (energy saved meter) to zero. | | | | | | | |
| | 0 | No reset | | | | | | |
| | 1 | Reset r0039 to 0 | | | | | | |
| P0042[0...1] | Energy saving scaling | 0.000 - 100.00 | 0.000 | T | - | - | Float | 2 |
| | Scales the calculated energy saved value | | | | | | | |
| Index: | [0] | Factor for kWh to currency conversion | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|---------------------------------------|-----------------|----------------|-----------------|----------|-----------------|------------|
| | [1] | Factor for kWh to CO2 conversion | | | | | | |
| r0043[0...2] | Energy saved [kWh] | - | - | - | - | - | Float | 2 |
| | Displays calculated energy saved | | | | | | | |
| Index: | [0] | Energy saving in kWh | | | | | | |
| | [1] | Energy saving in currency | | | | | | |
| | [2] | Energy saving in CO2 | | | | | | |
| r0050 | CO / BO: Active command data set | - | - | - | - | - | U16 | 2 |
| | Displays currently active command data set. | | | | | | | |
| | 0 | Command data set 0 (CDS) | | | | | | |
| | 1 | Command data set 1 (CDS) | | | | | | |
| | 2 | Command data set 2 (CDS) | | | | | | |
| Note: | See P0810 | | | | | | | |
| r0051[0...1] | CO: Active inverter data set (DDS) | - | - | - | - | - | U16 | 2 |
| | Displays currently selected and active inverter data set (DDS). | | | | | | | |
| | 0 | Inverter data set 0 (DDS0) | | | | | | |
| | 1 | Inverter data set 1 (DDS1) | | | | | | |
| | 2 | Inverter data set 2 (DDS2) | | | | | | |
| Index: | [0] | Selected inverter data set | | | | | | |
| | [1] | Active inverter data set | | | | | | |
| Note: | See P0820 | | | | | | | |
| r0052.0...15 | CO / BO: Active status word 1 | - | - | - | - | - | U16 | 2 |
| | Displays first active status word of inverter (bit format) and can be used to diagnose inverter status. | | | | | | | |
| | Bit | Signal name | | | 1 signal | | 0 signal | |
| | 00 | Inverter ready | | | Yes | | No | |
| | 01 | Inverter ready to run | | | Yes | | No | |
| | 02 | Inverter running | | | Yes | | No | |
| | 03 | Inverter fault active | | | Yes | | No | |
| | 04 | OFF2 active | | | No | | Yes | |
| | 05 | OFF3 active | | | No | | Yes | |
| | 06 | ON inhibit active | | | Yes | | No | |
| | 07 | Inverter warning active | | | Yes | | No | |
| | 08 | Deviation setpoint / act. value | | | No | | Yes | |
| | 09 | PZD control | | | Yes | | No | |
| | 10 | f_act >= P1082 (f_max) | | | Yes | | No | |
| | 11 | Warning: Motor current / torque limit | | | No | | Yes | |
| | 12 | Brake open | | | Yes | | No | |
| | 13 | Motor overload | | | No | | Yes | |
| | 14 | Motor runs right | | | Yes | | No | |
| | 15 | Inverter overload | | | No | | Yes | |
| Dependency: | r0052 bit 03 "Inverter fault active": Output of bit 3 (Fault) will be inverted on digital output (Low = Fault, High = No Fault). | | | | | | | |
| Note: | See r2197 and r2198. | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | |
|---|--|-------|-----------------|----------------|----------|----------|-----------|------------|--|--|--|--|
| r0053.0...15 | CO / BO: Active status word 2 | - | - | - | - | - | U16 | 2 | | | | |
| Displays second status word of inverter (in bit format). | | | | | | | | | | | | |
| Bit | Signal name | | | | 1 signal | | 0 signal | | | | | |
| 00 | DC brake active | | | | Yes | | No | | | | | |
| 01 | f_act > P2167 (f_off) | | | | Yes | | No | | | | | |
| 02 | f_act > P1080 (f_min) | | | | Yes | | No | | | | | |
| 03 | Act. current r0068 >= P2170 | | | | Yes | | No | | | | | |
| 04 | f_act > P2155 (f_1) | | | | Yes | | No | | | | | |
| 05 | f_act <= P2155 (f_1) | | | | Yes | | No | | | | | |
| 06 | f_act >= setpoint (f_set) | | | | Yes | | No | | | | | |
| 07 | Act. unfilt. Vdc < P2172 | | | | Yes | | No | | | | | |
| 08 | Act. unfilt. Vdc > P2172 | | | | Yes | | No | | | | | |
| 09 | Ramping finished | | | | Yes | | No | | | | | |
| 10 | PID output r2294 == P2292 (PID_min) | | | | Yes | | No | | | | | |
| 11 | PID output r2294 == P2291 (PID_max) | | | | Yes | | No | | | | | |
| 14 | Download Data set 0 from OP | | | | Yes | | No | | | | | |
| 15 | Download Data set 1 from OP | | | | Yes | | No | | | | | |
| Notice: | r0053 bit 00 "DC brake active" ==> see P1233 | | | | | | | | | | | |
| Note: | See r2197 and r2198 | | | | | | | | | | | |
| r0054.0...15 | CO / BO: Active control word 1 | - | - | - | - | - | U16 | 3 | | | | |
| Displays first control word of inverter (in bit format) and can be used to diagnose which commands are active. | | | | | | | | | | | | |
| Bit | Signal name | | | | 1 signal | | 0 signal | | | | | |
| 00 | ON / OFF1 | | | | Yes | | No | | | | | |
| 01 | OFF2: Electrical stop | | | | No | | Yes | | | | | |
| 02 | OFF3: Fast stop | | | | No | | Yes | | | | | |
| 03 | Pulse enable | | | | Yes | | No | | | | | |
| 04 | RFG enable | | | | Yes | | No | | | | | |
| 05 | RFG start | | | | Yes | | No | | | | | |
| 06 | Setpoint enable | | | | Yes | | No | | | | | |
| 07 | Fault acknowledge | | | | Yes | | No | | | | | |
| 08 | JOG right | | | | Yes | | No | | | | | |
| 09 | JOG left | | | | Yes | | No | | | | | |
| 10 | Control from PLC | | | | Yes | | No | | | | | |
| 11 | Reverse (setpoint inversion) | | | | Yes | | No | | | | | |
| 13 | Motor potentiometer MOP up | | | | Yes | | No | | | | | |
| 14 | Motor potentiometer MOP down | | | | Yes | | No | | | | | |
| 15 | CDS Bit 0 (Hand / Auto) | | | | Yes | | No | | | | | |
| Notice: | r0054 is identical to r2036 if USS is selected as command source via P0700 or P0719. | | | | | | | | | | | |
| r0055.0...15 | CO / BO: Active control word 2 | - | - | - | - | - | U16 | 3 | | | | |
| Displays additional control word of inverter (in bit format) and can be used to diagnose which commands are active. | | | | | | | | | | | | |

Parameter list

7.2 Parameter list


| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|----------------|---|---|-----------------|----------------|---------|----------|-----------------|-----------------|
| | Bit | Signal name | | | | | 1 signal | 0 signal |
| | 00 | Fixed frequency Bit 0 | | | | | Yes | No |
| | 01 | Fixed frequency Bit 1 | | | | | Yes | No |
| | 02 | Fixed frequency Bit 2 | | | | | Yes | No |
| | 03 | Fixed frequency Bit 3 | | | | | Yes | No |
| | 04 | Inverter data set (DDS) Bit 0 | | | | | Yes | No |
| | 05 | Inverter data set (DDS) Bit 1 | | | | | Yes | No |
| | 06 | Quick stop disable | | | | | Yes | No |
| | 08 | Enable PID | | | | | Yes | No |
| | 09 | Enable DC brake | | | | | Yes | No |
| | 13 | External fault 1 | | | | | No | Yes |
| | 15 | Command data set (CDS) Bit 1 | | | | | Yes | No |
| Notice: | r0055 is identical to r2037 if USS is selected as command source via P0700 or P0719. | | | | | | | |
| r0056.0...15 | CO / BO: Status of motor control | - | - | - | - | - | U16 | 3 |
| | Displays status of motor control (in bit format), which can be used to diagnose inverter status. | | | | | | | |
| | Bit | Signal name | | | | | 1 signal | 0 signal |
| | 00 | Init. control finished | | | | | Yes | No |
| | 01 | Motor demagnetizing finished | | | | | Yes | No |
| | 02 | Pulses enabled | | | | | Yes | No |
| | 03 | Voltage soft start select | | | | | Yes | No |
| | 04 | Motor excitation finished | | | | | Yes | No |
| | 05 | Starting boost active | | | | | Yes | No |
| | 06 | Acceleration boost active | | | | | Yes | No |
| | 07 | Frequency is negative | | | | | Yes | No |
| | 08 | Field weakening active | | | | | Yes | No |
| | 09 | Volts setpoint limited | | | | | Yes | No |
| | 10 | Slip frequency limited | | | | | Yes | No |
| | 11 | f_out > f_max Freq. limited | | | | | Yes | No |
| | 12 | Phase reversal selected | | | | | Yes | No |
| | 13 | I _{max} controller active / torque limit reached | | | | | Yes | No |
| | 14 | V _{dc} _max controller active | | | | | Yes | No |
| | 15 | KIB (V _{dc} _min control) active | | | | | Yes | No |
| Notice: | The I _{max} controller (r0056 bit 13) will be activated when the actual output current (r0027) exceeds the current limit in r0067. | | | | | | | |
| r0066 | CO: Actual output frequency [Hz] | - | - | - | - | - | Float | 3 |
| | Displays actual output frequency in Hz. This value is available filtered (r0024) and unfiltered (r0066). | | | | | | | |
| Note: | The output frequency is limited by the values entered in P1080 (minimum frequency) and P1082 (maximum frequency). | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|---|--------------------------|-----------------|----------------|---------|----------|-----------|------------|
| r0067 | CO: Actual output current limit [A] | - | - | - | P2002 | - | Float | 3 |
| | Displays valid maximum output current of inverter. r0067 is influenced / determined by the following factors: <ul style="list-style-type: none">• Rated motor current P0305• Motor overload factor P0640• Motor protection in dependency of P0610• r0067 is less than or equal to maximum inverter current r0209• Inverter protection in dependency of P0290 | | | | | | | |
| Note: | A reduction of r0067 may indicate an inverter overload or a motor overload. | | | | | | | |
| r0068 | CO: Output current [A] | - | - | - | P2002 | - | Float | 3 |
| | Displays unfiltered [rms] value of motor current. This value is available filtered (r0027) and unfiltered (r0068). | | | | | | | |
| Note: | Used for process control purposes (in contrast to r0027, which is filtered). | | | | | | | |
| r0069[0...5] | CO: Actual phase currents [A] | - | - | - | P2002 | - | Float | 4 |
| | Displays measured phase currents. | | | | | | | |
| Index: | [0] | U_Phase / Emitter1/ | | | | | | |
| | [1] | Dclink / Emitter2 | | | | | | |
| | [2] | Dclink | | | | | | |
| | [3] | Offset U_phase / Emitter | | | | | | |
| | [4] | Offset dclink | | | | | | |
| | [5] | Not used | | | | | | |
| r0070 | CO: Actual DC-link voltage [V] | - | - | - | - | - | Float | 3 |
| | Displays DC-link voltage. This value is available filtered (r0026) and unfiltered (r0070). | | | | | | | |
| Note: | Used for process control purposes (in contrast to r0026 (actual DC-link voltage), which is filtered). | | | | | | | |
| r0071 | CO: Maximum output voltage [V] | - | - | - | - | - | Float | 3 |
| | Displays maximum output voltage. | | | | | | | |
| Dependency: | Actual maximum output voltage depends on the actual input supply voltage. | | | | | | | |
| r0072 | CO: Actual output voltage [V] | - | - | - | - | - | Float | 3 |
| | Displays output voltage. This value is available filtered (r0025) and unfiltered (r0072). | | | | | | | |
| r0074 | CO: Actual modulation [%] | - | - | - | PERCENT | - | Float | 4 |
| | Displays actual modulation index. The modulation index is defined as ratio between the magnitude of the fundamental component in the inverter phase output voltage and half of the DC-link voltage. | | | | | | | |
| r0078 | CO: Actual current Isq [A] | - | - | - | P2002 | - | Float | 3 |
| | Displays component of torque generating current. This value is available filtered (r0030) and unfiltered (r0078). | | | | | | | |
| r0080 | CO: Actual torque [Nm] | - | - | - | - | - | Float | 4 |
| | Displays actual torque. This value is available filtered (r0031) and unfiltered (r0080). | | | | | | | |
| r0084 | CO: Actual air gap flux [%] | - | - | - | PERCENT | - | Float | 4 |
| | Displays air gap flux relative to the rated motor flux. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|---|-----------------|----------------|---------|----------|-----------|------------|
| r0085 | CO: Actual re-active current [A] | - | - | - | P2002 | - | Float | 3 |
| | Displays re-active (imaginary part) of motor current. | | | | | | | |
| Dependency: | Applies when V/f control is selected in P1300 (control mode); otherwise, the display shows the value zero. | | | | | | | |
| r0086 | CO: Actual active current [A] | - | - | - | P2002 | - | Float | 3 |
| | Displays active (real part) of motor current. | | | | | | | |
| Dependency: | See r0085 | | | | | | | |
| r0087 | CO: Actual power factor | - | - | - | - | - | Float | 3 |
| | Displays the actual power factor. | | | | | | | |
| P0095[0...9] | Cl: Display PZD signals | - | 0 | T | 4000H | - | U32 / I16 | 3 |
| | Selects source of display for PZD signals. | | | | | | | |
| Index: | [0] | 1st PZD signal | | | | | | |
| | [1] | 2nd PZD signal | | | | | | |
| | ... | ... | | | | | | |
| | [9] | 10th PZD signal | | | | | | |
| r0096[0...9] | PZD signals [%] | - | - | - | - | - | Float | 3 |
| | Displays PZD signals. | | | | | | | |
| Index: | [0] | 1st PZD signal | | | | | | |
| | [1] | 2nd PZD signal | | | | | | |
| | ... | ... | | | | | | |
| | [9] | 10th PZD signal | | | | | | |
| Note: | r0096 = 100 % corresponds to 4000 hex. | | | | | | | |
| P0100 | Europe / North America | 0 - 2 | 0 | C(1) | - | - | U16 | 1 |
| | Determines whether power settings are expressed in [kW] or [hp] (e.g. Rated motor power P0307). The default settings for the rated motor frequency P0310 and maximum frequency P1082 are set automatically here, in addition to reference frequency P2000. | | | | | | | |
| | 0 | Europe [kW], motor base frequency is 50 Hz | | | | | | |
| | 1 | North America [hp], motor base frequency is 60 Hz | | | | | | |
| | 2 | North America [kW], motor base frequency is 60 Hz | | | | | | |
| Dependency: | Where: <ul style="list-style-type: none"> Stop inverter first (i.e. disable all pulses) before you change this parameter. P0100 can only be changed with P0010 = 1 (Commissioning mode) via the respective interface. Changing P0100 resets all rated motor parameters as well as other parameters that depend on the rated motor parameters (see P0340 - calculation of motor parameters). | | | | | | | |
| P0199 | Equipment system number | 0 - 255 | 0 | U, T | - | - | U16 | 4 |
| | Equipment system number. This parameter has no operation effect (only for factory purposes). | | | | | | | |
| r0206 | Rated inverter power [kW] / [hp] | - | - | - | - | - | Float | 2 |
| | Displays nominal rated motor power from inverter. | | | | | | | |
| Dependency: | Value is displayed in [kW] or [hp] depending on setting for P0100 (operation for Europe / North America). | | | | | | | |
| r0207[0...2] | Rated inverter current [A] | - | - | - | - | - | Float | 2 |
| | Displays rated inverter current. | | | | | | | |
| Index: | [0] | Rated inverter current | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|----------------------------------|-----------------|----------------|---------|----------|-----------|------------|
| | [1] | Not used | | | | | | |
| | [2] | Rated high overload (HO) current | | | | | | |
| Note: | The rated high overload (HO) current r0207[2] values correspond to suitable 4-pole Siemens standard motors (IEC) for the selected load cycle (see diagram). r0207[2] is the default value of P0305 in association with the HO application (load cycle). | | | | | | | |
| | Inverter current / power  | | | | | | | |
| r0208 | Rated inverter voltage [V] | - | - | - | - | - | U32 | 2 |
| | Displays nominal AC supply voltage of inverter. | | | | | | | |
| Note: | r0208 = 230: 200 - 240 V + / - 10 % r0208 = 400: 380 - 480 V + / - 10 % r0208 = 575: 500 - 600 V + / - 10 % | | | | | | | |
| r0209 | Maximum inverter current [A] | - | - | - | - | - | Float | 2 |
| | Displays maximum output current of inverter. | | | | | | | |
| Dependency: | r0209 depends on the derating which is affected by pulse frequency P1800, ambient temperature and altitude. The data of deration is given in the Operating Instructions. | | | | | | | |
| P0210 | Supply voltage [V] | 0 - 1000 | 400 | T | - | - | U16 | 3 |
| | P0210 defines the supply voltage. Its default value depends upon the type of inverter. If P0210 does not correspond to the supply voltage, then it must be modified. | | | | | | | |
| Dependency: | Optimizes Vdc controller, which extends the ramp-down time if regenerative energy from motor would otherwise cause DC-link overvoltage trips. Reducing the value enables controller to cut in earlier and reduce the risk of overvoltage. Set P1254 ("Auto detect Vdc switch-on levels") = 0. Cut-in levels for Vdc controller and compound braking are then derived directly from P0210 (supply voltage): <ul style="list-style-type: none">• Vdc_min switch-on level (r1246) = P1245 * sqrt(2) * P0210• Vdc_max switch-on level (r1242) = 1.15 * sqrt(2) * P0210• Dynamic braking switch-on level = 1.13 * sqrt(2) * P0210• Compound braking switch-on level = 1.13 * sqrt(2) * P0210 Set P1254 ("Auto detect Vdc switch-on levels") = 1. Cut-in levels for Vdc controller and compound braking are then derived from r0070 (DC-link voltage): <ul style="list-style-type: none">• Vdc_min switch-on level (r1246) = P1245 * r0070• Vdc_max switch-on level (r1242) = 1.15 * r0070• Dynamic braking switch-on level = 0.98 * r1242• Compound braking switch-on level = 0.98 * r1242 Auto-detection calculations are only performed when the inverter has been in standby for over 20s. When pulses are enabled, the calculated values are frozen until 20s after pulses cease. | | | | | | | |

Parameter list




7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | |
|--------------------|--|--|-----------------|----------------|---------|----------|-----------|------------|--|--|--|--|--|--|
| Note: | For best results, it is recommended that auto-detection of Vdc switch-on levels (P1254 = 1) is used. Setting P1254 = 0 is only recommended when there is a high degree of fluctuation of the DC-link when the motor is being driven. In this case, ensure the setting of P0210 is correct. If mains voltage is higher than value entered, automatic deactivation of the Vdc controller may occur to avoid acceleration of the motor. A warning will be issued in this case (A910). Default value is depending on inverter type and its rating data. | | | | | | | | | | | | | |
| r0231[0...1] | Maximum cable length [m] | - | - | - | - | - | U16 | 3 | | | | | | |
| | Indexed parameter to display maximum allowable cable length between inverter and motor. | | | | | | | | | | | | | |
| Index: | [0] | Maximum allowed unscreened cable length | | | | | | | | | | | | |
| | [1] | Maximum allowed screened cable length | | | | | | | | | | | | |
| Notice: | For full EMC compliance, the screened cable must not exceed 25 m in length when an EMC filter is fitted. | | | | | | | | | | | | | |
| P0290 | Inverter overload reaction | 0 - 3 | 2 | T | - | - | U16 | 3 | | | | | | |
| | Selects reaction of inverter to an internal thermal overload condition. | | | | | | | | | | | | | |
| | 0 | Reduce output frequency and output current | | | | | | | | | | | | |
| | 1 | No reduction, trip (F4 / 5 / 6) when thermal limits reached | | | | | | | | | | | | |
| | 2 | Reduce pulse frequency, output current and output frequency | | | | | | | | | | | | |
| | 3 | Reduce pulse frequency only and trip (F6) when overload too high | | | | | | | | | | | | |
| Dependency: | Following physical values influence the inverter overload protection (see diagram): <ul style="list-style-type: none">• Heat sink temperature (r0037[0]); causes A504 and F4.• IGBT Junction temperature (r0037[1]); causes F4 or F6.• Delta temperature between heat sink and junction temperature; causes A504 and F6.• Inverter I^2t (r0036); causes A505 and F5. | | | | | | | | | | | | | |
| | <pre> graph LR subgraph InverterMonitoring [Inverter monitoring] direction TB I2t["I²t P0294"] Htemp["Heatsink temperature P0292"] Itemp["IGBT temperature P0292"] I2t --> i_max Htemp --> i_max Itemp --> i_max I2t --> f_pulse Htemp --> f_pulse Itemp --> f_pulse end subgraph P0290 [P0290] direction TB i_max["i_max control"] f_pulse["f_pulse control"] i_max --> A504 i_max --> A505 i_max --> A506 f_pulse --> F4 f_pulse --> F5 f_pulse --> F6 end </pre> | | | | | | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | | | | | | | | | | |
|--------------------|---|----------|-----------------|----------------|---------|----------|-----------|------------|-----|-------------|----------|----------|----|-------------------------|-----|----|----|----------|-----|----|----|----------------------|----|-----|
| Notice: | <p>P0290 = 0, 2:</p> <ul style="list-style-type: none"> Reduction of output frequency is only effective if the load is also reduced. This is for example valid for light overload applications with a quadratic torque characteristic as pumps or fans. For settings P0290 = 0 or 2, the I-max controller will act upon the output current limit (r0067) in case of overtemperature. <p>P0290 = 0:</p> <ul style="list-style-type: none"> With pulse frequencies above nominal, pulse frequency will be reduced to nominal immediately in the event of r0027 greater than r0067 (current limit). <p>P0290 = 2, 3:</p> <ul style="list-style-type: none"> The pulse frequency P1800 is reduced only if higher than 2 kHz and if the operating frequency is below 2 Hz. The actual pulse frequency is displayed in r1801[0] and the minimal pulse frequency for reduction is displayed in r1801[1]. Inverter I²t acts upon output current and output frequency, but not on pulse frequency. A trip will always result, if the action taken does not sufficiently reduce internal temperatures. | | | | | | | | | | | | | | | | | | | | | | | |
| P0291[0...2] | Inverter protection 0 - 6 1 T - DDS U16 4 <table border="1"> <tr> <td>Bit</td> <td>Signal name</td> <td>1 signal</td> <td>0 signal</td> </tr> <tr> <td>00</td> <td>Pulse frequency reduced</td> <td>Yes</td> <td>No</td> </tr> <tr> <td>01</td> <td>Reserved</td> <td>Yes</td> <td>No</td> </tr> <tr> <td>02</td> <td>Phase loss detection</td> <td>No</td> <td>Yes</td> </tr> </table> | | | | | | | | Bit | Signal name | 1 signal | 0 signal | 00 | Pulse frequency reduced | Yes | No | 01 | Reserved | Yes | No | 02 | Phase loss detection | No | Yes |
| Bit | Signal name | 1 signal | 0 signal | | | | | | | | | | | | | | | | | | | | | |
| 00 | Pulse frequency reduced | Yes | No | | | | | | | | | | | | | | | | | | | | | |
| 01 | Reserved | Yes | No | | | | | | | | | | | | | | | | | | | | | |
| 02 | Phase loss detection | No | Yes | | | | | | | | | | | | | | | | | | | | | |
| Note: | See P0290 | | | | | | | | | | | | | | | | | | | | | | | |
| P0292 | Inverter temperature warning [°C] 0 - 25 5 U, T - - U16 3 <p>Defines the temperature difference (in °C) between the overtemperature trip threshold (F4) and the warning threshold (A504) of the inverter. The trip threshold is stored internally by the inverter and cannot be changed by the user.</p> | | | | | | | | | | | | | | | | | | | | | | | |
| P0294 | Inverter I²t warning [%] 10.0 - 100.0 95.0 U, T - - Float 3 <p>Defines the [%] value at which warning A505 (inverter I²t) is generated. Inverter I²t calculation is used to determine a maximum tolerable period for inverter overload. The I²t calculation value is deemed = 100 % when this maximum tolerable period is reached.</p> | | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | <ul style="list-style-type: none"> The output current of the inverter has been reduced. The value of I²t does not exceed 100 %. | | | | | | | | | | | | | | | | | | | | | | | |
| Note: | P0294 = 100 % corresponds to stationary nominal load. | | | | | | | | | | | | | | | | | | | | | | | |
| P0295 | Inverter fan off delay time [s] 0 - 3600 0 U, T - - U16 3 <p>Defines inverter fan switch off delay time in seconds after inverter has stopped.</p> | | | | | | | | | | | | | | | | | | | | | | | |
| Note: | Setting to 0, inverter fan will switch off when the inverter stops, that means no delay. | | | | | | | | | | | | | | | | | | | | | | | |
| P0304[0...2] | Rated motor voltage [V] 10 - 2000 400 C(1) - DDS U16 1 <p>Nominal motor voltage from rating plate.</p> | | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | Changeable only when P0010 = 1 (quick commissioning). Default value is depending on inverter type and its rating data. | | | | | | | | | | | | | | | | | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|-----------------|-----------------|----------------|---------|----------|-----------|------------|
| Caution: | The input of rating plate data must correspond with the wiring of the motor (star / delta). This means, if delta wiring is used for the motor, delta rating plate data has to be entered. IEC Motor | | | | | | | |
| |  | | | | | | | |
| Note: | Following diagram shows a typical rating plate with the locations of the relevant motor data. | | | | | | | |
| |  | | | | | | | |
| P0305[0...2] | Rated motor current [A] | 0.01 - 10000.00 | 1.86 | C(1) | - | DDS | Float | 1 |
| | Nominal motor current from rating plate. | | | | | | | |
| Dependency: | Changeable only when P0010 = 1 (quick commissioning). Depends also on P0320 (motor magnetization current). | | | | | | | |
| Note: | <p>The maximum value of P0305 depends on the maximum inverter current r0209 and the motor type: Asynchronous motor : P0305_max = P0209 It is recommended that the ratio of P0305 (rated motor current) and r0207 (rated inverter current) should not be lower than: $(1 / 8) \leq (P0305 / r0207)$ When the relation of the nominal motor current P0305 and half of the maximal inverter current (r0209) exceeds 1.5 an additional current derating is applied. This is necessary to protect the inverter from harmonic current waves.</p>  | | | | | | | |
| | Default value is depending on inverter type and its rating data. | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|----------------|-----------------|----------------|---------|----------|-----------|------------|
| P0307[0...2] | Rated motor power | 0.01 - 2000.00 | 0.75 | C(1) | - | DDS | Float | 1 |
| | Nominal motor power [kW / hp] from rating plate. | | | | | | | |
| Dependency: | If P0100 = 1, values will be in [hp]. Changeable only when P0010 = 1 (quick commissioning). | | | | | | | |
| Note: | Default value is depending on inverter type and its rating data. | | | | | | | |
| P0308[0...2] | Rated motor cosφ | 0.000 - 1.000 | 0.000 | C(1) | - | DDS | Float | 1 |
| | Nominal motor power factor ($\cos\phi$) from rating plate. | | | | | | | |
| Dependency: | Changeable only when P0010 = 1 (quick commissioning). Visible only when P0100 = 0 or 2, (motor power entered in [kW]). Setting 0 causes internal calculation of value. The value is displayed in r0332. | | | | | | | |
| P0309[0...2] | Rated motor efficiency [%] | 0.0 - 99.9 | 0.0 | C(1) | - | DDS | Float | 1 |
| | Nominal motor efficiency from rating plate. | | | | | | | |
| Dependency: | Changeable only when P0010 = 1 (quick commissioning). Visible only when P0100 = 1, (i.e. motor power entered in [hp]). Setting 0 causes internal calculation of value. The value is displayed in r0332. | | | | | | | |
| P0310[0...2] | Rated motor frequency [Hz] | 12.00 - 599.00 | 50.00 | C(1) | - | DDS | Float | 1 |
| | Nominal motor frequency from rating plate. | | | | | | | |
| Dependency: | Changeable only when P0010 = 1 (quick commissioning). Pole pair number recalculated automatically if parameter is changed. | | | | | | | |
| Note: | Changes to P0310 can influence the maximum motor frequency. For further information see P1082. | | | | | | | |
| P0311[0...2] | Rated motor speed [RPM] | 0 - 40000 | 1395 | C(1) | - | DDS | U16 | 1 |
| | Nominal motor speed from rating plate. | | | | | | | |
| Dependency: | Changeable only when P0010 = 1 (quick commissioning). Setting 0 causes internal calculation of value. Slip compensation in V/f control requires rated motor speed for correct operation. Pole pair number recalculated automatically if parameter is changed. | | | | | | | |
| Note: | Default value is depending on inverter type and its rating data. | | | | | | | |
| r0313[0...2] | Motor pole pairs | - | - | - | - | DDS | U16 | 3 |
| | Displays number of motor pole pairs that the inverter is currently using for internal calculations. | | | | | | | |
| Dependency: | Recalculated automatically when P0310 (rated motor frequency) or P0311 (rated motor speed) is changed. r0313 = 1: 2-pole motor r0313 = 2: 4-pole motor ... | | | | | | | |
| P0314[0...2] | Motor pole pair number | 0 - 99 | 0 | C(1) | - | DDS | U16 | 3 |
| | Specifies number of pole pairs of motor. | | | | | | | |
| Dependency: | Changeable only when P0010 = 1 (quick commissioning). Setting 0 causes r0313 (calculated motor pole pairs) to be used during operation. Setting to > 0 overrides r0313. P0314 = 1: 2-pole motor P0314 = 2: 4-pole motor ... | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|--|-----------------|----------------|-----------|-----------|-----------|------------|
| P0320[0...2] | Motor magnetizing current [%] | 0.0 - 99.0 | 0.0 | C(1), T | - | DDS | Float | 3 |
| | Defines motor magnetization current relative to P0305 (rated motor current). | | | | | | | |
| Dependency: | Setting 0 causes calculation by P0340 = 1 (data entered from rating plate) or by P3900 = 1 - 3 (end of quick commissioning). The calculated value is displayed in r0331. | | | | | | | |
| r0330[0...2] | Rated motor slip [%] | - | - | - | PERCENT | DDS | Float | 3 |
| | Displays nominal motor slip relative to P0310 (rated motor frequency) and P0311 (rated motor speed). r0330[%] = ((P0310 - r0313 * (P0311 / 60)) / P0310) * 100% | | | | | | | |
| r0331[0...2] | Rated magnetization current [A] | - | - | - | - | DDS | Float | 3 |
| | Displays calculated magnetizing current of motor. | | | | | | | |
| r0332[0...2] | Rated power factor | - | - | - | - | DDS | Float | 3 |
| | Displays power factor for motor. | | | | | | | |
| Dependency: | Value is calculated internally if P0308 (rated motor cosφ) set to 0; otherwise, value entered in P0308 is displayed. | | | | | | | |
| r0333[0...2] | Rated motor torque [Nm] | - | - | - | - | DDS | Float | 3 |
| | Displays rated motor torque. | | | | | | | |
| Dependency: | Value is calculated from P0307 (rated motor power) and P0311 (rated motor speed). r0333[Nm] = (P0307[kW] * 1000) / ((P0311[1 / min] / 60) * 2 * Pi) | | | | | | | |
| P0335[0...2] | Motor cooling | 0 - 3 | 0 | C(1), T | - | DDS | U16 | 2 |
| | Selects motor cooling system used. | | | | | | | |
| | 0 | Self-cooled: Shaft mounted fan attached motor (IC410 or IC411) | | | | | | |
| | 1 | Force-cooled: Separately powered cooling fan (IC416) | | | | | | |
| | 2 | Self-cooled and internal fan | | | | | | |
| | 3 | Force-cooled and internal fan | | | | | | |
| P0340[0...2] | Calculation of motor parameters | 0 - 4 | 0 | T | - | DDS | U16 | 2 |
| | Calculates various motor parameters. | | | | | | | |
| | | | | P0340 = 1 | P0340 = 2 | P0340 = 3 | P0340 = 4 | |
| | P0341[0...2] Motor inertia [kg*m^2] | | | x | | | | |
| | P0342[0...2] Total / motor inertia ratio | | | x | | | | |
| | P0344[0...2] Motor weight | | | x | | | | |
| | P0346[0...2] Magnetization time | | | x | | x | | |
| | P0347[0...2] Demagnetization time | | | x | | x | | |
| | P0350[0...2] Stator resistance (line-to-line) | | | x | x | | | |
| | P0352[0...2] Cable resistance | | | x | x | | | |
| | P0354[0...2] Rotor resistance | | | x | x | | | |
| | P0356[0...2] Stator leakage inductance | | | x | x | | | |
| | P0358[0...2] Rotor leakage inductance | | | x | x | | | |
| | P0360[0...2] Main inductance | | | x | x | | | |
| | P0625[0...2] Ambient motor temperature | | | x | x | | | |
| | P1253[0...2] Controller output limitation | | | x | | x | | |
| | P1316[0...2] Boost end frequency | | | x | | x | | |
| | P1338[0...2] Resonance damping gain V/f | | | x | | x | | x |
| | P1341[0...2] I _{max} controller integral time | | | x | | x | | x |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|---|---|-----------------|----------------|---------|----------|-----------|------------|
| | P1345[0...2] Imax voltage ctrl. prop. gain | | x | | | x | | x |
| | P1346[0...2] Imax voltage ctrl. integral time | | x | | | x | | x |
| | P2002[0...2] Reference current | | x | | | | | |
| | P2003[0...2] Reference torque | | x | | | | | |
| | P2185[0...2] Upper torque threshold 1 | | x | | | | | |
| | P2187[0...2] Upper torque threshold 2 | | x | | | | | |
| | P2189[0...2] Upper torque threshold 3 | | x | | | | | |
| | 0 | No calculation | | | | | | |
| | 1 | Complete parameterization | | | | | | |
| | 2 | Calculation of equivalent circuit data | | | | | | |
| | 3 | Calculation of V/f control data | | | | | | |
| | 4 | Calculation of controller settings only | | | | | | |
| Note: | <p>This parameter is required during commissioning to optimize inverter performance. If there is a large mismatch in Power ratings of Inverter to Motor it is possible that r0384 and r0386 may not be calculated correctly. In these cases use P1900.</p> <p>When transferring P0340, the inverter uses its processor to carry out internal calculations. Communications to the inverter may be interrupted.</p> <p>The faults can be acknowledged as soon as the calculations have been completed in the inverter. These calculations can take approximately 10s to complete.</p> | | | | | | | |
| P0341[0...2] | Motor inertia [kg*m^2] | 0.0001 - 1000.0 | 0.0018 | U, T | - | DDS | Float | 3 |
| | <p>Sets no-load inertia of motor.</p> <p>Together with P0342 (inertia ratio total / motor) and P1496 (scaling factor acceleration), this value produces the acceleration torque (r1518), which can be added to any additional torque produced from a BICO source (P1511), and incorporated in the torque control function.</p> | | | | | | | |
| Dependency: | This parameter is influenced by automatic calculations defined by P0340. | | | | | | | |
| Note: | <p>The result of P0341 * P0342 is included in the speed controller calculation.</p> <p>P0341 * P0342 = total motor inertia</p> <p>P1496 = 100 % activates acceleration pre-control for the speed controller and calculates the torque from P0341 and P0342.</p> | | | | | | | |
| P0342[0...2] | Total / motor inertia ratio | 1.000 - 400.00 | 1.000 | U, T | - | DDS | Float | 3 |
| | Specifies ratio between total inertia (load + motor) and motor inertia. | | | | | | | |
| Dependency: | See P0341 | | | | | | | |
| P0344[0...2] | Motor weight [kg] | 1.0 - 6500.0 | 9.4 | U, T | - | DDS | Float | 3 |
| | Specifies motor weight [kg]. | | | | | | | |
| Dependency: | See P0341 | | | | | | | |
| Note: | This value is used in the motor thermal model. It is normally calculated automatically from P0340 (motor parameters) but can also be entered manually. Default value is depending on inverter type and its rating data. | | | | | | | |
| r0345[0...2] | Motor start-up time [s] | - | - | - | - | DDS | Float | 3 |
| | Displays motor start-up time. This time corresponds to the standardized motor inertia. The start-up time is the time taken to reach rated motor speed from standstill at acceleration with rated motor torque (r0333). | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|-----------------|-----------------|----------------|---------|----------|-----------|------------|
| P0346[0...2] | Magnetization time [s] | 0.000 - 20.000 | 1.000 | U, T | - | DDS | Float | 3 |
| | Sets magnetization time [s], i.e. waiting time between pulse enable and start of ramp-up. Motor magnetization builds up during this time. Magnetization time is normally calculated automatically from the motor data and corresponds to the rotor time constant. | | | | | | | |
| Dependency: | See P0341 | | | | | | | |
| Notice: | An excessive reduction of this time can result in insufficient motor magnetization. | | | | | | | |
| Note: | If boost settings are higher than 100 %, magnetization time may be reduced. Default value is depending on inverter type and its rating data. | | | | | | | |
| P0347[0...2] | Demagnetization time [s] | 0.000 - 20.000 | 1.000 | U, T | - | DDS | Float | 3 |
| | Changes time allowed after OFF2 / fault condition, before pulses can be re-enabled. | | | | | | | |
| Dependency: | See P0341 | | | | | | | |
| Note: | The demagnetization time is approximately 2.5 x rotor time constant in seconds. Default value is depending on inverter type and its rating data. | | | | | | | |
| P0350[0...2] | Stator resistance (line) [Ohm] | 0.0000 - 2000.0 | 2.0000 | U, T | - | DDS | Float | 3 |
| | Stator resistance value for connected motor (line value). The parameter value doesn't include the cable resistance. | | | | | | | |
| Dependency: | See P0341 | | | | | | | |
| Note: | <p>There are three ways to determine the value for this parameter:</p> <ol style="list-style-type: none"> Calculate using <ul style="list-style-type: none"> P0340 = 1 (data entered from rating plate) or P0010 = 1, P3900 = 1, 2 or 3 (end of quick commissioning). Measure using P1900 = 2 (standard motor data identification - value for stator resistance is overwritten). Measure manually using an Ohmmeter. <p>Since the manually measured resistor is a line-to-line value, which includes the cable resistors, the measured value has to be divided by two and the cable resistor of a line has to be subtracted from that value.</p> <p>The value entered in P0350 is the one obtained by the method last used. Default value is depending on inverter type and its rating data.</p> | | | | | | | |
| P0352[0...2] | Cable resistance [Ohm] | 0.0 - 120.0 | 0.0 | U, T | - | DDS | Float | 3 |
| | Describes cable resistance between inverter and motor for one phase. The value corresponds to the resistance of the cable between the inverter and the motor, relative to the rated impedance. | | | | | | | |
| Dependency: | See P0341 | | | | | | | |
| P0354[0...2] | Rotor resistance [Ohm] | 0.0 - 300.0 | 10.0 | U, T | - | DDS | Float | 3 |
| | Sets rotor resistance of motor equivalent circuit (phase value). | | | | | | | |
| Dependency: | Calculated automatically using the motor model or determined using P1900 (motor identification). This parameter is influenced by automatic calculations defined by P0340. | | | | | | | |
| P0356[0...2] | Stator leakage inductance [mH] | 0.0000 - 1000.0 | 10.000 | U, T | - | DDS | Float | 3 |
| | Sets stator leakage inductance of motor equivalent circuit (phase value). | | | | | | | |
| Dependency: | See P0354 | | | | | | | |
| P0358[0...2] | Rotor leakage inductance [mH] | 0.0 - 1000.0 | 10.0 | U, T | - | DDS | Float | 3 |
| | Sets rotor leakage inductance of motor equivalent circuit (phase value). | | | | | | | |
| Dependency: | See P0354 | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | |
|--------------------|--|----------------------------|-----------------|----------------|---------|----------|-----------|------------|--|
| P0360[0...2] | Main inductance [mH] | 0.0 - 10000.0 | 10.0 | U, T | - | DDS | Float | 3 | |
| | Sets main inductance of the motor equivalent circuit (phase value). | | | | | | | | |
| Dependency: | See P0354 | | | | | | | | |
| Caution: | The data of equivalent circuit relates to the star equivalent circuit. Any data of the delta equivalent circuit available therefore must be transformed to the star equivalent circuit before entering into the inverter. | | | | | | | | |
| r0370[0...2] | Stator resistance [%] | - | - | - | PERCENT | DDS | Float | 4 | |
| | Displays standardized stator resistance of motor equivalent circuit (phase value). | | | | | | | | |
| r0372[0...2] | Cable resistance [%] | - | - | - | PERCENT | DDS | Float | 4 | |
| | Displays standardized cable resistance of motor equivalent circuit (phase value). It is estimated to be 20 % of the stator resistance. | | | | | | | | |
| r0373[0...2] | Rated stator resistance [%] | - | - | - | PERCENT | DDS | Float | 4 | |
| | Displays rated stator resistance of the motor equivalent circuit (phase value). | | | | | | | | |
| r0374[0...2] | Rotor resistance [%] | - | - | - | PERCENT | DDS | Float | 4 | |
| | Displays standardized rotor resistance of the motor equivalent circuit (phase value). | | | | | | | | |
| r0376[0...2] | Rated rotor resistance [%] | - | - | - | PERCENT | DDS | Float | 4 | |
| | Displays rated rotor resistance of the motor equivalent circuit (phase value). | | | | | | | | |
| r0377[0...2] | Total leakage reactance [%] | - | - | - | PERCENT | DDS | Float | 4 | |
| | Displays standardized total leakage reactance of the motor equivalent circuit (phase value). | | | | | | | | |
| r0382[0...2] | Main reactance [%] | - | - | - | PERCENT | DDS | Float | 4 | |
| | Displays standardized main reactance of the motor equivalent circuit (phase value). | | | | | | | | |
| r0384[0...2] | Rotor time constant [ms] | - | - | - | - | DDS | Float | 3 | |
| | Displays calculated rotor time constant. | | | | | | | | |
| r0386[0...2] | Total leakage time constant [ms] | - | - | - | - | DDS | Float | 4 | |
| | Displays total leakage time constant of motor. | | | | | | | | |
| r0395 | CO: Total stator resistance [%] | - | - | - | PERCENT | - | Float | 3 | |
| | Displays stator resistance of motor of combined stator / cable resistance. | | | | | | | | |
| P0503[0...2] | Enable Keep-running Operation | 0 - 1 | 0 | T | - | - | U16 | 3 | |
| | Enables keep-running operation. This attempts to prevent the inverter from tripping by enabling all possible existing de-rating features, and the automatic restart function. May be used with P2113 = 1 to mask resulting warnings from the user. | | | | | | | | |
| | 0 | Keep-running mode disabled | | | | | | | |
| | 1 | Keep-running mode enabled | | | | | | | |
| Index: | [0] | Inverter data set 0 (DDS0) | | | | | | | |
| | [1] | Inverter data set 1 (DDS1) | | | | | | | |
| | [2] | Inverter data set 2 (DDS2) | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|---|------------------------------------|----------------------------------|----------------|---------|----------|-----------|------------|
| Notice: | P0503 = 1 Sets the following parameter values to minimize likelihood of a trip: <ul style="list-style-type: none">• P0290 = 2• P1210 = 7• P1211 = 10• P1240 = 3 P0503 = 0 Resets the parameters to their default values: <ul style="list-style-type: none">• P0290 = 2• P1210 = 1• P1211 = 3• P1240 = 1 | | | | | | | |
| Note: | See also: <ul style="list-style-type: none">• P0290• P1210• P1211• P1240• P2113 | | | | | | | |
| P0507 | Application macro | 0 - 255 | 0 | C(1) | - | - | U16 | 1 |
| | Selects a given Application macro, which is a set of parameter values for a given application. There are a number of application macros covering a set of basic applications such as simple pump, conveyor, compressor etc. | | | | | | | |
| Note: | Please note that to guarantee correct setting of the Application macro, the Application macro number should only be changed during Setup directly after a parameter reset. | | | | | | | |
| P0511[0..2] | Scaling for display | 0.00 - 100.00 | [0] 1.00 [1] 1.00 [2] 0.00 | U, T | - | - | Float | 3 |
| | Allows operator to enter the scaling factors for the display of motor frequency. Index 0 = value of multiplier (a) Index 1 = value of divisor (b) Index 2 = value of constant (c) With the parameter set to a non-default value the displayed value for frequency and setpoint on internal and external BOPs is scaled accordingly. Note - the units "Hz" is no longer displayed if the value is scaled. The formula used to scale the display is: (a / b)*N + c. | | | | | | | |
| Index: | [0] | Multiplier for Scaling for display | | | | | | |
| | [1] | Divider for Scaling for display | | | | | | |
| | [2] | Constant for Scaling for display | | | | | | |
| r0512 | CO: Scaled filtered frequency | - | - | - | - | - | Float | 2 |
| | Displays actual inverter output frequency (r0024) excluding slip compensation (and resonance damping, frequency limitation in V/f mode). | | | | | | | |
| P0604[0..2] | Threshold motor temperature [°C] | 0.0 - 200.0 | 130.0 | U, T | - | DDS | Float | 2 |
| | Enters warning threshold for motor temperature protection. The trip temperature defined is always 10 % higher than the warning threshold P0604. When actual motor temperature exceeds warning temperature then inverter reacts as defined in P0610. | | | | | | | |
| Dependency: | This value should be at least 40°C higher than the motor ambient temperature P0625. | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | |
|--------------------|---|--|-----------------|----------------|---------|----------|-----------|------------|--|
| P0610[0...2] | Motor I²t temperature reaction | 0 - 6 | 6 | T | - | DDS | U16 | 3 | |
| | Defines reaction when motor temperature reaches warning threshold. | | | | | | | | |
| | 0 | Warning only. Does not recall the motor temperature (stored at power down) on power up | | | | | | | |
| | 1 | Warning with Imax control (motor current reduced) and trip (F11). Does not recall the motor temperature (stored at power down) on power up | | | | | | | |
| | 2 | Warning and trip (F11). Does not recall the motor temperature (stored at power down) on power up | | | | | | | |
| | 4 | Warning only. Recalls the motor temperature (stored at power down) on power up | | | | | | | |
| | 5 | Warning with Imax control (motor current reduced) and trip (F11). Recalls the motor temperature (stored at power down) on power up | | | | | | | |
| | 6 | Warning and trip (F11). Recalls the motor temperature (stored at power down) on power up | | | | | | | |
| Dependency: | Trip level = P0604 (motor temperature threshold) * 110 % | | | | | | | | |
| Note: | <ul style="list-style-type: none"> P0610 = 0 (No reaction, warning only) <p>When temperature reaches warning level defined in P0604, the inverter displays warning A511, no reaction is done.</p> <ul style="list-style-type: none"> P0610 = 1 (Warning, Imax reduction and Trip) <p>When temperature reaches warning level defined in P0604, the inverter displays warning A511, reduce frequency and trips F11, when temperature exceeds the trip level.</p> <ul style="list-style-type: none"> P0610 = 2 (Warning and trip F11) <p>When temperature reaches warning level defined in P0604, the inverter displays warning A511 and trips F11, when temperature exceeds the trip level.</p> <p>The purpose of motor I²t is to calculate the motor temperature and disable the inverter if the motor is in danger of overheating.</p> <p>I²t operation:</p> <p>The measured motor current is displayed in r0027. The motor temperature in °C is displayed in r0035. This temperature is derived from a calculated value using motor thermal model.</p> <p>The reaction to the warning can be changed from this default using P0610.</p> <p>r0035 is particularly useful to monitor if the calculated motor temperature is rising excessively.</p> | | | | | | | | |
| P0622[0...2] | Magnetizing time for temp id after start up [ms] | 0.000 - 20000 | 0.000 | U, T | - | DDS | Float | 3 | |
| | Specifies the magnetization time for stator resistance identification. | | | | | | | | |
| r0623[0...2] | CO: Display for the identified stator resistance [Ohm] | - | - | - | - | DDS | Float | 4 | |
| | Display of the actual identified stator resistance after temperature identification. | | | | | | | | |
| P0625[0...2] | Ambient motor temperature [°C] | -40.0 - 80.0 | 20.0 | C(1), U, T | - | DDS | Float | 3 | |
| | Ambient temperature of motor at time of motor data identification. It is only allowed to change the value when the motor is cold. A motor identification has to be made after changing the value. | | | | | | | | |
| Dependency: | This parameter is influenced by automatic calculations defined by P0340. | | | | | | | | |
| P0626[0...2] | Overtemperature stator iron [°C] | 20.0 - 200.0 | 50.0 | U, T | - | DDS | Float | 4 | |
| | Overtemperature of stator iron. | | | | | | | | |

Parameter list

7.2 Parameter list



| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | |
|--------------------|--|-------------------------|-----------------|----------------|---------|----------|-----------|------------|--|--|--|--|--|--|--|
| Note: | Temperature rises are valid for sinusoidal operations (line supply temperature rises). Temperature rises due to inverter operation (modulation losses) and output filter are also considered. | | | | | | | | | | | | | | |
| P0627[0...2] | Overtemperature stator winding [°C] | 20.0 - 200.0 | 80.0 | U, T | - | DDS | Float | 4 | | | | | | | |
| | Overtemperature of the stator winding. It is only allowed to change the value when the motor is cold. A motor identification has to be made after changing the value. | | | | | | | | | | | | | | |
| Note: | See P0626 | | | | | | | | | | | | | | |
| P0628[0...2] | Overtemperature rotor winding [°C] | 20.0 - 200.0 | 100.0 | U, T | - | DDS | Float | 4 | | | | | | | |
| | Overtemperature of the rotor winding. | | | | | | | | | | | | | | |
| Note: | See P0626 | | | | | | | | | | | | | | |
| r0630[0...2] | CO: Motor model ambient temp. [°C] | - | - | - | - | DDS | Float | 4 | | | | | | | |
| | Displays ambient temperature of motor mass model. | | | | | | | | | | | | | | |
| r0631[0...2] | CO: Stator iron temperature [°C] | - | - | - | - | DDS | Float | 4 | | | | | | | |
| | Displays iron temperature of motor mass model. | | | | | | | | | | | | | | |
| r0632[0...2] | CO: Stator winding temperature [°C] | - | - | - | - | DDS | Float | 4 | | | | | | | |
| | Displays stator winding temperature of motor mass model. | | | | | | | | | | | | | | |
| r0633[0...2] | CO: Rotor winding temperature [°C] | - | - | - | - | DDS | Float | 4 | | | | | | | |
| | Displays rotor winding temperature of motor mass model. | | | | | | | | | | | | | | |
| P0640[0...2] | Motor overload factor [%] | 10.0 - 400.0 | 150.0 | C(1), U, T | - | DDS | Float | 2 | | | | | | | |
| | Defines motor overload current limit relative to P0305 (rated motor current). | | | | | | | | | | | | | | |
| Dependency: | Limited to maximum inverter current or to 400 % of rated motor current (P0305), whichever is the lower. P0640_max = (min(r0209, 4 * P0305) / P0305) * 100 | | | | | | | | | | | | | | |
| Note: | Changes to P0640 will be effective only after the next off state. | | | | | | | | | | | | | | |
| P0700[0...2] | Selection of command source | 0 - 5 | 1 | C(1), T | - | CDS | U16 | 1 | | | | | | | |
| | Selects digital command source. | | | | | | | | | | | | | | |
| | 0 | Factory default setting | | | | | | | | | | | | | |
| | 1 | Operator panel (keypad) | | | | | | | | | | | | | |
| | 2 | Terminal | | | | | | | | | | | | | |
| | 5 | USS / MBUS on RS485 | | | | | | | | | | | | | |
| Dependency: | Changing this parameter sets (to default) all settings on item selected. These are the following parameters: P0701, ... (function of DI), P0840, P0842, P0844, P0845, P0848, P0849, P0852, P1020, P1021, P1022, P1023, P1035, P1036, P1055, P1056, P1074, P1110, P1113, P1124, P1140, P1141, P1142, P1230, P2103, P2104, P2106, P2200, P2220, P2221, P2222, P2223, P2235, P2236 | | | | | | | | | | | | | | |
| Caution: | Be aware, by changing of P0700 all BI parameters are reset to the default value. | | | | | | | | | | | | | | |
| Note: | RS485 also supports MODBUS protocol as well as USS. All USS options on RS485 are also applicable to MODBUS. | | | | | | | | | | | | | | |
| P0701[0...2] | Function of digital input 1 | 0 - 99 | 0 | T | - | CDS | U16 | 2 | | | | | | | |
| | Selects function of digital input 1. | | | | | | | | | | | | | | |
| | 0 | Digital input disabled | | | | | | | | | | | | | |
| | 1 | ON / OFF1 | | | | | | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|----------------------------------|-----------------|----------------|---------|----------|-----------|------------|
| | 2 | ON reverse / OFF1 | | | | | | |
| | 3 | OFF2 - coast to standstill | | | | | | |
| | 4 | OFF3 - quick ramp-down | | | | | | |
| | 9 | Fault acknowledge | | | | | | |
| | 10 | JOG right | | | | | | |
| | 11 | JOG left | | | | | | |
| | 12 | Reverse | | | | | | |
| | 13 | MOP up (increase frequency) | | | | | | |
| | 14 | MOP down (decrease frequency) | | | | | | |
| | 15 | Fixed frequency selector bit0 | | | | | | |
| | 16 | Fixed frequency selector bit1 | | | | | | |
| | 17 | Fixed frequency selector bit2 | | | | | | |
| | 18 | Fixed frequency selector bit3 | | | | | | |
| | 22 | QuickStop Source 1 | | | | | | |
| | 23 | QuickStop Source 2 | | | | | | |
| | 24 | QuickStop Override | | | | | | |
| | 25 | DC brake enable | | | | | | |
| | 27 | Enable PID | | | | | | |
| | 29 | External trip | | | | | | |
| | 33 | Disable additional freq setpoint | | | | | | |
| | 99 | Enable BICO parameterization | | | | | | |
| Dependency: | Setting 99 (enable BICO parameterization) requires: | | | | | | | |
| | <ul style="list-style-type: none"> • P0700 command source or • P0010 = 1, P3900 = 1, 2 or 3 (quick commissioning) or • P0010 = 30, P0970 = 1 factory reset in order to reset | | | | | | | |
| Note: | "ON / OFF1" can only be selected for one digital input (e.g. P0700 = 2 and P0701 = 1). Configuring DI2 with P0702 = 1 will disable DI1 by setting P0701 = 0. Only the last activated digital input serves as a command source. "ON / OFF1" on a digital input can be combined with "ON reverse / OFF1" on another digital input. | | | | | | | |
| P0702[0...2] | Function of digital input 2 | 0 - 99 | 0 | T | - | CDS | U16 | 2 |
| | Selects function of digital input 2. See P0701. | | | | | | | |
| P0703[0...2] | Function of digital input 3 | 0 - 99 | 9 | T | - | CDS | U16 | 2 |
| | Selects function of digital input 3. See P0701. | | | | | | | |
| P0704[0...2] | Function of digital input 4 | 0 - 99 | 15 | T | - | CDS | U16 | 2 |
| | Selects function of digital input 4. See P0701. | | | | | | | |
| P0712 [0...2] | Analog / digital input 1 | 0 - 99 | 0 | T | - | CDS | U16 | 2 |
| | Selects function of digital input AI1 (via analog input). See P0701. | | | | | | | |
| Note: | See P0701. Signals above 4 V are active; signals below 1.6 V are inactive. | | | | | | | |
| P0713[0...2] | Analog / digital input 2 | 0 - 99 | 0 | T | - | CDS | U16 | 2 |
| | Selects function of digital input AI2 (via analog input). See P0701. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | |
|--------------------|---|---|-----------------|----------------|---------|----------|-----------|------------|--|--|--|--|--|--|--|
| Note: | See P0701. Signals above 4 V are active; signals below 1.6 V are inactive. | | | | | | | | | | | | | | |
| P0717 | Connection macro | 0 - 255 | 0 | C(1) | - | - | U16 | 1 | | | | | | | |
| | Selects a given connection macro, which is a set of parameter values for a given set of control connections. There are a number of connection macros which define basic control connection settings such as Terminals, BOP, PID with analog setpoint etc. | | | | | | | | | | | | | | |
| Note: | Please note that to guarantee correct setting of the Connection macro, the Connection macro number should only be changed during Setup directly after a parameter reset. | | | | | | | | | | | | | | |
| P0719[0...2] | Selection of command & frequency setpoint | 0 - 57 | 0 | T | - | CDS | U16 | 4 | | | | | | | |
| | Central switch to select control command source for inverter. Switches command and setpoint source between freely programmable BICO parameters and fixed command / setpoint profiles. Command and setpoint sources can be changed independently. The tens digit chooses the command source and the units digit chooses the setpoint source. | | | | | | | | | | | | | | |
| | 0 | Cmd = BICO parameter, Setpoint = BICO parameter | | | | | | | | | | | | | |
| | 1 | Cmd = BICO parameter, Setpoint = MOP setpoint | | | | | | | | | | | | | |
| | 2 | Cmd = BICO parameter, Setpoint = Analog setpoint | | | | | | | | | | | | | |
| | 3 | Cmd = BICO parameter, Setpoint = Fixed frequency | | | | | | | | | | | | | |
| | 4 | Cmd = BICO parameter, Setpoint = USS on RS232 (reserved) | | | | | | | | | | | | | |
| | 5 | Cmd = BICO parameter, Setpoint = USS on RS485 | | | | | | | | | | | | | |
| | 7 | Cmd = BICO parameter, Setpoint = Analog setpoint 2 | | | | | | | | | | | | | |
| | 40 | Cmd = USS on RS232 (reserved), Setpoint = BICO parameter | | | | | | | | | | | | | |
| | 41 | Cmd = USS on RS232 (reserved), Setpoint = MOP setpoint | | | | | | | | | | | | | |
| | 42 | Cmd = USS on RS232 (reserved), Setpoint = Analog setpoint | | | | | | | | | | | | | |
| | 43 | Cmd = USS on RS232 (reserved), Setpoint = Fixed frequency | | | | | | | | | | | | | |
| | 44 | Cmd = USS on RS232 (reserved), Setpoint = USS on RS232 (reserved) | | | | | | | | | | | | | |
| | 45 | Cmd = USS on RS232 (reserved), Setpoint = USS on RS485 | | | | | | | | | | | | | |
| | 47 | Cmd = USS on RS232 (reserved), Setpoint = Analog setpoint 2 | | | | | | | | | | | | | |
| | 50 | Cmd = USS on RS485, Setpoint = BICO parameter | | | | | | | | | | | | | |
| | 51 | Cmd = USS on RS485, Setpoint = MOP setpoint | | | | | | | | | | | | | |
| | 52 | Cmd = USS on RS485, Setpoint = Analog setpoint | | | | | | | | | | | | | |
| | 53 | Cmd = USS on RS485, Setpoint = Fixed frequency | | | | | | | | | | | | | |
| | 54 | Cmd = USS on RS485, Setpoint = USS on RS232 (reserved) | | | | | | | | | | | | | |
| | 55 | Cmd = USS on RS485, Setpoint = USS on RS485 | | | | | | | | | | | | | |
| | 57 | Cmd = USS on RS485, Setpoint = Analog setpoint 2 | | | | | | | | | | | | | |
| Dependency: | P0719 has higher priority than P0700 and P1000. If set to a value other than 0 (i.e. BICO parameter is not the setpoint source), P0844 / P0848 (first source of OFF2 / OFF3) are not effective; instead, P0845 / P0849 (second source of OFF2 / OFF3) apply and the OFF commands are obtained via the particular source defined. BICO connections made previously remain unchanged. | | | | | | | | | | | | | | |
| Notice: | Particularly useful when e.g. changing command source temporarily from P0700 = 2. Settings in P0719 (contrary to P0700 settings) do not reset the digital inputs (P0701, P0702, ...) | | | | | | | | | | | | | | |
| r0720 | Number of digital inputs | - | - | - | - | - | U16 | 3 | | | | | | | |
| | Displays number of digital inputs. | | | | | | | | | | | | | | |
| r0722.0...12 | CO / BO: Digital input values | - | - | - | - | - | U16 | 2 | | | | | | | |
| | Displays status of digital inputs. | | | | | | | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------|--|-----------------------|-----------------|----------------|---------|----------|-----------|------------|
| | Bit | Signal name | | | | | 1 signal | 0 signal |
| | 00 | Digital input 1 | | | | | Yes | No |
| | 01 | Digital input 2 | | | | | Yes | No |
| | 02 | Digital input 3 | | | | | Yes | No |
| | 03 | Digital input 4 | | | | | Yes | No |
| | 11 | Analog input 1 | | | | | Yes | No |
| | 12 | Analog input 2 | | | | | Yes | No |
| Note: | Segment is lit when signal is active. | | | | | | | |
| P0724 | Debounce time for digital inputs | 0 - 3 | 3 | T | - | - | U16 | 3 |
| | Defines debounce time (filtering time) used for digital inputs. | | | | | | | |
| | 0 | No debounce time | | | | | | |
| | 1 | 2.5 ms debounce time | | | | | | |
| | 2 | 8.2 ms debounce time | | | | | | |
| | 3 | 12.3 ms debounce time | | | | | | |
| P0727[0...2] | Selection of 2 / 3-wire method | 0 - 3 | 0 | C(1), T | - | CDS | U16 | 2 |
| | Determines the control method using the terminals. This parameter allows the selection of the control philosophy. The control philosophies exclude each other. | | | | | | | |
| | 2 / 3-wire control allows to start, stop and reverse the inverter in one of the following ways: | | | | | | | |
| | <ul style="list-style-type: none"> • 2-wire control with Siemens standard control using ON / OFF1 and REV as permanent signals  | | | | | | | |
| | <ul style="list-style-type: none"> • 2-wire control with Siemens standard control using ON / OFF1 and ON_REV / OFF1 as permanent signals  | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|-----------|--|-------|-----------------------|----------------|---------|----------|-----------|------------|
| | <ul style="list-style-type: none"> 2-wire control using ON_FWD and ON_REV as permanent signals | | | | | | | |
| | <ul style="list-style-type: none"> 3-wire control using STOP as permanent signal, FWD and REV as pulses | | | | | | | |
| | <ul style="list-style-type: none"> 3-wire control using OFF1 / HOLD and REV as permanent signal, ON as pulse signal | | | | | | | |
| | 0 | | Siemens (start / dir) | | | | | |
| | 1 | | 2-wire (fwd / rev) | | | | | |
| | 2 | | 3-wire (fwd / rev) | | | | | |
| | 3 | | 3-wire (start / dir) | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|---|--------------------------------------|----------------------------|----------------------------|----------------------------|-----------------|-----------|------------|
| Note: | <p>Where:</p> <ul style="list-style-type: none"> • P denotes Pulse • FWD denotes FORWARD • REV denotes REVERSE <p>When any of the control functions are selected using P0727, the setting for the digital inputs (P0701 - P0704) are redefined as follows:</p> | | | | | | | |
| | Settings of P0701 - P0704 | P0727 = 0 (Siemens Standard Control) | P0727 = 1 (2-wire Control) | P0727 = 2 (3-wire Control) | P0727 = 3 (3-wire Control) | | | |
| | = 1 (P0840) | ON / OFF1 | ON_FWD | STOP | ON_PULSE | | | |
| | = 2 (P0842) | ON_REV / OFF1 | ON_REV | FWDP | OFF1 / HOLD | | | |
| | = 12 (P1113) | REV | REV | REVP | REV | | | |
| | <p>To use the 2 / 3-wire control, the sources for ON / OFF1 (P0840), ON_REV / OFF1 (P0842) and REV (P1113) corresponding to the redefined values have to be set accordingly.</p> | | | | | | | |
| | <p>Regarding the use of fixed frequencies see P1000 and P1001.</p> | | | | | | | |
| r0730 | Number of digital outputs | - | - | - | - | - | U16 | 3 |
| | <p>Displays number of digital outputs.</p> | | | | | | | |
| P0731[0...2] | BI: Function of digital output 1 | - | 52.3 | U, T | - | CDS | U32 / Bin | 2 |
| | <p>Defines source of digital output 1.</p> | | | | | | | |
| Notice: | <p>An inverse logic can be realized by inverting the digital outputs in P0748.</p> | | | | | | | |
| Note: | <p>Output of fault bit 52.3 is inverted on digital output. Therefore, with P0748 = 0, the digital output is set to low when a fault is triggered, and when there is no fault, it is set to high.</p> <p>Monitor functions ==> see r0052, r0053</p> <p>Motor holding brake ==> see P1215</p> <p>DC-Brake ==> see P1232, P1233</p> | | | | | | | |
| P0732[0...2] | BI: Function of digital output 2 | - | 52.7 | U, T | - | CDS | U32 / Bin | 2 |
| | <p>Defines source of digital output 2.</p> | | | | | | | |
| r0747.0...1 | CO / BO: State of digital outputs | - | - | - | - | - | U16 | 3 |
| | <p>Displays status of digital outputs (also includes inversion of digital outputs via P0748).</p> | | | | | | | |
| | Bit | Signal name | | | 1 signal | 0 signal | | |
| | 00 | Digital output 1 energized | | | Yes | No | | |
| | 01 | Digital output 2 energized | | | Yes | No | | |
| Dependency: | <p>Bit = 0 signal: Contacts open</p> <p>Bit = 1 signal: Contacts closed</p> | | | | | | | |
| P0748 | Invert digital outputs | - | 0000 bin | U, T | - | - | U16 | 3 |
| | <p>Defines high and low states of digital output for a given function.</p> | | | | | | | |
| | Bit | Signal name | | | 1 signal | 0 signal | | |
| | 00 | Invert digital output 1 | | | Yes | No | | |
| | 01 | Invert digital output 2 | | | Yes | No | | |
| r0750 | Number of analog inputs | - | - | - | - | - | U16 | 3 |
| | <p>Displays number of analog inputs available.</p> | | | | | | | |
| r0751.0...9 | CO / BO: Status word of analog input | - | - | - | - | - | U16 | 3 |
| | <p>Displays status of analog input.</p> | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|-----------------------|-----------------|----------------|---------|----------|-----------------|-----------------|
| | Bit | Signal name | | | | | 1 signal | 0 signal |
| | 00 | Signal lost on AI1 | | | | | Yes | No |
| | 01 | Signal lost on AI2 | | | | | Yes | No |
| | 08 | No signal lost on AI1 | | | | | Yes | No |
| | 09 | No signal lost on AI2 | | | | | Yes | No |
| r0752[0...1] | Actual analog input [V] or [mA] | - | - | - | - | - | Float | 2 |
| | Displays smoothed analog input value in volts or million amps before the scaling block. | | | | | | | |
| Index: | [0] | Analog input 1 (AI1) | | | | | | |
| | [1] | Analog input 2 (AI2) | | | | | | |
| P0753[0...1] | Smooth time analog input [ms] | 0 - 10000 | 3 | U, T | - | - | U16 | 3 |
| | Defines filter time (PT1 filter) for analog input. | | | | | | | |
| Index: | See r0752 | | | | | | | |
| Note: | Increasing this time (smooth) reduces jitter but slows down response to the analog input. P0753 = 0: No filtering | | | | | | | |
| r0754[0...1] | Actual analog input value after scaling [%] | - | - | - | - | - | Float | 2 |
| | Shows smoothed value of analog input after scaling block. | | | | | | | |
| Index: | See r0752 | | | | | | | |
| Dependency: | P0757 to P0760 define range (analog input scaling). | | | | | | | |
| r0755[0...1] | CO: Actual analog input after scaling [4000h] | - | - | - | - | 4000H | I16 | 2 |
| | Displays analog input, scaled using ASPmin and ASPmax (ASP = analog setpoint). Analog setpoint (ASP) from the analog scaling block can vary from minimum analog setpoint (ASPmin) to a maximum analog setpoint (ASPmax). The largest magnitude (value without sign) of ASPmin and ASPmax defines the scaling of 16384. By associating r0755 with an internal value (e.g. frequency setpoint), a scaled value is calculated internally by the inverter. The frequency value is calculated using the following equation: $r0755 [\text{Hz}] = (\text{r0755} [\text{hex}] / 4000 [\text{hex}] * \text{P2000} * (\max(\text{ASP_max} , \text{ASP_min}) / 100\%)$ | | | | | | | |
| Example: | Case a: ASPmin = 300 %, ASPmax = 100 % then 16384 represents 300 %. This parameter will vary from 5461 to 16384. Case b: ASPmin = -200 %, ASPmax = 100 % then 16384 represents 200 %. This parameter will vary from -16384 to +8192. | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | |
|--------------------|--|---|-----------------|----------------|---------|----------|-----------|------------|--|--|--|--|--|--|--|
| | $4000 \text{ h} = \max(\text{ASP}_{\text{max}} , \text{ASP}_{\text{min}})$ $4000 \text{ h} \leq 16384 \text{ dez}$ $7FFF \text{ h} \leq -16383 \text{ dez}$ | | | | | | | | | | | | | | |
| Index: | See r0752 | | | | | | | | | | | | | | |
| Note: | This value is used as an input to analog BICO connectors. ASPmax represents the highest analog setpoint (this may be at 10 V). ASPmin represents the lowest analog setpoint (this may be at 0 V). See P0757 to P0760 (analog input scaling). | | | | | | | | | | | | | | |
| P0756[0...1] | Type of analog input | 0 - 4 | 0 | T | - | - | U16 | 2 | | | | | | | |
| | Defines type of analog input and also enables analog input monitoring. | | | | | | | | | | | | | | |
| | 0 | Unipolar voltage input (0 to +10 V) | | | | | | | | | | | | | |
| | 1 | Unipolar voltage input with monitoring (0 to 10 V) | | | | | | | | | | | | | |
| | 2 | Unipolar current input (0 to 20 mA) | | | | | | | | | | | | | |
| | 3 | Unipolar current input with monitoring (0 to 20 mA) | | | | | | | | | | | | | |
| | 4 | Bipolar voltage input (-10 V to +10 V) | | | | | | | | | | | | | |
| Index: | See r0752 | | | | | | | | | | | | | | |
| Dependency: | Function disabled if analog scaling block programmed to output negative setpoints (see P0757 to P0760). | | | | | | | | | | | | | | |
| Notice: | When monitoring is enabled and a deadband defined (P0761), a fault condition will be generated (F80) if the analog input voltage falls below 50 % of the deadband voltage. It is not possible to select the bipolar voltage for analog input 2. | | | | | | | | | | | | | | |
| Note: | See P0757 to P0760 (analog input scaling). In current mode, if the input exceeds 24mA, the inverter will trip F80/11 for analog input 1 and F80/12 for analog input 2. This will result in channel switching back to voltage mode. Analog input parameter readings for the channel concerned will no longer be updated until the fault (F80) has been reset. Once the fault has been reset then the input will switch back to current mode and normal readings will resume. | | | | | | | | | | | | | | |
| P0757[0...1] | Value x1 of analog input scaling | -20 - 20 | 0 | U, T | - | - | Float | 2 | | | | | | | |
| | P0757 - P0760 configure the input scaling. x1 is the first value of the two pairs of variants x1 / y1 and x2 / y2 which determine the straight line. The value x2 of analog input scaling P0759 must be greater than the value x1 of analog input scaling P0757. | | | | | | | | | | | | | | |
| Index: | See r0752 | | | | | | | | | | | | | | |
| Notice: | <ul style="list-style-type: none"> Analog setpoints represent a [%] of the normalized frequency in P2000. Analog setpoints may be larger than 100 %. ASPmax represents highest analog setpoint (this may be at 10 V or 20 mA). ASPmin represents lowest analog setpoint (this may be at 0 V or 20 mA). Default values provide a scaling of 0 V or 0 mA = 0 %, and 10 V or 20 mA = 100 %. | | | | | | | | | | | | | | |
| P0758[0...1] | Value y1 of analog input scaling [%] | -99999 - 99999 | 0.0 | U, T | - | - | Float | 2 | | | | | | | |
| | Sets value of y1 as described in P0757 (analog input scaling) | | | | | | | | | | | | | | |
| Index: | See r0752 | | | | | | | | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|-----------------------|-----------------|----------------|---------|----------|-----------|------------|
| Dependency: | Affects P2000 to P2003 (reference frequency, voltage, current or torque) depending on which setpoint is to be generated. | | | | | | | |
| P0759[0...1] | Value x2 of analog input scaling | -20 - 20 | 10 | U, T | - | - | Float | 2 |
| | Sets value of x2 as described in P0757 (analog input scaling). | | | | | | | |
| Index: | See r0752 | | | | | | | |
| Notice: | The value x2 of analog input scaling P0759 must be greater than the value x1 of analog input scaling P0757. | | | | | | | |
| P0760[0...1] | Value y2 of analog input scaling [%] | -99999 - 99999 | 100.0 | U, T | - | - | Float | 2 |
| | Sets value of y2 as described in P0757 (analog input scaling). | | | | | | | |
| Index: | See r0752 | | | | | | | |
| Dependency: | See P0758 | | | | | | | |
| P0761[0...1] | Width of analog input deadband | 0 - 20 | 0 | U, T | - | - | Float | 2 |
| | Defines width of deadband on analog input. | | | | | | | |
| Example: | <p>The below example produces a 2 to 10 V, 0 to 50 Hz analog input (AI value 2 to 10 V, 0 to 50 Hz):</p> <ul style="list-style-type: none"> • P2000 = 50 Hz • P0759 = 8 V P0760 = 75 % • P0757 = 2 V P0758 = 0 % • P0761 = 2 V • P0756 = 0 or 1 <p>The below example produces a 0 to 10 V analog input (-50 to +50 Hz) with center zero and a "holding point" 0.2 V wide (0.1 V to each side of center, AI value 0 to 10 V, -50 to +50 Hz):</p> <ul style="list-style-type: none"> • P2000 = 50 Hz • P0759 = 8 V P0760 = 75 % • P0757 = 2 V P0758 = -75 % • P0761 = 0.1 V • P0756 = 0 or 1 | | | | | | | |
| Index: | See r0752 | | | | | | | |
| Notice: | Deadband starts from 0 V to value of P0761, if both values of P0758 and P0760 (y coordinates of analog input scaling) are positive or negative respectively. However, deadband is active in both directions from point of intersection (x axis with analog input scaling curve), if sign of P0758 and P0760 are opposite. | | | | | | | |
| Note: | <p>P0761[x] = 0: No deadband active.</p> <p>Minimum frequency P1080 should be zero when using center zero setup.</p> <p>There is no hysteresis at the end of the deadband.</p> | | | | | | | |
| P0762[0...1] | Delay for loss of signal action [ms] | 0 - 10000 | 10 | U, T | - | - | U16 | 3 |
| | Defines time delay between loss of analog setpoint and appearance of fault code F80. | | | | | | | |
| Index: | See r0752 | | | | | | | |
| Note: | Expert users can choose the desired reaction to F80 (default is OFF2). | | | | | | | |
| r0770 | Number of analog output | - | - | - | - | - | U16 | 3 |
| | Displays number of analog outputs available. | | | | | | | |
| P0771[0] | Cl: Analog output | - | 21[0] | U, T | - | - | U32 / I32 | 2 |
| | Defines function of the analog output. | | | | | | | |
| Index: | [0] | Analog output 1 (AO1) | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|--------------------------|-----------------|----------------|---------|-----------------|-----------------|------------|
| P0773[0] | Smooth time analog output [ms] | 0 - 1000 | 2 | U, T | - | - | U16 | 2 |
| | Defines smoothing time for analog output signal. This parameter enables smoothing for analog output using a PT1 filter. | | | | | | | |
| Index: | See P0771 | | | | | | | |
| Dependency: | P0773 = 0: Deactivates filter. | | | | | | | |
| r0774[0] | Actual analog output value [V] or [mA] | - | - | - | - | - | Float | 2 |
| | Shows value of analog output after filtering and scaling. | | | | | | | |
| Index: | See P0771 | | | | | | | |
| Note: | The analog output is only a current output. By connecting an external resistor of 500 Ohm to the terminals (4/5) a voltage output with a range of 0...10 V can be created. | | | | | | | |
| P0775[0] | Permit absolute value | 0 - 65535 | 0 | T | - | - | U16 | 2 |
| | Decides if the absolute value of the analog output is used. If enabled, this parameter will take the absolute value to be outputed. If the value was originally negative then the corresponding bit in r0785 is set, otherwise it is cleared. | | | | | | | |
| Index: | See P0771 | | | | | | | |
| P0777[0] | Value x1 of analog output scaling [%] | -99999 - 99999 | 0.0 | U, T | - | - | Float | 2 |
| | Defines x1 output characteristic. Scaling block is responsible for adjustment of output value defined in P0771 (analog output connector input). x1 is the first value of the two pairs of variants x1 / y1 and x2 / y2 which determine the straight line. The two points P1 (x1, y1) and P2 (x2, y2) can be chosen freely. | | | | | | | |
| Note: | See P0771 | | | | | | | |
| Dependency: | See P0758 | | | | | | | |
| P0778[0] | Value y1 of analog output scaling | 0 - 20 | 0 | U, T | - | - | Float | 2 |
| | Defines y1 of output characteristic. | | | | | | | |
| Index: | See P0771 | | | | | | | |
| P0779[0] | Value x2 of analog output scaling [%] | -99999 - 99999 | 100.0 | U, T | - | - | Float | 2 |
| | Defines x2 of output characteristic. | | | | | | | |
| Index: | See P0771 | | | | | | | |
| Dependency: | See P0758 | | | | | | | |
| P0780[0] | Value y2 of analog output scaling | 0 - 20 | 20 | U, T | - | - | Float | 2 |
| | Defines y2 of output characteristic. | | | | | | | |
| Index: | See P0771 | | | | | | | |
| P0781[0] | Width of analog output deadband | 0 - 20 | 0 | U, T | - | - | Float | 2 |
| | Sets width of dead-band for analog output. | | | | | | | |
| Index: | See P0771 | | | | | | | |
| r0785.0 | CO / BO: Status word of analog output | - | - | - | - | - | U16 | 2 |
| | Displays status of analog output. Bit 0 indicates that the value of analog output 1 is negative. | | | | | | | |
| | Bit | Signal name | | | | 1 signal | 0 signal | |
| | 00 | Analog output 1 negative | | | | Yes | No | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | |
|-----------------|---|-----------------------|----------------------|----------------|---------|-----------------|-----------------|------------|--|
| P0802 | Transfer data from EEPROM | 0 - 2 | 0 | - | - | - | U16 | 3 | |
| | Transfers values from inverter to External device when none 0. P0010 must be set to 30 for this to be possible. | | | | | | | | |
| | 0 | Disabled | | | | | | | |
| | 2 | Start MMC Transfer | | | | | | | |
| Note: | Parameter is automatically reset to 0 (default) after transfer. P0010 will be reset to 0 on successful completion. Ensure that enough space exists on the MMC card before transferring data (8kb). | | | | | | | | |
| P0803 | Transfer data to EEPROM | 0 - 2 | 0 | - | - | - | U16 | 3 | |
| | Transfers values from External to inverter when none 0. P0010 must be set to 30 for this to be possible. See P0802 for parameter values. | | | | | | | | |
| Note: | Parameter is automatically reset to 0 (default) after transfer. P0010 will be reset to 0 on successful completion. | | | | | | | | |
| P0804 | Select Clone file | 0 - 99 | 0 | - | - | - | U16 | 3 | |
| | Select clone file to up / down load. if P0804 = 0 then file name is clone00.bin if P0804 = 1 then file name is clone01.bin etc. | | | | | | | | |
| P0806 | BI: Inhibit panel access | - | 0 | U, T | - | - | U32 / Bin | 3 | |
| | Binector input to lock control panel access through external client. | | | | | | | | |
| r0807.0 | BO: Displays client access | - | - | - | - | - | U16 | 3 | |
| | Binector output to display whether command and setpoint source is connected to an external client. | | | | | | | | |
| | Bit | Signal name | | | | 1 signal | 0 signal | | |
| | 00 | Master control active | | | | Yes | No | | |
| P0809[0...2] | Copy command data set (CDS) | 0 - 2 | [0] 0 [1] 1 [2] 0 | T | - | - | U16 | 2 | |
| | Calls 'Copy command data set (CDS)' function. The list of all command data sets (CDS) parameters is shown in "Index" at the end of the manual. | | | | | | | | |
| Example: | Copying of all values from CDS0 to CDS2 can be accomplished by the following procedure: P0809[0] = 0 Copy from CDS0 P0809[1] = 2 Copy to CDS2 P0809[2] = 1 Start copy | | | | | | | | |
| Index: | [0] | Copy from CDS | | | | | | | |
| | [1] | Copy to CDS | | | | | | | |
| | [2] | Start copy | | | | | | | |
| Note: | Start value in index 2 is automatically reset to '0' after execution of function. | | | | | | | | |
| P0810 | BI: command data set bit 0 (Hand / Auto) | - | 0 | U, T | - | - | U32 / Bin | 2 | |
| | Selects command source from which to read Bit 0 for selecting a command data set (CDS). The actual selected CDS is displayed in r0054.15 (CDS bit 0) and r0055.15 (CDS bit 1). The actual active CDS is displayed in r0050. | | | | | | | | |
| Note: | P0811 is also relevant for command data set (CDS) selection. | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|---------------|----------------------|----------------|---------|----------|-----------|------------|
| P0811 | BI: command data set bit 1 | - | 0 | U, T | - | - | U32 / Bin | 2 |
| | Selects command source from which to read Bit 1 for selecting a command data set (see P0810). | | | | | | | |
| Note: | P0810 is also relevant for command data set (CDS) selection. | | | | | | | |
| P0819[0...2] | Copy inverter data set (DDS) | 0 - 2 | [0] 0 [1] 1 [2] 0 | T | - | - | U16 | 2 |
| | Calls 'Copy inverter data set (DDS)' function. The list of all inverter data set (DDS) parameters is shown in "Index" at the end of the manual. | | | | | | | |
| Example: | Copying of all values from DDS0 to DDS2 can be accomplished by the following procedure: P0819[0] = 0 Copy from DDS0 P0819[1] = 2 Copy to DDS2 P0819[2] = 1 Start copy | | | | | | | |
| Index: | [0] | Copy from DDS | | | | | | |
| | [1] | Copy to DDS | | | | | | |
| | [2] | Start copy | | | | | | |
| Note: | See P0809 | | | | | | | |
| P0820 | BI: inverter data set bit 0 | - | 0 | T | - | - | U32 / Bin | 3 |
| | Selects command source from which to read Bit 0 for selecting an inverter data set (DDS). The actual selected inverter data set (DDS) is displayed in parameter r0051[0]. The actual active inverter data set (DDS) is displayed in parameter r0051[1]. | | | | | | | |
| Note: | P0821 is also relevant for inverter data set (DDS) selection. | | | | | | | |
| P0821 | BI: inverter data set bit 1 | - | 0 | T | - | - | U32 / Bin | 3 |
| | Selects command source from which Bit 1 for selecting an inverter data set is to be read in (see P0820). | | | | | | | |
| Note: | P0820 is also relevant for inverter data set (DDS) selection. | | | | | | | |
| P0840[0...2] | BI: ON / OFF1 | - | 19.0 | T | - | CDS | U32 / Bin | 3 |
| | Allows ON / OFF1 command source to be selected using BICO. | | | | | | | |
| Dependency: | For digital inputs as command source BICO requires P0700 set to 2 (enable BICO). The default setting (ON right) is digital input 1 (722.0). Alternative source possible only when function of digital input 1 is changed (via P0701) before changing value of P0840. | | | | | | | |
| P0842[0...2] | BI: ON reverse / OFF1 | - | 0 | T | - | CDS | U32 / Bin | 3 |
| | Allows ON / OFF1 reverse command source to be selected using BICO. In general a positive frequency setpoint is run up counterclockwise (negative frequency). | | | | | | | |
| P0844[0...2] | BI: 1. OFF2 | - | 19.1 | T | - | CDS | U32 / Bin | 3 |
| | Defines first source of OFF2 when P0719 = 0 (BICO). | | | | | | | |
| Dependency: | If one of the digital inputs is selected for OFF2, the inverter will not run unless the digital input is active. | | | | | | | |
| Note: | OFF2 means immediate pulse-disabling; the motor is coasting. OFF2 is low-active, i.e.: 0 = Pulse disabling. 1 = Operating condition. | | | | | | | |
| P0845[0...2] | BI: 2. OFF2 | - | 1 | T | - | CDS | U32 / Bin | 3 |
| | Defines second source of OFF2. | | | | | | | |
| Dependency: | In contrast to P0844 (first source of OFF2), this parameter is always active, independent of P0719 (selection of command and frequency setpoint). See P0844. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|--|-----------------|----------------|---------|-----------------|-----------------|------------|
| Note: | See P0844 | | | | | | | |
| P0848[0...2] | Bi: 1. OFF3 | - | 1 | T | - | CDS | U32 / Bin | 3 |
| | Defines first source of OFF3 when P0719 = 0 (BICO). | | | | | | | |
| Dependency: | If one of the digital inputs is selected for OFF3, the inverter will not run unless the digital input is active. | | | | | | | |
| Note: | OFF3 means quick ramp-down to 0. OFF3 is low-active, i.e. 0 = Quick ramp-down. 1 = Operating condition. | | | | | | | |
| P0849[0...2] | Bi: 2. OFF3 | - | 1 | T | - | CDS | U32 / Bin | 3 |
| | Defines second source of OFF3. | | | | | | | |
| Dependency: | In contrast to P0848 (first source of OFF3), this parameter is always active, independent of P0719 (selection of command and frequency setpoint). See P0848. | | | | | | | |
| Note: | See P0848 | | | | | | | |
| P0852[0...2] | Bi: Pulse enable | - | 1 | T | - | CDS | U32 / Bin | 3 |
| | Defines source of pulse enable / disable signal. | | | | | | | |
| Dependency: | Active only when P0719 = 0 (Auto selection of command / setpoint source). | | | | | | | |
| P0881[0...2] | Bi: Quick stop source 1 | - | 1 | T | - | CDS | U32 / Bin | 3 |
| | Allows quick stop source 1 command to be selected using BICO. The signal is expected to be active low (default setting P0886 = 2). | | | | | | | |
| P0882[0...2] | Bi: Quick stop source 2 | - | 1 | T | - | CDS | U32 / Bin | 3 |
| | Allows quick stop source 2 command to be selected using BICO. The signal is expected to be active low (default setting P0886 = 2). | | | | | | | |
| P0883[0...2] | Bi: Quick stop override | - | 0 | T | - | CDS | U32 / Bin | 3 |
| | Allows quick stop override command source to be selected using BICO. The signal is expected to be active high. | | | | | | | |
| r0885.0...4 | CO / BO: Quick stop status | - | - | - | - | - | - | U16 3 |
| | Bit field describing status of quick stop. | | | | | | | |
| | Bit | Signal name | | | | 1 signal | 0 signal | |
| | 00 | Quick stop is active | | | | Yes | No | |
| | 01 | Quick stop selected | | | | Yes | No | |
| | 02 | Override selected | | | | Yes | No | |
| | 04 | Quick stop enabled | | | | Yes | No | |
| P0886[0...2] | Quick stop input type | 0 - 4 | 2 | T | - | CDS | U16 | 3 |
| | Control Word for selecting the quick stop input type. | | | | | | | |
| | 0 | Quick stop not selected | | | | | | |
| | 1 | Quick stop input active high | | | | | | |
| | 2 | Quick stop input active low | | | | | | |
| | 3 | Quick stop input positive edge triggered | | | | | | |
| | 4 | Quick stop input negative edge triggered | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|---|-------------------------------------|-----------------|----------------|-----------------|----------|-----------------|------------|
| P0927 | Parameter changeable via | - | 1111 bin | U, T | - | - | U16 | 2 |
| | Specifies the interfaces which can be used to change parameters. This parameter allows the user to easily protect the inverter from unauthorized modification of parameters. | | | | | | | |
| | Annotation: P0927 is not password protected. | | | | | | | |
| | Bit | Signal name | | | 1 signal | | 0 signal | |
| | 00 | Not used | | | Yes | | No | |
| | 01 | Not used | | | Yes | | No | |
| | 02 | USS on RS232 (reserved) | | | Yes | | No | |
| | 03 | USS on RS485 | | | Yes | | No | |
| Example: | Default: All bits are set. The default setting allows parameters to be changed via any interface. | | | | | | | |
| r0944 | Total number of messages | - | - | - | - | - | U16 | 3 |
| | Displays the total number of messages available. | | | | | | | |
| r0947[0...63] | CO: Last fault code | - | - | - | - | - | U16 | 2 |
| | Displays fault history. | | | | | | | |
| Index: | [0] | Recent fault trip --, fault 1 | | | | | | |
| | [1] | Recent fault trip --, fault 2 | | | | | | |
| | ... | ... | | | | | | |
| | [7] | Recent fault trip --, fault 8 | | | | | | |
| | [8] | Recent fault trip -1, fault 1 | | | | | | |
| Note: | See Chapter "Fault and warning codes (Page 233)". | | | | | | | |
| r0948[0...63] | Fault time | - | - | - | - | - | U32 | 3 |
| | Time stamp to indicate when a fault has occurred. P0969 (system run time counter) is the possible source of the time stamp. | | | | | | | |
| Index: | [0] | Recent fault trip --, fault time 1 | | | | | | |
| | [1] | Recent fault trip --, fault time 2 | | | | | | |
| | ... | ... | | | | | | |
| | [7] | Recent fault trip --, fault time 8 | | | | | | |
| | [8] | Recent fault trip -1, fault time 1 | | | | | | |
| r0949[0...63] | CO: Fault value | - | - | - | - | - | U32 | 3 |
| | Displays inverter fault values. It is for service purposes and indicates the type of fault reported. The values are not documented. They are listed in the code where faults are reported. | | | | | | | |
| Index: | [0] | Recent fault trip --, fault value 1 | | | | | | |
| | [1] | Recent fault trip --, fault value 2 | | | | | | |
| | ... | ... | | | | | | |
| | [7] | Recent fault trip --, fault value 8 | | | | | | |
| | [8] | Recent fault trip -1, fault value 1 | | | | | | |
| P0952 | Total number of trips | 0 - 65535 | 0 | T | - | - | U16 | 3 |
| | Displays number of trips stored in r0947. | | | | | | | |
| Dependency: | Setting 0 resets fault history (changing to 0 also resets r0948 - fault time). | | | | | | | |
| r0964[0...6] | Firmware version data | - | - | - | - | - | U16 | 3 |
| | Firmware version data. | | | | | | | |
| Index: | [0] | Company (Siemens = 42) | | | | | | |

Parameter list


7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | |
|--------------------|--|--|-----------------|----------------|---------|----------|-----------|------------|--|--|--|--|--|--|--|
| | [1] | Product type | | | | | | | | | | | | | |
| | [2] | Firmware version | | | | | | | | | | | | | |
| | [3] | Firmware date (year) | | | | | | | | | | | | | |
| | [4] | Firmware date (day / month) | | | | | | | | | | | | | |
| | [5] | Number of inverter objects | | | | | | | | | | | | | |
| | [6] | Firmware version | | | | | | | | | | | | | |
| r0967 | Control word 1 | - | - | - | - | - | U16 | 3 | | | | | | | |
| | | Displays control word 1. See r0054 for the bit field description. | | | | | | | | | | | | | |
| r0968 | Status word 1 | - | - | - | - | - | U16 | 3 | | | | | | | |
| | | Displays active status word of inverter (in binary) and can be used to diagnose which commands are active. See r0052 for the bit field description. | | | | | | | | | | | | | |
| P0969 | Resettable system run time counter | 0 - 4294967295 | 0 | T | - | - | U32 | 3 | | | | | | | |
| | | Resettable system run time counter. | | | | | | | | | | | | | |
| P0970 | Factory reset | 0 - 21 | 0 | - | - | - | U16 | 1 | | | | | | | |
| | | P0970 = 1 resets all parameters (not user defaults) to their default values. P0970 = 21 resets all parameters and all user defaults to Factory Reset state. | | | | | | | | | | | | | |
| | 0 | Disabled | | | | | | | | | | | | | |
| | 1 | Parameter reset | | | | | | | | | | | | | |
| | 21 | User Default Parameter Reset | | | | | | | | | | | | | |
| Dependency: | First set P0010 = 30 (factory settings). Stop inverter (i.e. disable all pulses) before you can reset parameters to default values. | | | | | | | | | | | | | | |
| Note: | <p>The following parameters retain their values after a factory reset:</p> <ul style="list-style-type: none"> • r0039 CO: Energy consumption meter [kWh] • P0014 Store mode • P0100 Europe / North America • P2010 USS / MODBUS baudrate • P2011 USS address • P2021 MODBUS address • P2023 RS485 protocol selection • P8458 Clone control <p>When transferring P0970, the inverter uses its processor to carry out internal calculations. Communications are interrupted for the time that it takes to make these calculations.</p> | | | | | | | | | | | | | | |
| P0971 | Transfer data from RAM to EEPROM | 0 - 21 | 0 | U, T | - | - | U16 | 3 | | | | | | | |
| | | Transfers values from RAM to EEPROM when set to 1. Transfers new user default values from RAM to EEPROM when set to 21. | | | | | | | | | | | | | |
| | 0 | Disabled | | | | | | | | | | | | | |
| | 1 | Start transfer | | | | | | | | | | | | | |
| | 21 | Start User Defaults transfer | | | | | | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|---|--|--------------|-----------------|----------------|---------|----------|-----------|------------|
| Note: | All values in RAM are transferred to EEPROM. Parameter is automatically reset to 0 (default) after successful transfer. The storage from RAM to EEPROM is accomplished via P0971. The communications are reset, if the transfer was successful. During the reset process communications will be interrupted. | | | | | | | |
| r0980[0...99] | List of available parameter numbers | - | - | - | - | - | U16 | 4 |
| Contains 100 parameter numbers index 0 - 99. | | | | | | | | |
| Index: | [0] | Parameter 1 | | | | | | |
| | [1] | Parameter 2 | | | | | | |
| | ... | ... | | | | | | |
| | [9] | Parameter 10 | | | | | | |
| Note: | The parameter list array has 2 elements to reduce memory consumption. On each access to an element index 0 - 99, the individual result is determined dynamically by the 'BeforeAccess' function. The last element contains the number of the following parameter array, 0 indicates end of list. | | | | | | | |
| r0981[0...99] | List of available parameter numbers | - | - | - | - | - | U16 | 4 |
| Contains 100 parameter numbers index 100 - 199. | | | | | | | | |
| Index: | See r0980 | | | | | | | |
| Note: | See r0980 | | | | | | | |
| r0982[0...99] | List of available parameter numbers | - | - | - | - | - | U16 | 4 |
| Contains 100 parameter numbers index 200 - 299. | | | | | | | | |
| Index: | See r0980 | | | | | | | |
| Note: | See r0980 | | | | | | | |
| r0983[0...99] | List of available parameter numbers | - | - | - | - | - | U16 | 4 |
| Contains 100 parameter numbers index 300 - 399. | | | | | | | | |
| Index: | See r0980 | | | | | | | |
| Note: | See r0980 | | | | | | | |
| r0984[0...99] | List of available parameter numbers | - | - | - | - | - | U16 | 4 |
| Contains 100 parameter numbers index 400 - 499. | | | | | | | | |
| Index: | See r0980 | | | | | | | |
| Note: | See r0980 | | | | | | | |
| r0985[0...99] | List of available parameter numbers | - | - | - | - | - | U16 | 4 |
| Contains 100 parameter numbers index 500 - 599. | | | | | | | | |
| Index: | See r0980 | | | | | | | |
| Note: | See r0980 | | | | | | | |
| r0986[0...99] | List of available parameter numbers | - | - | - | - | - | U16 | 4 |
| Contains 100 parameter numbers index 600 - 699. | | | | | | | | |
| Index: | See r0980 | | | | | | | |
| Note: | See r0980 | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | |
|---------------|---|---|-----------------|----------------|---------|----------|-----------|------------|--|
| r0987[0...99] | List of available parameter numbers | - | - | - | - | - | U16 | 4 | |
| | Contains 100 parameter numbers index 700 - 799. | | | | | | | | |
| Index: | See r0980 | | | | | | | | |
| Note: | See r0980 | | | | | | | | |
| r0988[0...99] | List of available parameter numbers | - | - | - | - | - | U16 | 4 | |
| | Contains 100 parameter numbers index 800 - 899. | | | | | | | | |
| Index: | See r0980 | | | | | | | | |
| Note: | See r0980 | | | | | | | | |
| r0989[0...99] | List of available parameter numbers | - | - | - | - | - | U16 | 4 | |
| | Contains 100 parameter numbers index 900 - 999. | | | | | | | | |
| Index: | See r0980 | | | | | | | | |
| Note: | See r0980 | | | | | | | | |
| P1000[0..2] | Selection of frequency setpoint | 0 - 77 | 1 | C(1), T | - | CDS | U16 | 1 | |
| | Selects frequency setpoint source. The main setpoint is given by the least significant digit (right-hand position) and the additional setpoint is given by the most significant digit (left-hand position). Single digits denote main setpoints that have no additional setpoint. |  <p>The graph illustrates the selection of frequency setpoint. The vertical axis is labeled "Output frequency" and the horizontal axis is labeled "Time". A solid line shows the "Actual output frequency" which follows a trapezoidal profile. A horizontal dashed line represents the "Main setpoint". A vertical dashed line represents the "Additional setpoint", positioned above the Main setpoint. A step function at the bottom represents the "Run command".</p> | | | | | | | |
| | 0 | No main setpoint | | | | | | | |
| | 1 | MOP setpoint | | | | | | | |
| | 2 | Analog setpoint | | | | | | | |
| | 3 | Fixed frequency | | | | | | | |
| | 5 | USS on RS485 | | | | | | | |
| | 7 | Analog setpoint 2 | | | | | | | |
| | 10 | No main setpoint + MOP setpoint | | | | | | | |
| | 11 | MOP setpoint + MOP setpoint | | | | | | | |
| | 12 | Analog setpoint + MOP setpoint | | | | | | | |
| | 13 | Fixed frequency + MOP setpoint | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|---------------------------------------|-----------------|----------------|---------|----------|-----------|------------|
| | 15 | USS on RS485 + MOP setpoint | | | | | | |
| | 17 | Analog setpoint 2 + MOP setpoint | | | | | | |
| | 20 | No main setpoint + Analog setpoint | | | | | | |
| | 21 | MOP setpoint + Analog setpoint | | | | | | |
| | 22 | Analog setpoint + Analog setpoint | | | | | | |
| | 23 | Fixed frequency + Analog setpoint | | | | | | |
| | 25 | USS on RS485 + Analog setpoint | | | | | | |
| | 27 | Analog setpoint 2 + Analog setpoint | | | | | | |
| | 30 | No main setpoint + Fixed frequency | | | | | | |
| | 31 | MOP setpoint + Fixed frequency | | | | | | |
| | 32 | Analog setpoint + Fixed frequency | | | | | | |
| | 33 | Fixed frequency + Fixed frequency | | | | | | |
| | 35 | USS on RS485 + Fixed frequency | | | | | | |
| | 37 | Analog setpoint 2 + Fixed frequency | | | | | | |
| | 50 | No main setpoint + USS on RS485 | | | | | | |
| | 51 | MOP setpoint + USS on RS485 | | | | | | |
| | 52 | Analog setpoint + USS on RS485 | | | | | | |
| | 53 | Fixed frequency + USS on RS485 | | | | | | |
| | 55 | USS on RS485 + USS on RS485 | | | | | | |
| | 57 | Analog setpoint 2 + USS on RS485 | | | | | | |
| | 70 | No main setpoint + Analog setpoint 2 | | | | | | |
| | 71 | MOP setpoint + Analog setpoint 2 | | | | | | |
| | 72 | Analog setpoint + Analog setpoint 2 | | | | | | |
| | 73 | Fixed frequency + Analog setpoint 2 | | | | | | |
| | 75 | USS on RS485 + Analog setpoint 2 | | | | | | |
| | 77 | Analog setpoint 2 + Analog setpoint 2 | | | | | | |
| Dependency: | Related parameter: P1074 (BI: Disable additional setpoint) | | | | | | | |
| Caution: | Changing this parameter sets (to default) all settings on item selected. These are the following parameters: P1070, P1071, P1075, P1076 If P1000 = 1 or 1X, and P1032 (inhibit reverse direction of MOP) = 1, then reverse motor direction will be inhibited. | | | | | | | |
| Note: | RS485 also supports MODBUS protocol as well as USS. All USS options on RS485 are also applicable to MODBUS. | | | | | | | |
| P1001[0...2] | Fixed frequency 1 [Hz] | -599.00 - 599.00 | 10.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed frequency setpoint 1. There are 2 types of fixed frequencies: 1. Direct selection (P1016 = 1): – In this mode of operation 1 Fixed Frequency selector (P1020...P1023) selects 1 fixed frequency. – If several inputs are active together, the selected frequencies are summed. E.g.: FF1 + FF2 + FF3 + FF4. 2. Binary coded selection (P1016 = 2): – Up to 16 different fixed frequency values can be selected using this method. | | | | | | | |
| Dependency: | Select fixed frequency operation (using P1000). Inverter requires ON command to start in the case of direct selection. Therefore r1025 must be connected to P0840 to start. | | | | | | | |
| Note: | Fixed frequencies can be selected using the digital inputs. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------|--------------------------------------|------------------|-----------------|----------------|---------|----------|-----------|------------|
| P1002[0...2] | Fixed frequency 2 [Hz] | -599.00 - 599.00 | 15.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed frequency setpoint 2. | | | | | | | |
| Note: | See P1001 | | | | | | | |
| P1003[0...2] | Fixed frequency 3 [Hz] | -599.00 - 599.00 | 25.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed frequency setpoint 3. | | | | | | | |
| Note: | See P1001 | | | | | | | |
| P1004[0...2] | Fixed frequency 4 [Hz] | -599.00 - 599.00 | 50.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed frequency setpoint 4. | | | | | | | |
| Note: | See P1001 | | | | | | | |
| P1005[0...2] | Fixed frequency 5 [Hz] | -599.00 - 599.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed frequency setpoint 5. | | | | | | | |
| Note: | See P1001 | | | | | | | |
| P1006[0...2] | Fixed frequency 6 [Hz] | -599.00 - 599.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed frequency setpoint 6. | | | | | | | |
| Note: | See P1001 | | | | | | | |
| P1007[0...2] | Fixed frequency 7 [Hz] | -599.00 - 599.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed frequency setpoint 7. | | | | | | | |
| Note: | See P1001 | | | | | | | |
| P1008[0...2] | Fixed frequency 8 [Hz] | -599.00 - 599.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed frequency setpoint 8. | | | | | | | |
| Note: | See P1001 | | | | | | | |
| P1009[0...2] | Fixed frequency 9 [Hz] | -599.00 - 599.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed frequency setpoint 9. | | | | | | | |
| Note: | See P1001 | | | | | | | |
| P1010[0...2] | Fixed frequency 10 [Hz] | -599.00 - 599.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed frequency setpoint 10. | | | | | | | |
| Note: | See P1001 | | | | | | | |
| P1011[0...2] | Fixed frequency 11 [Hz] | -599.00 - 599.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed frequency setpoint 11. | | | | | | | |
| Note: | See P1001 | | | | | | | |
| P1012[0...2] | Fixed frequency 12 [Hz] | -599.00 - 599.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed frequency setpoint 12. | | | | | | | |
| Note: | See P1001 | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|---|-------------------------------|-----------------|----------------|---------|-----------------|-----------------|------------|
| P1013[0...2] | Fixed frequency 13 [Hz] | -599.00 - 599.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed frequency setpoint 13. | | | | | | | |
| Note: | See P1001 | | | | | | | |
| P1014[0...2] | Fixed frequency 14 [Hz] | -599.00 - 599.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed frequency setpoint 14. | | | | | | | |
| Note: | See P1001 | | | | | | | |
| P1015[0...2] | Fixed frequency 15 [Hz] | -599.00 - 599.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed frequency setpoint 15. | | | | | | | |
| Note: | See P1001 | | | | | | | |
| P1016[0...2] | Fixed frequency mode | 1 - 2 | 1 | T | - | DDS | U16 | 2 |
| | Fixed frequencies can be selected in two different modes. P1016 defines the mode. | | | | | | | |
| | 1 | Direct selection | | | | | | |
| | 2 | Binary selection | | | | | | |
| Note: | See P1001 for description of how to use fixed frequencies. | | | | | | | |
| P1020[0...2] | BI: Fixed frequency selection Bit 0 | - | 722.3 | T | - | CDS | U32 / Bin | 3 |
| | Defines origin of fixed frequency selection. | | | | | | | |
| Dependency: | Accessible only if P0701 - P070x = 99 (function of digital inputs = BICO) | | | | | | | |
| P1021[0...2] | BI: Fixed frequency selection Bit 1 | - | 722.4 | T | - | CDS | U32 / Bin | 3 |
| | See P1020 | | | | | | | |
| P1022[0...2] | BI: Fixed frequency selection Bit 2 | - | 722.5 | T | - | CDS | U32 / Bin | 3 |
| | See P1020 | | | | | | | |
| P1023[0...2] | BI: Fixed frequency selection Bit 3 | - | 722.6 | T | - | CDS | U32 / Bin | 3 |
| | See P1020 | | | | | | | |
| r1024 | CO: Actual fixed frequency [Hz] | - | - | - | - | - | Float | 3 |
| | Displays sum total of selected fixed frequencies. | | | | | | | |
| r1025.0 | BO: Fixed frequency status | - | - | - | - | - | U16 | 3 |
| | Displays the status of fixed frequencies. | | | | | | | |
| | Bit | Signal name | | | | 1 signal | 0 signal | |
| | 00 | Status of FF | | | | Yes | No | |
| P1031[0...2] | MOP mode | - | 1 | U, T | - | DDS | U16 | 2 |
| | MOP mode specification. | | | | | | | |
| | Bit | Signal name | | | | 1 signal | 0 signal | |
| | 00 | Setpoint store active | | | | Yes | No | |
| | 01 | No On-state for MOP necessary | | | | Yes | No | |
| Note: | Defines the operation mode of the motorized potentiometer. See P1040. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | |
|--------------------|---|------------------------------|-----------------|----------------|---------|----------|-----------|------------|--|
| P1032 | Inhibit reverse direction of MOP | 0 - 1 | 1 | T | - | - | U16 | 2 | |
| | Inhibits reverse setpoint selection of the MOP. | | | | | | | | |
| | 0 | Reverse direction is allowed | | | | | | | |
| | 1 | Reverse direction inhibited | | | | | | | |
| Note: | Setting 0 enables a change of motor direction using the motor potentiometer setpoint (increase / decrease frequency). If P1032 = 1 and P1000 = 1 or 1X, then reverse motor direction will be inhibited. | | | | | | | | |
| P1035[0..2] | BI: Enable MOP (UP-command) | - | 19.13 | T | - | CDS | U32 / Bin | 3 | |
| | Defines source for motor potentiometer setpoint increase frequency. | | | | | | | | |
| Notice: | If this command is enabled by short pulses of less than 1 second, the frequency is changed in steps of 0.1 Hz. When the signal is enabled longer than 1 second the ramp generator accelerates with the rate of P1047. | | | | | | | | |
| P1036[0..2] | BI: Enable MOP (DOWN-command) | - | 19.14 | T | - | CDS | U32 / Bin | 3 | |
| | Defines source for motor potentiometer setpoint decrease frequency. | | | | | | | | |
| Notice: | If this command is enabled by short pulses of less than 1 second, the frequency is changed in steps of 0.1 Hz. When the signal is enabled longer than 1 second the ramp generator decelerates with the rate of P1048. | | | | | | | | |
| P1040[0..2] | Setpoint of the MOP [Hz] | -599.00 - 599.00 | 5.00 | U, T | - | DDS | Float | 2 | |
| | Determines setpoint for motor potentiometer control (P1000 = 1). | | | | | | | | |
| Dependency: | Motor potentiometer (P1040) must be chosen as main setpoint or additional setpoint (using P1000). | | | | | | | | |
| Note: | <p>If motor potentiometer setpoint is selected either as main setpoint or additional setpoint, the reverse direction will be inhibited by default of P1032 (inhibit reverse direction of MOP). To re-enable reverse direction, set P1032 = 0.</p> <p>A short press of the 'up' or 'down' keys (e.g.: operator panel) will change the frequency setpoint in steps of 0.1 Hz. A longer press will cause an accelerated frequency setpoint change.</p> <p>The start value gets active (for the MOP output) only at the start of the MOP. P1031 influences the start value behavior as follows:</p> <ul style="list-style-type: none"> • P1031 = 0: P1040 gets immediately active in the OFF-state and when changed in the ON-state, it gets active after the next OFF and ON cycle. • P1031 = 1: The last MOP output before stop is stored as starting value, since storing is selected, so a change of P1040 while in ON-state has no effect. In OFF-state P1040 can be changed. • P1031 = 2: The MOP is active every time, so the change of P1040 affects after the next power cycle or a change of P1031 to 0. | | | | | | | | |
| P1041[0..2] | BI: MOP select setpoint automatically / manually | - | 0 | T | - | CDS | U32 / Bin | 3 | |
| | Sets the signal source to change over from manual to automatic mode. If using the motorized potentiometer in the manual mode the setpoint is changed using two signals for up and down e.g. P1035 and P1036. If using the automatic mode the setpoint must be interconnected via the connector input (P1042). 0: manually 1: automatically | | | | | | | | |
| Notice: | Refer to: P1035, P1036, P1042 | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|----------------|--|---------------------|-----------------|----------------|---------|----------|-----------|------------|
| P1042[0...2] | Cl: MOP auto setpoint | - | 0 | T | - | CDS | U32 / I32 | 3 |
| | Sets the signal source for the setpoint of the motorized potentiometer if automatic mode P1041 is selected. | | | | | | | |
| Notice: | Refer to: P1041 | | | | | | | |
| P1043[0...2] | Bi: MOP accept rampgenerator setpoint | - | 0 | T | - | CDS | U32 / Bin | 3 |
| | Sets the signal source for the setting command to accept the setting value for the motorized potentiometer. The value becomes effective for a 0 / 1 edge of the setting command. | | | | | | | |
| Notice: | Refer to: P1044 | | | | | | | |
| P1044[0...2] | Cl: MOP rampgenerator setpoint | - | 0 | T | - | CDS | U32 / I32 | 3 |
| | Sets the signal source for the setpoint value for the MOP. The value becomes effective for a 0 / 1 edge of the setting command. | | | | | | | |
| Notice: | Refer to: P1043 | | | | | | | |
| r1045 | CO: MOP input frequency of the RFG [Hz] | - | - | - | - | - | Float | 3 |
| | Displays the motorized potentiometer setpoint before it passed the MOP RFG. | | | | | | | |
| P1047[0...2] | MOP ramp-up time of the RFG [s] | 0.00 - 1000.00 | 10.00 | U, T | - | DDS | Float | 2 |
| | Sets the ramp-up time for the internal MOP ramp-function generator. The setpoint is changed from zero up to limit defined in P1082 within this time. | | | | | | | |
| Notice: | Refer to: P1048, P1082 | | | | | | | |
| P1048[0...2] | MOP ramp-down time of the RFG [s] | 0.00 - 1000.0 | 10.00 | U, T | - | DDS | Float | 2 |
| | Sets the ramp-down time for the internal MOP ramp-function generator. The setpoint is changed from limit defined in P1082 down to zero within this time. | | | | | | | |
| Notice: | Refer to: P1047, P1082 | | | | | | | |
| r1050 | CO: Actual output freq. of the MOP [Hz] | - | - | - | - | - | Float | 2 |
| | Displays output frequency of motor potentiometer setpoint. | | | | | | | |
| P1055[0...2] | Bi: Enable JOG right | - | 19.8 | T | - | CDS | U32 / Bin | 3 |
| | Defines source of JOG right when P0719 = 0 (Auto selection of command / setpoint source). | | | | | | | |
| P1056[0...2] | Bi: Enable JOG left | - | 0 | T | - | CDS | U32 / Bin | 3 |
| | Defines source of JOG left when P0719 = 0 (Auto selection of command / setpoint source). | | | | | | | |
| P1057 | JOG enable | 0000 bin - 0001 bin | 0001 bin | T | - | - | U16 | 3 |
| | While JOG enable is '0' Jogging (P1056 and P1055) is disabled. When '1' Jogging is enabled. | | | | | | | |
| P1058[0...2] | JOG frequency [Hz] | 0.00 - 599.00 | 5.00 | U, T | - | DDS | Float | 2 |
| | Jogging increases the motor speed by small amounts. The JOG mode allows the operator to perform a specific number of revolutions and position the rotor manually. In JOG mode, the RUN button on the operator panel for jogging uses a non-latching switch on one of the digital inputs to control the motor speed. While jogging, P1058 determines the frequency at which the inverter will run. The motor speed is increased as long as 'JOG left' or 'JOG right' are selected and until the left or right JOG frequency is reached. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|---|---------------|----------------------|----------------|---------|----------|-----------|------------|
| Dependency: | P1060 and P1061 set up and down ramp times respectively for jogging. Rounding times (P1130 - P1133), rounding type (P1134) and P2167 will also have influence on the JOG ramp. | | | | | | | |
| P1059[0...2] | JOG frequency left [Hz] | 0.00 - 599.00 | 5.00 | U, T | - | DDS | Float | 2 |
| | While JOG left is selected, this parameter determines the frequency at which the inverter will run. | | | | | | | |
| Dependency: | P1060 and P1061 set up and down ramp times respectively for jogging. | | | | | | | |
| P1060[0...2] | JOG ramp-up time [s] | 0.00 - 650.00 | 10.00 | U, T | - | DDS | Float | 2 |
| | Sets jog ramp-up time. This is the time used while jogging is active. | | | | | | | |
| Dependency: | See also P3350, P3353. | | | | | | | |
| Notice: | Ramp times will be used as follows: <ul style="list-style-type: none">• P1060 / P1061 : JOG mode is active• P1120 / P1121 : Normal mode (ON / OFF) is active• P1060 / P1061 : Normal mode (ON / OFF) and P1124 is active The rounding of P1130 - P1133 also applies to the JOG ramping. | | | | | | | |
| Note: | If the SuperTorque function is enabled, the inverter will initially ramp using the value in P3353. | | | | | | | |
| P1061[0...2] | JOG ramp-down time [s] | 0.00 - 650.00 | 10.00 | U, T | - | DDS | Float | 2 |
| | Sets ramp-down time. This is the time used while jogging is active. | | | | | | | |
| Dependency: | See also P3350, P3353. | | | | | | | |
| Note: | See P1060 | | | | | | | |
| P1070[0...2] | Cl: Main setpoint | - | 1050[0] | T | - | CDS | U32 / I32 | 3 |
| | Defines source of main setpoint. | | | | | | | |
| P1071[0...2] | Cl: Main setpoint scaling | - | 1 | T | 4000H | CDS | U32 / I16 | 3 |
| | Defines source of the main setpoint scaling. | | | | | | | |
| P1074[0...2] | Bi: Disable additional setpoint | - | 0 | U, T | - | CDS | U32 / Bin | 3 |
| | Disables additional setpoint. | | | | | | | |
| P1075[0...2] | Cl: Additional setpoint | - | 0 | T | - | CDS | U32 / I32 | 3 |
| | Defines source of the additional setpoint (to be added to main setpoint). | | | | | | | |
| P1076[0...2] | Cl: Additional setpoint scaling | - | [0] 1 [1] 0 [2] 1 | T | 4000H | CDS | U32 / I16 | 3 |
| | Defines source of scaling for additional setpoint (to be added to main setpoint). | | | | | | | |
| r1078 | CO: Total frequency setpoint [Hz] | - | - | - | - | - | Float | 3 |
| | Displays sum of main and additional setpoints. | | | | | | | |
| r1079 | CO: Selected frequency setpoint [Hz] | - | - | - | - | - | Float | 3 |
| | Displays selected frequency setpoint. Following frequency setpoints are displayed: <ul style="list-style-type: none">• r1078 Total frequency setpoint• P1058 JOG frequency right• P1059 JOG frequency left | | | | | | | |
| Dependency: | P1055 (Bi: Enable JOG right) or P1056 (Bi: Enable JOG left) define command source of JOG right or JOG left respectively. | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | | | | | | | | | |
|------------------------|---|---------------|-----------------|----------------|---------|----------|-----------|------------|--|-------|--|--|--|--|-------|-------|-------|------------|------------------------|--------------|--------------|------------|--------------|
| Note: | P1055 = 0 and P1056 = 0 ==> Total frequency setpoint is selected. | | | | | | | | | | | | | | | | | | | | | | |
| P1080[0...2] | Minimum frequency [Hz] | 0.00 - 599.00 | 0.00 | C(1), U, T | - | DDS | Float | 1 | | | | | | | | | | | | | | | |
| | Sets minimum motor frequency at which motor will run irrespective of frequency setpoint. The minimum frequency P1080 represents a masking frequency of 0 Hz for all frequency target value sources e.g. AI, MOP, FF, USS with the exception of the JOG target value source (analogous to P1091). Thus the frequency band + / -P1080 is run through in optimum time by means of the acceleration / deceleration ramps. Dwelling in the frequency band is not possible. Furthermore, an overshoot of the actual frequency f_act upper minimum frequency P1080 is output by the signal function f_act > f_min. | | | | | | | | | | | | | | | | | | | | | | |
| Note: | Value set here is valid both for clockwise and for anticlockwise rotation. Under certain conditions (e.g. ramping, current limiting), motor can run below minimum frequency. | | | | | | | | | | | | | | | | | | | | | | |
| P1082[0...2] | Maximum frequency [Hz] | 0.00 - 599.00 | 50.00 | C(1), T | - | DDS | Float | 1 | | | | | | | | | | | | | | | |
| | Sets maximum motor frequency at which motor will run irrespective of the frequency setpoint. The value set here is valid for both clockwise and anticlockwise rotation. Furthermore, the monitoring function f_act >= P1082 (r0052 bit 10, see example below) is affected by this parameter. | | | | | | | | | | | | | | | | | | | | | | |
| Example: | <p>The graph illustrates the monitoring function f_act ≥ P1082(f_max). The top axis represents the absolute value of the actual frequency f_act , which follows a trapezoidal waveform. Two horizontal dashed lines indicate the levels P1082 and P1082 - 3 Hz. The bottom axis represents the digital signal r0052 Bit 10, which is 0 until f_act reaches P1082, at which point it switches to 1 and remains high during the constant frequency segment.</p> | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | The maximum value of P1082 also depends on the nominal frequency: Max. P1082 = min (15*P0310, 599.0 Hz). As consequence P1082 can be affected if P0310 is changed to a smaller value. The maximum frequency and the pulse frequency depending on each other. The maximum frequency affects the pulse frequency according to the following table. | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th></th> <th colspan="4">P1800</th> </tr> <tr> <th></th> <th>2 kHz</th> <th>4 kHz</th> <th>6 kHz</th> <th>8 - 16 kHz</th> </tr> </thead> <tbody> <tr> <td>f_{max} P1082</td> <td>0 - 133.3 Hz</td> <td>0 - 266.6 Hz</td> <td>0 - 400 Hz</td> <td>0 - 599.0 Hz</td> </tr> </tbody> </table> | | | | | | | | | P1800 | | | | | 2 kHz | 4 kHz | 6 kHz | 8 - 16 kHz | f _{max} P1082 | 0 - 133.3 Hz | 0 - 266.6 Hz | 0 - 400 Hz | 0 - 599.0 Hz |
| | P1800 | | | | | | | | | | | | | | | | | | | | | | |
| | 2 kHz | 4 kHz | 6 kHz | 8 - 16 kHz | | | | | | | | | | | | | | | | | | | |
| f _{max} P1082 | 0 - 133.3 Hz | 0 - 266.6 Hz | 0 - 400 Hz | 0 - 599.0 Hz | | | | | | | | | | | | | | | | | | | |
| | Example: If P1082 is set to 350 Hz a pulse frequency from at least 6 kHz is necessary. If P1800 is smaller than 6 kHz the parameter is changed P1800 = 6 kHz. The maximum output frequency of inverter can be exceeded if one of the following is active: - P1335 ≠ 0 (Slip compensation active): $f_{max} (P1335) = f_{max} + f_{slip,max} = P1802 + \frac{P1336 \cdot r0330}{100} \cdot P0310$ - P1200 ≠ 0 (Flying restart active): $f_{max} (P1200) = f_{max} + 2 \cdot f_{slip,nom} = P1802 + 2 \cdot \frac{r0330}{100} \cdot P0310$ | | | | | | | | | | | | | | | | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|----------------|---|---------------|-----------------|----------------|---------|----------|-----------|------------|
| Note: | <p>When using the setpoint source</p> <ul style="list-style-type: none"> • Analog Input • USS <p>the setpoint frequency (in Hz) is cyclically calculated using</p> <ul style="list-style-type: none"> • a percentage value(e.g. for the analog input r0754) • a hexadecimal value (e.g. for the USS r2018[1]) • and the reference frequency P2000. <p>If for example P1082 = 80 Hz, P2000 = 50 Hz and the analog input is parameterized with P0757 = 0 V, P0758 = 0 %, P0759 = 10 V, P0760 = 100 %, a setpoint frequency of 50 Hz will be applied at 10 V of the analog input. When Quick Commissioning is carried out P2000 is changed as follows: P2000 = P1082.</p> | | | | | | | |
| r1084 | Resultant maximum frequency [Hz] | - | - | - | - | - | Float | 3 |
| | <p>Displays resultant maximum frequency.</p> <p>P1300 < 20: $P1800 \leq 6 \text{ kHz} \rightarrow r1084 = \min(P1082, P1800 / 15, 599.00)$ $P1800 \geq 8 \text{ kHz} \rightarrow r1084 = \min(P1082, 599.00)$</p> | | | | | | | |
| P1091[0..2] | Skip frequency [Hz] | 0.00 - 599.00 | 0.00 | U, T | - | DDS | Float | 3 |
| | <p>Defines skip frequency 1 which avoids effects of mechanical resonance and suppresses frequencies within + / -P1101 (skip frequency bandwidth).</p> | | | | | | | |
| Notice: | <p>Stationary operation is not possible within the suppressed frequency range; the range is merely passed through (on the ramp). For example, if P1091 = 10 Hz and P1101 = 2 Hz, it is not possible to operate continuously between 10 Hz + / - 2 Hz (i.e. between 8 and 12 Hz).</p> | | | | | | | |
| Note: | <p>The function is disabled if P1091 = 0.</p> | | | | | | | |
| P1092[0..2] | Skip frequency 2 [Hz] | 0.00 - 599.00 | 0.00 | U, T | - | DDS | Float | 3 |
| | <p>Defines skip frequency 2 which avoids effects of mechanical resonance and suppresses frequencies within + / -P1101 (skip frequency bandwidth).</p> | | | | | | | |
| Note: | <p>See P1091</p> | | | | | | | |
| P1093[0..2] | Skip frequency 3 [Hz] | 0.00 - 599.00 | 0.00 | U, T | - | DDS | Float | 3 |
| | <p>Defines skip frequency 3 which avoids effects of mechanical resonance and suppresses frequencies within + / -P1101 (skip frequency bandwidth).</p> | | | | | | | |
| Note: | <p>See P1091</p> | | | | | | | |
| P1094[0..2] | Skip frequency 4 [Hz] | 0.00 - 599.00 | 0.00 | U, T | - | DDS | Float | 3 |
| | <p>Defines skip frequency 4 which avoids effects of mechanical resonance and suppresses frequencies within + / -P1101 (skip frequency bandwidth).</p> | | | | | | | |
| Note: | <p>See P1091</p> | | | | | | | |
| P1101[0..2] | Skip frequency bandwidth [Hz] | 0.00 - 10.00 | 2.00 | U, T | - | DDS | Float | 3 |
| | <p>Delivers frequency bandwidth to be applied to skip frequencies.</p> | | | | | | | |
| Note: | <p>See P1091</p> | | | | | | | |
| P1110[0..2] | BI: Inhibit negative frequency setpoint | - | 0 | T | - | CDS | U32 / Bin | 3 |
| | <p>This parameter suppresses negative setpoints. Therefore, modification of the motor direction is inhibited to the set-point channel. If a minimum frequency (P1080) and a negative setpoint are given, the motor is accelerated by a positive value in relationship to the minimum frequency.</p> | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|---|---------------|-----------------|----------------|---------|----------|-----------|------------|
| P1113[0...2] | BI: Reverse | - | 19.11 | T | - | CDS | U32 / Bin | 3 |
| | Defines source of reverse command used when P0719 = 0 (Auto selection of command / setpoint source). | | | | | | | |
| r1114 | CO: Freq. setpoint after direction control [Hz] | - | - | - | - | - | Float | 3 |
| | Displays setpoint frequency after change of direction. | | | | | | | |
| r1119 | CO: Freq. setpoint before RFG [Hz] | - | - | - | - | - | Float | 3 |
| | Displays frequency setpoint at the input to the ramp function generator after modification by other functions, e.g.: <ul style="list-style-type: none"> • P1110 BI: Inhibit neg. freq. setpoint, • P1091 - P1094 skip frequencies, • P1080 min. frequency, • P1082 max. frequency, This value is available filtered (r0020) and unfiltered (r1119). | | | | | | | |
| P1120[0...2] | Ramp-up time [s] | 0.00 - 650.00 | 10.00 | C(1), U, T | - | DDS | Float | 1 |
| | Time taken for motor to accelerate from standstill up to maximum motor frequency (P1082) when no rounding is used. Setting the ramp-up time too short can cause the inverter to trip (overcurrent F1). | | | | | | | |
| Dependency: | Rounding times (P1130 - P1133) and rounding type (P1134) will also have influence on the ramp. See also P3350, P3353. | | | | | | | |
| Notice: | Ramp times will be used as follows: <ul style="list-style-type: none"> • P1060 / P1061 : JOG mode is active • P1120 / P1121 : Normal mode (ON / OFF) is active • P1060 / P1061 : Normal mode (ON / OFF) and P1124 is active | | | | | | | |
| Note: | If an external frequency setpoint with set ramp rates is used (e.g. from a PLC), the best way to achieve optimum inverter performance is to set ramp times in P1120 and P1121 slightly shorter than those of the PLC. Changes to P1120 will be immediately effective. If the SuperTorque function is enabled, the inverter will initially ramp using the value in P3353. | | | | | | | |
| P1121[0...2] | Ramp-down time [s] | 0.00 - 650.00 | 10.00 | C(1), U, T | - | DDS | Float | 1 |
| | Time taken for motor to decelerate from maximum motor frequency (P1082) down to standstill when no rounding is used. | | | | | | | |
| Dependency: | See also P3350, P3353. | | | | | | | |
| Notice: | Setting the ramp-down time too short can cause the inverter to trip (overcurrent F1 / overvoltage F2). See P1120 | | | | | | | |
| Note: | Changes to P1121 will be immediately effective. See P1120 | | | | | | | |
| P1124[0...2] | BI: Enable JOG ramp times | - | 0 | T | - | CDS | U32 / Bin | 3 |
| | Defines source for switching between jog ramp times (P1060, P1061) and normal ramp times (P1120, P1121) as applied to the RFG. This parameter is valid for normal mode (ON / OFF) only. | | | | | | | |
| Dependency: | See also P1175. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|---|-------------------------|-----------------|----------------|---------|----------|-----------|------------|
| Notice: | P1124 does not have any impact when JOG mode is selected. In this case, jog ramp times (P1060, P1061) will be used all the time. If the Dual Ramp function is selected using P1175, ramp times will switch between normal (P1120, P1121) and JOG (P1060, P1061) ramp times, depending on the settings of P2150, P2157 and P2159. Therefore, it is not recommended that JOG ramp is selected at the same time as Dual Ramp. See P1120 | | | | | | | |
| P1130[0...2] | Ramp-up initial rounding time [s] | 0.00 - 40.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines rounding time in seconds at start of ramp-up. | | | | | | | |
| Notice: | Rounding times are recommended, since they prevent an abrupt response, thus avoiding detrimental effects on the mechanics. Rounding times are not recommended when analog inputs are used, since they would result in overshoot / undershoot in the inverter response. | | | | | | | |
| Note: | If short or zero ramp times (P1120, P1121 < P1130, P1131, P1132, P1133) are set, the total ramp up time (t_{up}) or ramp down time (t_{down}) will not depend on P1130. | | | | | | | |
| P1131[0...2] | Ramp-up final rounding time [s] | 0.00 - 40.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines rounding time at end of ramp-up. | | | | | | | |
| Notice: | See P1130 | | | | | | | |
| P1132[0...2] | Ramp-down initial rounding time [s] | 0.00 - 40.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines rounding time at start of ramp-down. | | | | | | | |
| Notice: | See P1130 | | | | | | | |
| P1133[0...2] | Ramp-down final rounding time [s] | 0.00 - 40.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines rounding time at end of ramp-down. | | | | | | | |
| Notice: | See P1130 | | | | | | | |
| P1134[0...2] | Rounding type | 0 - 1 | 0 | U, T | - | DDS | U16 | 2 |
| | Defines the smoothing which is active by setpoint modifications during acceleration or deceleration (e.g. new setpoint, OFF1, OFF3, REV). This smoothing is applied, if the motor is ramped-up or ramped-down and <ul style="list-style-type: none"> • P1134 = 0, • P1132 > 0, P1133 > 0 and • the setpoint is not yet reached. | | | | | | | |
| | 0 | Continuous smoothing | | | | | | |
| | 1 | Discontinuous smoothing | | | | | | |
| Dependency: | Effect only when P1130 (Ramp-up initial rounding time) or P1131 (Ramp-up final rounding time) or P1132 (Ramp-down initial rounding time) or P1133 (Ramp-down final rounding time) > 0 s. | | | | | | | |
| P1135[0...2] | OFF3 ramp-down time [s] | 0.00 - 650.00 | 5.00 | C(1), U, T | - | DDS | Float | 2 |
| | Defines ramp-down time from maximum frequency to standstill for OFF3 command. Settings in P1130 and P1134 will have no effect on OFF3 ramp-down characteristic. An initial ramp-down rounding time of approximately 10% of P1135 is however included. For the total OFF3 ramp-down time: $t_{down,OFF3} = f(P1134) = 1.1 * P1135 * (f_2 / P1082)$ | | | | | | | |
| Note: | This time may be exceeded if the Vdc_max level is reached. | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | |
|--------------------|--|-------|-----------------|----------------|---------|----------|-----------|------------|--|
| P1140[0...2] | BI: RFG enable | - | 1 | T | - | CDS | U32 / Bin | 3 | |
| | Defines command source of RFG enable command (RFG: ramp function generator). If binary input is equal to zero then the RFG output will be set immediately to 0. | | | | | | | | |
| P1141[0...2] | BI: RFG start | - | 1 | T | - | CDS | U32 / Bin | 3 | |
| | Defines command source of RFG start command (RFG: ramp function generator). If binary input is equal to zero then the RFG output is held at its present value. | | | | | | | | |
| P1142[0...2] | BI: RFG enable setpoint | - | 1 | T | - | CDS | U32 / Bin | 3 | |
| | Defines command source of RFG enable setpoint command (RFG: ramp function generator). If binary input is equal to zero, the RFG input will be set to zero and the RFG output will ramp-down to zero. | | | | | | | | |
| r1170 | CO: Frequency setpoint after RFG [Hz] | - | - | - | - | - | Float | 3 | |
| | Displays overall frequency setpoint after ramp generator. | | | | | | | | |
| P1175[0...2] | BI: Dual ramp enable | - | 0 | T | - | CDS | U32 / Bin | 3 | |
| | Defines command source of dual ramp enable command. If binary input is equal to one, then the dual ramp will be applied. This works as follows: | | | | | | | | |
| | 1. Ramp-up: | | | | | | | | |
| | – Inverter starts ramp-up using ramp time from P1120 | | | | | | | | |
| | – When $f_{act} > P2157$, switch to ramp time from P1060 | | | | | | | | |
| | 2. Ramp-down: | | | | | | | | |
| | – Inverter starts ramp-down using ramp time from P1061 | | | | | | | | |
| | – When $f_{act} < P2159$, switch to ramp time from P1121 | | | | | | | | |
| | Output frequency (Hz) | | | | | | | | |
| | P2159 (Hz) | | | | | | | | |
| | P2157 (Hz) | | | | | | | | |
| | -P2157 (Hz) | | | | | | | | |
| | -P2159 (Hz) | | | | | | | | |
| | +ve setpoint | | | | | | | | |
| | -ve setpoint | | | | | | | | |
| | ON | | | | | | | | |
| | OFF 1 | | | | | | | | |
| | P1175 | | | | | | | | |
| | 1 | | | | | | | | |
| | 0 | | | | | | | | |
| Dependency: | See P2150, P2157, P2159, r2198. | | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | |
|-----------------|---|---|-----------------|----------------|-----------------|-----------------|-----------|------------|--|--|--|--|--|--|--|
| Note: | The dual ramp algorithm uses r2198 bits 1 and 2 to determine ($f_{act} > P2157$) and ($f_{act} < P2159$). P2150 is used to apply hysteresis to these settings, so the user may wish to change the value of this parameter to make the dual ramp function more responsive. It is not recommended that the dual ramp function is used in conjunction with JOG ramp. See P1124. | | | | | | | | | | | | | | |
| r1199.7...12 | CO / BO: RFG status word | - | - | - | - | - | U16 | 3 | | | | | | | |
| | Displays status of ramp function generator (RFG). | | | | | | | | | | | | | | |
| | Bit | Signal name | | | 1 signal | 0 signal | | | | | | | | | |
| | 07 | Ramp #0 active | | | Yes | No | | | | | | | | | |
| | 08 | Ramp #1 active | | | Yes | No | | | | | | | | | |
| | 09 | Ramping finished | | | Yes | No | | | | | | | | | |
| | 10 | Direction right / left | | | Yes | No | | | | | | | | | |
| | 11 | $f_{act} > P2157(f_2)$ | | | Yes | No | | | | | | | | | |
| | 12 | $f_{act} < P2159(f_3)$ | | | Yes | No | | | | | | | | | |
| Note: | See P2157 and P2159. | | | | | | | | | | | | | | |
| P1200 | Flying start | 0 - 6 | 0 | U, T | - | - | U16 | 2 | | | | | | | |
| | Starts inverter onto a spinning motor by rapidly changing the output frequency of the inverter until the actual motor speed has been found. Then, the motor runs up to setpoint using the normal ramp time. | | | | | | | | | | | | | | |
| | 0 | Flying start disabled | | | | | | | | | | | | | |
| | 1 | Flying start always active; searches in both directions | | | | | | | | | | | | | |
| | 2 | Flying start active after power on, fault, OFF2; searches in both directions | | | | | | | | | | | | | |
| | 3 | Flying start active after fault, OFF2; searches in both directions | | | | | | | | | | | | | |
| | 4 | Flying start always active; searches in direction of setpoint only | | | | | | | | | | | | | |
| | 5 | Flying start active after power on, fault, OFF2; searches in direction of setpoint only | | | | | | | | | | | | | |
| | 6 | Flying start active after fault, OFF2; searches in direction of setpoint only | | | | | | | | | | | | | |
| Notice: | Flying start must be used in cases where the motor may still be turning (e.g. after a short mains break) or can be driven by the load. Otherwise, overcurrent trips will occur. | | | | | | | | | | | | | | |
| Note: | Useful for motors with high inertia loads. Settings 1 to 3 search in both directions. Settings 4 to 6 search only in direction of setpoint. | | | | | | | | | | | | | | |
| P1202[0...2] | Motor-current: flying start [%] | 10 - 200 | 100 | U, T | - | DDS | U16 | 3 | | | | | | | |
| | Defines search current used for flying start. Value is in [%] based on rated motor current (P0305). | | | | | | | | | | | | | | |
| Note: | Reducing the search current may improve performance for flying start if the inertia of the system is not very high. However, search current settings in P1202 that are below 30% (and sometimes other settings in P1202 and P1203) may cause motor speed to be found prematurely or too late, which can result in F1 or F2 trips. | | | | | | | | | | | | | | |
| P1203[0...2] | Search rate: flying start [%] | 10 - 500 | 100 | U, T | - | DDS | U16 | 3 | | | | | | | |
| | Sets factor (in V/f mode only) by which the output frequency changes during flying start to synchronize with turning motor. This value is entered in [%]. It defines the reciprocal initial gradient in the search sequence. P1203 influences the time taken to search for the motor frequency. | | | | | | | | | | | | | | |
| Example: | For a motor with 50 Hz, 1350 rpm, 100 % would produce a maximum search time of 600 ms. | | | | | | | | | | | | | | |
| Note: | A higher value produces a flatter gradient and thus a longer search time. A lower value has the opposite effect. | | | | | | | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | |
|---|---|--|-----------------|----------------|---------|----------|-----------|------------|--|--|--|--|--|--|--|
| r1204 | Status word: flying start V/f | - | - | - | - | - | U16 | 4 | | | | | | | |
| Bit parameter for checking and monitoring states during search. | | | | | | | | | | | | | | | |
| | Bit | Signal name | | | | 1 signal | 0 signal | | | | | | | | |
| | 00 | Current applied | | | | Yes | No | | | | | | | | |
| | 01 | Current could not be applied | | | | Yes | No | | | | | | | | |
| | 02 | Voltage reduced | | | | Yes | No | | | | | | | | |
| | 03 | Slope-filter started | | | | Yes | No | | | | | | | | |
| | 04 | Current less threshold | | | | Yes | No | | | | | | | | |
| | 05 | Current-minimum | | | | Yes | No | | | | | | | | |
| | 07 | Speed could not be found | | | | Yes | No | | | | | | | | |
| P1210 | Automatic restart | 0 - 7 | 1 | U, T | - | - | U16 | 2 | | | | | | | |
| Configures automatic restart function. | | | | | | | | | | | | | | | |
| | 0 | Disabled | | | | | | | | | | | | | |
| | 1 | Trip reset after power on, P1211 disabled | | | | | | | | | | | | | |
| | 2 | Restart after mains blackout, P1211 disabled | | | | | | | | | | | | | |
| | 3 | Restart after mains brownout or fault, P1211 enabled | | | | | | | | | | | | | |
| | 4 | Restart after mains brownout, P1211 enabled | | | | | | | | | | | | | |
| | 5 | Restart after mains blackout and fault, P1211 disabled | | | | | | | | | | | | | |
| | 6 | Restart after mains brown- /blackout or fault, P1211 enabled | | | | | | | | | | | | | |
| | 7 | Restart after mains brown- /blackout or fault, trip when P1211 expires | | | | | | | | | | | | | |
| Dependency: | Automatic restart requires constant ON command via a digital input wire link. | | | | | | | | | | | | | | |
| Caution: | P1210 > 2 can cause the motor to restart automatically without toggling the ON command! | | | | | | | | | | | | | | |
| Notice: | <p>A "mains brownout" is a very short mains break, where the DC link has not fully collapsed before the power is reapplied.</p> <p>A "mains blackout" is a long mains break, where the DC link has fully collapsed before the power is re-applied.</p> <p>"Delay Time" is the time between attempts of quitting fault. The "Delay Time" of first attempt is 1 second, then it will be doubled every next attempt.</p> <p>The "Number of Restart Attempts" can be set in P1211. This is the number of restarts the inverter will try to quit fault.</p> <p>When faults are quit and after 4 seconds of no fault condition, "Number of Restart Attempts" will be reset to P1211 and "Delay Time" will be reset to 1 second.</p> <p>P1210 = 0: Automatic restart is disabled.</p> <p>P1210 = 1: The inverter will acknowledge (reset) faults i.e. it will reset a fault when the power is re-applied. This means the inverter must be fully powered down, a brownout is not sufficed. The inverter will not run until the ON command has been toggled.</p> <p>P1210 = 2: The inverter will acknowledge the fault F3 at power on after blackout and restarts the inverter. It is necessary that the ON command is wired via a digital input (DI).</p> <p>P1210 = 3: For these settings it is fundamental that the inverter only restarts if it has been in a RUN state at the time of the faults (F3, etc.). The inverter will acknowledge the fault and restarts the inverter after a brownout. It is necessary that the ON command is wired via a digital input (DI).</p> | | | | | | | | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|-----------------|---|------------------------------|-----------------|----------------|---------|----------|-----------|------------|
| | P1210 = 4: For these settings it is fundamental that the inverter only restarts if it has been in a RUN state at the time of the fault (F3). The inverter will acknowledge the fault and restarts the inverter after a brownout. It is necessary that the ON command is wired via a digital input (DI). P1210 = 5: The inverter will acknowledge the faults F3 etc. at power on after blackout and restarts the inverter. It is necessary that the ON command is wired via a digital input (DI). P1210 = 6: The inverter will acknowledge the faults (F3 etc.) at power on after blackout or brownout and restarts the inverter. It is necessary that the ON command is wired via a digital input (DI). Setting 6 causes the motor to restart immediately. P1210 = 7: The inverter will acknowledge the faults (F3 etc.) at power on after blackout or brownout and restarts the inverter. It is necessary that the ON command is wired via a digital input (DI). Setting 7 causes the motor to restart immediately. The difference between this mode and Mode 6 is that the fault status bit (r0052.3) is not set until the number of restarts defined by P1211 have been exhausted. Flying start must be used in cases where the motor may still be turning (e.g. after a short mains break) or can be driven by the load (P1200). | | | | | | | |
| P1211 | Number of restart attempts | 0 - 10 | 3 | U, T | - | - | U16 | 3 |
| | Specifies number of times inverter will attempt to restart if automatic restart P1210 is activated. | | | | | | | |
| P1215 | Holding brake enable | 0 - 1 | 0 | C, T | - | - | U16 | 2 |
| | Enables / disables holding brake function. The motor holding brake (MHB) is controlled via status word 1 r0052 bit 12. This signal can be issued via: <ul style="list-style-type: none">• status word of the serial interface (e.g. USS)• digital outputs (e.g. DO1: ==> P0731 = 52.C (r0052 bit 12)) | | | | | | | |
| | 0 | Motor holding brake disabled | | | | | | |
| | 1 | Motor holding brake enabled | | | | | | |
| Caution: | It is not permissible to use the motor holding brake as working brake, as it is generally only designed for a limited number of emergency braking operations. | | | | | | | |
| P1216 | Holding brake release delay[s] | 0.0 - 20.0 | 1.0 | C, T | - | - | Float | 2 |
| | Defines period during which inverter runs at minimum frequency P1080 before ramping up. | | | | | | | |
| P1217 | Holding time after ramp down [s] | 0.0 - 20.0 | 1.0 | C, T | - | - | Float | 2 |
| | Defines time for which inverter runs at minimum frequency (P1080) after ramping down. | | | | | | | |
| Note: | If P1217 > P1227, P1227 will take precedence. | | | | | | | |
| P1218[0...2] | BI: Motor holding brake override | - | 0 | U, T | - | CDS | U32 / Bin | 3 |
| | Enables the motor holding brake output to be overridden, allowing the brake to be opened under separate control. | | | | | | | |
| P1227[0...2] | Zero speed detection monitoring time [s] | 0.0 - 300.0 | 4.0 | U, T | - | DDS | Float | 2 |
| | Sets the monitoring time for the standstill identification. When braking with OFF1 or OFF3, standstill is identified after this time has expired, after the setpoint speed has fallen below P2167. After this, the braking signal is started, the system waits for the closing time and then the pulses are cancelled. | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|-----------------|---|---------------|-----------------|----------------|---------|----------|-----------|------------|
| Note: | P1227 = 300.0: function is deactivated P1227 = 0.0: pulses are locked immediately If P1217 > P1227, P1227 will take precedence. | | | | | | | |
| P1230[0...2] | Bl: Enable DC braking | - | 0 | U, T | - | CDS | U32 / Bin | 3 |
| | Enables DC braking via a signal applied from an external source. Function remains active while external input signal is active. DC braking causes the motor to stop rapidly by applying a DC braking current (current applied also holds shaft stationary). When the DC braking signal is applied, the inverter output pulses are blocked and the DC current is not applied until the motor has been sufficiently demagnetized. This delay time is set in P0347 (demagnetization time). If this delay is too short, overcurrent trips can occur. The level of DC braking is set in P1232 (DC braking current - relative to the rated motor current) which is set to 100 % by default. | | | | | | | |
| Caution: | With the DC braking, the kinetic energy of the motor is converted into heat in the motor. The inverter could overheat if it remains in this status for an excessive period of time! | | | | | | | |
| P1232[0...2] | DC braking current [%] | 0 - 250 | 100 | U, T | - | DDS | U16 | 2 |
| | Defines level of DC current relative to rated motor current (P0305). The DC braking can be issued observing the following dependencies: <ul style="list-style-type: none"> • OFF1 / OFF3 ==> see P1233 • BICO ==> see P1230 | | | | | | | |
| P1233[0...2] | Duration of DC braking [s] | 0.00 - 250.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines duration for which DC braking is active following an OFF1 or OFF3 command. When an OFF1 or OFF3 command is received by the inverter, the output frequency starts to ramp to 0 Hz. When the output frequency reaches the value set in P1234, the inverter injects a DC braking current P1232 for the time duration set in P1233. | | | | | | | |
| Caution: | See P1230 | | | | | | | |
| Notice: | The DC braking function causes the motor to stop rapidly by applying a DC braking current. When the DC braking signal is applied, the inverter output pulses are blocked and the DC current not applied until the motor has been sufficiently demagnetized (demagnetization time is calculated automatically from motor data). | | | | | | | |
| Note: | P1233 = 0 means that DC braking is not activated. | | | | | | | |
| P1234[0...2] | DC braking start frequency [Hz] | 0.00 - 599.00 | 599.00 | U, T | - | DDS | Float | 2 |
| | Sets start frequency for DC braking. When an OFF1 or OFF3 command is received by the inverter, the output frequency starts to ramp to 0 Hz. When the output frequency reaches the value set in start frequency of DC braking P1234, the inverter injects a DC braking current P1232 for the time duration set in P1233. | | | | | | | |
| P1236[0...2] | Compound braking current [%] | 0 - 250 | 0 | U, T | - | DDS | U16 | 2 |
| | Defines DC level superimposed on AC waveform after exceeding DC-link voltage threshold of compound braking. The value is entered in [%] relative to rated motor current (P0305). Compound braking switch-on level (V_DC,Comp): If P1254 = 0 --> V_DC,Comp = $1.13 * \sqrt{2} * V_{\text{mains}} = 1.13 * \sqrt{2} * P0210$ otherwise V_DC,Comp = $0.98 * r1242$ The Compound Brake is an overlay of the DC brake function with regenerative braking (effective braking at the ramp) after OFF1 or OFF3. This enables braking with controlled motor frequency and a minimum of energy returned to the motor. Through optimization of the ramp-down time and the compound braking an efficient braking without additional HW components is possible. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | |
|--------------------|---|------------------|-----------------|----------------|---------|----------|-----------|------------|--|--|--|--|--|--|--|
| Dependency: | Compound braking depends on the DC link voltage only (see threshold above). This will happen on OFF1, OFF3 and any regenerative condition. It is disabled, when: | | | | | | | | | | | | | | |
| | <ul style="list-style-type: none"> • DC braking is active • Flying start is active | | | | | | | | | | | | | | |
| Notice: | <p>Increasing the value will generally improve braking performance; however, if you set the value too high, an overcurrent trip may result.</p> <p>If used with dynamic braking enabled as well compound braking will take priority.</p> <p>If used with the Vdc_max controller enabled the inverter behavior when braking may be worsened particularly with high values of compound braking.</p> | | | | | | | | | | | | | | |
| Note: | P1236 = 0 means that compound braking is not activated. | | | | | | | | | | | | | | |
| P1237 | Dynamic braking | 0 - 5 | 0 | U, T | - | - | U16 | 2 | | | | | | | |
| | <p>Dynamic braking absorbs the braking energy in a chopper resistor.</p> <p>This parameter defines the rated duty cycle of the braking resistor (chopper resistor).</p> <p>Dynamic braking is active when the function is enabled and DC-link voltage exceeds the dynamic braking switch-on level.</p> <p>Dynamic braking switch-on level (V_DC,Chopper) :</p> <p>If P1254 = 0 --> V_DC,Chopper = 1.13 * sqrt(2) * V_mains = 1.13 * sqrt(2) * P0210 otherwise V_DC,Chopper = 0.98 * r1242</p> | | | | | | | | | | | | | | |
| | 0 | Disabled | | | | | | | | | | | | | |
| | 1 | 5 % duty cycle | | | | | | | | | | | | | |
| | 2 | 10 % duty cycle | | | | | | | | | | | | | |
| | 3 | 20 % duty cycle | | | | | | | | | | | | | |
| | 4 | 50 % duty cycle | | | | | | | | | | | | | |
| | 5 | 100 % duty cycle | | | | | | | | | | | | | |
| Note: | This parameter is only applicable for inverters of frame size D. For frame sizes A to C, the duty cycle of the braking resistor can be selected with the dynamic braking module (see Appendix "Dynamic braking module (Page 257)"). | | | | | | | | | | | | | | |
| Dependency: | If dynamic braking is used with DC braking enabled as well as compound braking, DC braking and compound braking will take priority. | | | | | | | | | | | | | | |
| | <pre> graph TD A{DC braking P1233 > 0 ?} -- yes --> B[DC braking enabled] A -- no --> C{Compound braking P1236 > 0 ?} C -- yes --> D[Compound braking enabled] C -- no --> E{Dynamic braking P1237 > 0 ?} E -- yes --> F[Dynamic braking enabled] E -- no --> G[Disabled] </pre> | | | | | | | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|---|--|-----------------|----------------|---------|----------|-----------|------------|
| Notice: | Initially the brake will operate at a high duty cycle dependant on the DC link level until the thermal limit is approached. The duty cycle specified by this parameter will then be imposed. The resistor should be able to operate at this level indefinitely without overheating. | | | | | | | |
| | $t_{\text{Chopper, ON}} = \frac{x}{100} \cdot t_{\text{Chopper}}$ $\Delta V = 17.0 \text{ V for } 380 - 480 \text{ V}$ | | | | | | | |
| | The threshold for the warning A535 is equivalent to 10 seconds running at 95 % duty cycle. The duty cycle will be limited when it was running 12 seconds at 95 % duty cycle. | | | | | | | |
| P1240[0...2] | Configuration of Vdc controller | 0 - 3 | 1 | C, T | - | DDS | U16 | 3 |
| | Enables / disables Vdc controller. The Vdc controller dynamically controls the DC link voltage to prevent overvoltage trips on high inertia systems. | | | | | | | |
| | 0 | Vdc controller disabled | | | | | | |
| | 1 | Vdc_max controller enabled | | | | | | |
| | 2 | Kinetic buffering (Vdc_min controller) enabled | | | | | | |
| | 3 | Vdc_max controller and kinetic buffering (KIB) enabled | | | | | | |
| Caution: | If P1245 increased too much, it may interfere with the inverter normal operation. | | | | | | | |
| Note: | <ul style="list-style-type: none"> Vdc_max controller: Vdc_max controller automatically increases ramp-down times to keep the DC-link voltage (r0026) within limits (r1242). Vdc_min controller: Vdc_min is activated if DC-link voltage falls below the switch on level P1245. The kinetic energy of the motor is then used to buffer the DC-link voltage, thus causing deceleration of the inverter. If the inverter trips with F3 immediately, try increasing the dynamic factor P1247 first. If still tripping with F3 try then increasing the switch on level P1245. | | | | | | | |
| r1242 | CO: Switch-on level of Vdc_max [V] | - | - | - | - | - | Float | 3 |
| | Displays switch-on level of Vdc_max controller. Following equation is only valid, if P1254 = 0: $r1242 = 1.15 * \sqrt{2} * V_{\text{mains}} = 1.15 * \sqrt{2} * P0210$ otherwise r1242 is internally calculated. | | | | | | | |
| P1243[0...2] | Dynamic factor of Vdc_max [%] | 10 - 200 | 100 | U, T | - | DDS | U16 | 3 |
| | Defines dynamic factor for DC link controller. | | | | | | | |
| Dependency: | P1243 = 100 % means P1250, P1251 and P1252 (gain, integration time and differential time) are used as set. Otherwise, these are multiplied by P1243 (dynamic factor of Vdc_max). | | | | | | | |
| Note: | Vdc controller adjustment is calculated automatically from motor and inverter data. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | |
|--------------------|--|------------------------------------|-----------------|----------------|---------|----------|-----------|------------|--|
| P1245[0...2] | Switch on level kinetic buffering [%] | 65 - 95 | 76 | U, T | - | DDS | U16 | 3 | |
| | Enter switch-on level for kinetic buffering (KIB) in [%] relative to supply voltage (P0210). $r1246[V] = (P1245[%] / 100) * \sqrt{2} * P0210$ | | | | | | | | |
| Warning: | Increasing the value too much, may interfere with the inverter normal operation. | | | | | | | | |
| Note: | P1254 has no effect on the switch-on-level for kinetic buffering. | | | | | | | | |
| r1246[0...2] | CO: Switch-on level kinetic buffering [V] | - | - | - | - | DDS | Float | 3 | |
| | Displays switch-on level of kinetic buffering (KIB, Vdc_min controller). If the dc-link voltage drops below the value in r1246, kinetic buffering will be activated. That means the motor frequency will be reduced in order to keep Vdc within the valid range. If there is not enough regenerative energy, the inverter trips with undervoltage. | | | | | | | | |
| P1247[0...2] | Dynamic factor of kinetic buffering [%] | 10 - 200 | 100 | U, T | - | DDS | U16 | 3 | |
| | Enters dynamic factor for kinetic buffering (KIB, Vdc_min controller). P1247 = 100 % means P1250, P1251 and P1252 (gain, integration time and differential time) are used as set. Otherwise, these are multiplied by P1247 (dynamic factor of Vdc_min). | | | | | | | | |
| Note: | Vdc controller adjustment is calculated automatically from motor and inverter data. | | | | | | | | |
| P1250[0...2] | Gain of Vdc controller | 0.00 - 10.00 | 1.00 | U, T | - | DDS | Float | 3 | |
| | Enters gain for Vdc controller. | | | | | | | | |
| P1251[0...2] | Integration time Vdc controller [ms] | 0.1 - 1000.0 | 40.0 | U, T | - | DDS | Float | 3 | |
| | Enters integral time constant for Vdc controller. | | | | | | | | |
| P1252[0...2] | Differential time Vdc controller [ms] | 0.0 - 1000.0 | 1.0 | U, T | - | DDS | Float | 3 | |
| | Enters differential time constant for Vdc controller. | | | | | | | | |
| P1253[0...2] | Vdc controller output limitation [Hz] | 0.00 - 599.00 | 10.00 | U, T | - | DDS | Float | 3 | |
| | Limits maximum effect of Vdc_max controller. | | | | | | | | |
| Dependency: | This parameter is influenced by automatic calculations defined by P0340. | | | | | | | | |
| Note: | The Factory setting depends on inverter power. | | | | | | | | |
| P1254 | Auto detect Vdc switch-on levels | 0 - 1 | 1 | C, T | - | - | U16 | 3 | |
| | Enables / disables auto-detection of switch-on levels for Vdc_max controller. For best results, it is recommended to set P1254 = 1 (auto-detection of Vdc switch-on levels enabled). Setting P1254 = 0 is only recommended when there is a high degree of fluctuation of the DC-link when the motor is being driven. Note that the auto detection only works when the inverter has been in standby for over 20s. | | | | | | | | |
| | 0 | Disabled | | | | | | | |
| | 1 | Enabled | | | | | | | |
| Dependency: | See P0210 | | | | | | | | |
| P1256[0...2] | Reaction of kinetic buffering | 0 - 2 | 0 | C, T | - | DDS | U16 | 3 | |
| | Enters reaction for kinetic buffering controller (Vdc_min controller). Depending on the setting selected, the frequency limit defined in P1257 is used to either hold the speed or disable pulses. If not enough regeneration is produced, inverter may trip with undervoltage. | | | | | | | | |
| | 0 | Maintain DC-link until trip | | | | | | | |
| | 1 | Maintain DC-link until trip / stop | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | |
|--------------|---|---|-----------------|----------------|---------|----------|-----------|------------|--|--|--|--|--|--|--|
| | 2 | Control stop | | | | | | | | | | | | | |
| Note: | <p>P1256 = 0: Maintain DC-link voltage until mains is returned or inverter is tripped with undervoltage. The frequency is kept above the frequency limit provided in P1257.</p> <p>P1256 = 1: Maintain DC-link voltage until mains is returned or inverter is tripped with undervoltage or pulses are disabled when frequency falls below the limit in P1257.</p> <p>P1256 = 2: This option ramps down the frequency to standstill even when mains return. If mains do not return, frequency brought down under the control of Vdc_min controller until P1257 limit. Then pulses are disabled or undervoltage has occurred. If mains return, then an OFF1 is active until P1257 limit. Then pulses are disabled.</p> | | | | | | | | | | | | | | |
| P1257[0...2] | Frequency limit for kinetic buffering [Hz] | 0.00 - 599.00 | 2.50 | U, T | - | DDS | Float | 3 | | | | | | | |
| | Frequency which kinetic buffering (KIB) either hold speed or disable pulses depending on P1256. | | | | | | | | | | | | | | |
| P1300[0...2] | Control mode | 0 - 19 | 0 | C(1), T | - | DDS | U16 | 2 | | | | | | | |
| | Parameter to select the control method. Controls relationship between speed of motor and voltage supplied by inverter. | | | | | | | | | | | | | | |
| | 0 | V/f with linear characteristic | | | | | | | | | | | | | |
| | 1 | V/f with FCC | | | | | | | | | | | | | |
| | 2 | V/f with quadratic characteristic | | | | | | | | | | | | | |
| | 3 | V/f with programmable characteristic | | | | | | | | | | | | | |
| | 4 | V/f with linear eco | | | | | | | | | | | | | |
| | 5 | V/f for textile applications | | | | | | | | | | | | | |
| | 6 | V/f with FCC for textile applications | | | | | | | | | | | | | |
| | 7 | V/f with quadratic eco | | | | | | | | | | | | | |
| | 19 | V/f control with independent voltage setpoint | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | |
| Note: | <p>P1300 = 1: V/f with FCC (flux current control)</p> <ul style="list-style-type: none"> Maintains motor flux current for improved efficiency If FCC is chosen, linear V/f is active at low frequencies <p>P1300 = 2: V/f with a quadratic characteristic</p> <ul style="list-style-type: none"> Suitable for centrifugal fans / pumps <p>P1300 = 3: V/f with a programmable characteristic</p> <ul style="list-style-type: none"> User defined characteristic (see P1320) <p>P1300 = 4: V/f with linear characteristic and Economy Mode</p> <ul style="list-style-type: none"> Linear characteristic with Economy Mode Modifies the output voltage to reduce power consumption | | | | | | | | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--------------|---|-------------|-----------------|----------------|---------|----------|-----------|------------|----|--|--|--|--|--|---|---|---|---|---|---|----|----------|--------------|---|---|---|---|---|---|---|---|----------|------------------|---|---|---|---|---|---|---|---|----------|--------------------|---|---|---|---|---|---|---|---|----------|----------------|---|---|---|---|---|---|---|---|----------|---------------------|---|---|---|---|---|---|---|---|----------|---------------------------------|---|---|---|---|---|---|---|---|----------|---------------------------------|---|---|---|---|---|---|---|---|----------|---------------------------------|---|---|---|---|---|---|---|---|----------|---------------------------------|---|---|---|---|---|---|---|---|----------|---------------------------------|---|---|---|---|---|---|---|---|----------|---------------------------------|---|---|---|---|---|---|---|---|----------|----------------------|---|---|---|---|---|---|---|---|----------|-------------------------|---|---|---|---|---|---|---|---|----------|-------------------|---|---|---|---|---|---|---|---|----------|----------------|---|---|---|---|---|---|---|---|----------|----------------------------|---|---|---|---|---|---|---|---|----------|----------------------------------|---|---|---|---|---|---|---|---|----------|-------------------------------|---|---|---|---|---|---|---|---|----------|----------------------------|---|---|---|---|---|---|---|---|----------|----------------------------------|---|---|---|---|---|---|---|---|----------|--------------------|---|---|---|---|---|---|---|---|--|--|--|--|--|--|--|--|
| | <p>P1300 = 5,6: V/f for textile applications</p> <ul style="list-style-type: none"> • Slip compensation disabled. • Imax controller modifies the output voltage only. • Imax controller does not influence the output frequency. <p>P1300 = 7: V/f with quadratic characteristic and Economy Mode</p> <ul style="list-style-type: none"> • Quadratic characteristic with Economy Mode • Modifies the output voltage to reduce power consumption <p>P1300 = 19: V/f control with independent voltage setpoint</p> <p>The following table presents an overview of control parameters (V/f) that can be modified in relationship to P1300 dependencies:</p> <table border="1"> <thead> <tr> <th>Par No.</th> <th>Parameter name</th> <th>Level</th> <th colspan="7">V/f</th> </tr> <tr> <th></th> <th></th> <th></th> <th>0</th> <th>1</th> <th>2</th> <th>3</th> <th>5</th> <th>6</th> <th>19</th> </tr> </thead> <tbody> <tr> <td>P1300[3]</td> <td>Control mode</td> <td>2</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> </tr> <tr> <td>P1310[3]</td> <td>Continuous boost</td> <td>2</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> </tr> <tr> <td>P1311[3]</td> <td>Acceleration boost</td> <td>2</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> </tr> <tr> <td>P1312[3]</td> <td>Starting boost</td> <td>2</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> </tr> <tr> <td>P1316[3]</td> <td>Boost end frequency</td> <td>3</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> </tr> <tr> <td>P1320[3]</td> <td>Programmable V/f freq. coord. 1</td> <td>3</td> <td>-</td> <td>-</td> <td>-</td> <td>x</td> <td>-</td> <td>-</td> <td>-</td> </tr> <tr> <td>P1321[3]</td> <td>Programmable V/f volt. coord. 1</td> <td>3</td> <td>-</td> <td>-</td> <td>-</td> <td>x</td> <td>-</td> <td>-</td> <td>-</td> </tr> <tr> <td>P1322[3]</td> <td>Programmable V/f freq. coord. 2</td> <td>3</td> <td>-</td> <td>-</td> <td>-</td> <td>x</td> <td>-</td> <td>-</td> <td>-</td> </tr> <tr> <td>P1323[3]</td> <td>Programmable V/f volt. coord. 2</td> <td>3</td> <td>-</td> <td>-</td> <td>-</td> <td>x</td> <td>-</td> <td>-</td> <td>-</td> </tr> <tr> <td>P1324[3]</td> <td>Programmable V/f freq. coord. 3</td> <td>3</td> <td>-</td> <td>-</td> <td>-</td> <td>x</td> <td>-</td> <td>-</td> <td>-</td> </tr> <tr> <td>P1325[3]</td> <td>Programmable V/f volt. coord. 3</td> <td>3</td> <td>-</td> <td>-</td> <td>-</td> <td>x</td> <td>-</td> <td>-</td> <td>-</td> </tr> <tr> <td>P1330[3]</td> <td>CI: Voltage setpoint</td> <td>3</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> <td>x</td> </tr> <tr> <td>P1333[3]</td> <td>Start frequency for FCC</td> <td>3</td> <td>-</td> <td>x</td> <td>-</td> <td>-</td> <td>-</td> <td>x</td> <td>-</td> </tr> <tr> <td>P1335[3]</td> <td>Slip compensation</td> <td>2</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>-</td> <td>-</td> <td>-</td> </tr> <tr> <td>P1336[3]</td> <td>CO: Slip limit</td> <td>2</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>-</td> <td>-</td> <td>-</td> </tr> <tr> <td>P1338[3]</td> <td>Resonance damping gain V/f</td> <td>3</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>-</td> <td>-</td> <td>-</td> </tr> <tr> <td>P1340[3]</td> <td>Imax freq. controller prop. gain</td> <td>3</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> </tr> <tr> <td>P1341[3]</td> <td>Imax controller integral time</td> <td>3</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> </tr> <tr> <td>P1345[3]</td> <td>Imax controller prop. gain</td> <td>3</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> </tr> <tr> <td>P1346[3]</td> <td>Imax voltage ctrl. integral time</td> <td>3</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> </tr> <tr> <td>P1350[3]</td> <td>Voltage soft start</td> <td>3</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> <td>x</td> </tr> </tbody> </table> | Par No. | Parameter name | Level | V/f | | | | | | | | | | 0 | 1 | 2 | 3 | 5 | 6 | 19 | P1300[3] | Control mode | 2 | x | x | x | x | x | x | x | P1310[3] | Continuous boost | 2 | x | x | x | x | x | x | x | P1311[3] | Acceleration boost | 2 | x | x | x | x | x | x | x | P1312[3] | Starting boost | 2 | x | x | x | x | x | x | x | P1316[3] | Boost end frequency | 3 | x | x | x | x | x | x | x | P1320[3] | Programmable V/f freq. coord. 1 | 3 | - | - | - | x | - | - | - | P1321[3] | Programmable V/f volt. coord. 1 | 3 | - | - | - | x | - | - | - | P1322[3] | Programmable V/f freq. coord. 2 | 3 | - | - | - | x | - | - | - | P1323[3] | Programmable V/f volt. coord. 2 | 3 | - | - | - | x | - | - | - | P1324[3] | Programmable V/f freq. coord. 3 | 3 | - | - | - | x | - | - | - | P1325[3] | Programmable V/f volt. coord. 3 | 3 | - | - | - | x | - | - | - | P1330[3] | CI: Voltage setpoint | 3 | - | - | - | - | - | - | x | P1333[3] | Start frequency for FCC | 3 | - | x | - | - | - | x | - | P1335[3] | Slip compensation | 2 | x | x | x | x | - | - | - | P1336[3] | CO: Slip limit | 2 | x | x | x | x | - | - | - | P1338[3] | Resonance damping gain V/f | 3 | x | x | x | x | - | - | - | P1340[3] | Imax freq. controller prop. gain | 3 | x | x | x | x | x | x | x | P1341[3] | Imax controller integral time | 3 | x | x | x | x | x | x | x | P1345[3] | Imax controller prop. gain | 3 | x | x | x | x | x | x | x | P1346[3] | Imax voltage ctrl. integral time | 3 | x | x | x | x | x | x | x | P1350[3] | Voltage soft start | 3 | x | x | x | x | x | x | x | | | | | | | | |
| Par No. | Parameter name | Level | V/f | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | 0 | 1 | 2 | 3 | 5 | 6 | 19 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1300[3] | Control mode | 2 | x | x | x | x | x | x | x | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1310[3] | Continuous boost | 2 | x | x | x | x | x | x | x | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1311[3] | Acceleration boost | 2 | x | x | x | x | x | x | x | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1312[3] | Starting boost | 2 | x | x | x | x | x | x | x | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1316[3] | Boost end frequency | 3 | x | x | x | x | x | x | x | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1320[3] | Programmable V/f freq. coord. 1 | 3 | - | - | - | x | - | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1321[3] | Programmable V/f volt. coord. 1 | 3 | - | - | - | x | - | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1322[3] | Programmable V/f freq. coord. 2 | 3 | - | - | - | x | - | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1323[3] | Programmable V/f volt. coord. 2 | 3 | - | - | - | x | - | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1324[3] | Programmable V/f freq. coord. 3 | 3 | - | - | - | x | - | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1325[3] | Programmable V/f volt. coord. 3 | 3 | - | - | - | x | - | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1330[3] | CI: Voltage setpoint | 3 | - | - | - | - | - | - | x | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1333[3] | Start frequency for FCC | 3 | - | x | - | - | - | x | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1335[3] | Slip compensation | 2 | x | x | x | x | - | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1336[3] | CO: Slip limit | 2 | x | x | x | x | - | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1338[3] | Resonance damping gain V/f | 3 | x | x | x | x | - | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1340[3] | Imax freq. controller prop. gain | 3 | x | x | x | x | x | x | x | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1341[3] | Imax controller integral time | 3 | x | x | x | x | x | x | x | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1345[3] | Imax controller prop. gain | 3 | x | x | x | x | x | x | x | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1346[3] | Imax voltage ctrl. integral time | 3 | x | x | x | x | x | x | x | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1350[3] | Voltage soft start | 3 | x | x | x | x | x | x | x | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P1310[0...2] | Continuous boost [%] | 0.0 - 250.0 | 50.0 | U, T | PERCENT | DDS | Float | 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <p>Defines boost level in [%] relative to P0305 (rated motor current) applicable to both linear and quadratic V/f curves.</p> <p>At low output frequencies the output voltage is low to keep the flux level constant. However, the output voltage may be too low for the following:</p> <ul style="list-style-type: none"> • magnetization the asynchronous motor • hold the load • overcome losses in the system. <p>The inverter output voltage can be increased via P1310 for the compensation of losses, hold loads at 0 Hz or maintain the magnetization.</p> <p>The magnitude of the boost in Volt at a frequency of zero is defined as follows:</p> $V_{ConBoost,100} = P0305 * Rsadj * (P1310 / 100)$ <p>Note:</p> <p>Rsadj = stator resistance adjusted for temperature</p> $Rsadj = (r0395 / 100) * (P0304 / (\sqrt{3} * P0305)) * P0305 * \sqrt{3}$ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|-------------|-----------------|----------------|---------|----------|-----------|------------|
| Note: | <p>Increasing the boost levels increases motor heating (especially at standstill). Setting in P0640 (motor overload factor [%]) limits the boost: $\text{sum(V_Boost)} / (\text{P0305} * \text{Rsadj}) \leq \text{P1310} / 100$</p> <p>The boost values are combined when continuous boost (P1310) used in conjunction with other boost parameters (acceleration boost P1311 and starting boost P1312). However priorities are allocated to these parameters as follows: $\text{P1310} > \text{P1311} > \text{P1312}$</p> <p>The total boost is limited by following equation: $\text{sum(V_Boost)} \leq 3 * \text{R_S} * \text{I_Mot} = 3 * \text{P0305} * \text{Rsadj}$</p> | | | | | | | |
| P1311[0...2] | Acceleration boost [%] | 0.0 - 250.0 | 0.0 | U, T | PERCENT | DDS | Float | 2 |
| | <p>Applies boost in [%] relative to P0305 (rated motor current) following a positive setpoint change and drops back out once the setpoint is reached.</p> <p>P1311 will only produce boost during ramping, and is therefore useful for additional torque during acceleration and deceleration.</p> <p>As opposed to P1312, which is only active on the first acceleration issued after the ON command, P1311 is always effect during an acceleration and deceleration when issued.</p> <p>The magnitude of the boost in volt at a frequency of zero is defined as follows: $V_{AccBoost,100} = \text{P0305} * \text{Rsadj} * (\text{P1311} / 100)$</p> <p>Note: $\text{Rsadj} = \text{stator resistance adjusted for temperature}$ $\text{Rsadj} = (\text{r0395} / 100) * (\text{P0304} / (\sqrt{3} * \text{P0305})) * \text{P0305} * \sqrt{3}$</p> | | | | | | | |
| Note: | See P1310 | | | | | | | |
| P1312[0...2] | Starting boost [%] | 0.0 - 250.0 | 0.0 | U, T | PERCENT | DDS | Float | 2 |
| | <p>Applies a constant linear offset (in [%] relative to P0305 (rated motor current)) to active V/f curve (either linear or quadratic) after an ON command and is active until:</p> <ol style="list-style-type: none"> ramp output reaches setpoint for the first time respectively setpoint is reduced to less than present ramp output <p>This is useful for starting loads with high inertia. Setting the starting boost (P1312) too high will cause the inverter to limit the current, which will in turn restrict the output frequency to below the setpoint frequency.</p> <p>The magnitude of the boost in volt at a frequency of zero is defined as follows: $V_{StartBoost,100} = \text{P0305} * \text{Rsadj} * (\text{P1312} / 100)$</p> <p>Note: $\text{Rsadj} = \text{stator resistance adjusted for temperature}$ $\text{Rsadj} = (\text{r0395} / 100) * (\text{P0304} / (\sqrt{3} * \text{P0305})) * \text{P0305} * \sqrt{3}$</p> | | | | | | | |
| Note: | See P1310 | | | | | | | |
| r1315 | CO: Total boost voltage [V] | - | - | - | - | - | Float | 4 |
| | Displays total value of voltage boost. | | | | | | | |
| P1316[0...2] | Boost end frequency [%] | 0.0 - 100.0 | 20.0 | U, T | PERCENT | DDS | Float | 3 |
| | <p>Defines point at which programmed boost reaches 50 % of its value. This value is expressed in [%] relative to P0310 (rated motor frequency). The default frequency is defined as follows: $V_{Boost,min} = 2 * (3 + (153 / \sqrt{\text{P_Motor}}))$</p> | | | | | | | |
| Dependency: | This parameter is influenced by automatic calculations defined by P0340. | | | | | | | |
| Note: | <p>The expert user may change this value to alter the shape of the curve, e.g. to increase torque at a particular frequency.</p> <p>Default value is depending on inverter type and its rating data.</p> | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | |
|--------------------|--|---------------|-----------------|----------------|---------|----------|-------------|------------|--|
| P1320[0..2] | Programmable V/f freq. coord. 1 [Hz] | 0.00 - 599.00 | 0.00 | T | - | DDS | Float | 3 | |
| | Sets the frequency of the first point of V/f coordinates (P1320 / 1321 to P1324 / 1325) to define V/f characteristic. These parameter pairs can be used to provide correct torque at correct frequency. | | | | | | | | |
| Dependency: | To set parameter, select P1300 = 3 (V/f with programmable characteristic). The acceleration boost and starting boost defined in P1311 and P1312 are applied to V/f with programmable characteristic. | | | | | | | | |
| Note: | Linear interpolation will be applied between the individual data points. V/f with programmable characteristic (P1300 = 3) has 3 programmable points and 2 non-programmable points. The 2 non-programmable points are: <ul style="list-style-type: none">• Continuous boost P1310 at 0 Hz• Rated motor voltage P0304 at rated motor frequency P0310 | | | | | | | | |
| P1321[0..2] | Programmable V/f volt. coord. 1 [V] | 0.0 - 3000.0 | 0.0 | U, T | - | DDS | Float | 3 | |
| | See P1320 | | | | | | | | |
| P1322[0..2] | Programmable V/f freq. coord. 2 [Hz] | 0.00 - 599.00 | 0.00 | T | - | DDS | Float | 3 | |
| | See P1320 | | | | | | | | |
| P1323[0..2] | Programmable V/f volt. coord. 2 [V] | 0.0 - 3000.0 | 0.0 | U, T | - | DDS | Float | 3 | |
| | See P1320 | | | | | | | | |
| P1324[0..2] | Programmable V/f freq. coord. 3 [Hz] | 0.00 - 599.00 | 0.00 | T | - | DDS | Float | 3 | |
| | See P1320 | | | | | | | | |
| P1325[0..2] | Programmable V/f volt. coord. 3 [V] | 0.0 - 3000.0 | 0.0 | U, T | - | DDS | Float | 3 | |
| | See P1320 | | | | | | | | |
| P1330[0..2] | Cl: Voltage setpoint | - | 0 | T | - | CDS | U32 / Float | 3 | |
| | BICO parameter for selecting source of voltage setpoint for independent V/f control (P1300 = 19). | | | | | | | | |
| P1333[0..2] | Start frequency for FCC [%] | 0.0 - 100.0 | 10.0 | U, T | PERCENT | DDS | Float | 3 | |
| | Defines start frequency at which FCC (flux current control) is enabled as [%] of rated motor frequency (P0310). | | | | | | | | |
| Notice: | If this value is too low, the system may become unstable. | | | | | | | | |
| P1334[0..2] | Slip compensation activation range [%] | 1.0 - 20.0 | 6.0 | U, T | PERCENT | DDS | Float | 3 | |
| | To set the frequency activation range for slip compensation. The percentage value of P1334 refers to the motor rated frequency P0310. The upper threshold will always stay 4 % above P1334. Range of slip compensation: | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| Dependency: | Slip compensation (P1333) active. | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|---------------|-----------------|----------------|---------|----------|-----------|------------|
| Note: | See P1335. The starting frequency of the slip compensation is P1334 * P0310. | | | | | | | |
| P1335[0...2] | Slip compensation [%] | 0.0 - 600.0 | 0.0 | U, T | PERCENT | DDS | Float | 2 |
| | Parameter dynamically adjusts inverter output frequency so that motor speed is kept constant independent of motor load. In the V/f-control, the motor frequency will always be less than the inverter output frequency due to the slip frequency. For a given output frequency, the motor frequency will drop as load is increased. This behavior, typical for induction motors, can be compensated using slip compensation. P1335 can be used to enable and fine-tune the slip compensation. | | | | | | | |
| Dependency: | Gain adjustment enables fine-tuning of the actual motor speed (see P1460 - gain speed control). P1335 > 0, P1336 > 0, P1337 = 0 if P1300 = 5, 6. | | | | | | | |
| Notice: | The applied value of the slip compensation (scaled by P1335) is limited by following equation: $f_{Slip_comp,max} = r0330 * (P1336 / 100)$ | | | | | | | |
| Note: | P1335 = 0 %: Slip compensation disabled. P1335 = 50 % - 70 %: Full slip compensation at cold motor (partial load). P1335 = 100 % (standard setting for warm stator): Full slip compensation at warm motor (full load). | | | | | | | |
| P1336[0...2] | Slip limit [%] | 0 - 600 | 250 | U, T | - | DDS | U16 | 2 |
| | Compensation slip limit in [%] relative to r0330 (rated motor slip), which is added to frequency setpoint. | | | | | | | |
| Dependency: | Slip compensation (P1335) active. | | | | | | | |
| r1337 | CO: V/f slip frequency [%] | - | - | - | PERCENT | - | Float | 3 |
| | Displays actual compensated motor slip as [%]. $f_{slip} [\text{Hz}] = r1337 [\%] * P0310 / 100$ | | | | | | | |
| Dependency: | Slip compensation (P1335) active. | | | | | | | |
| P1338[0...2] | Resonance damping gain V/f | 0.00 - 10.00 | 0.00 | U, T | - | DDS | Float | 3 |
| | Defines resonance damping gain for V/f. The di / dt of the active current will be scaled by P1338. If di / dt increases the resonance damping circuit decreases the inverter output frequency. | | | | | | | |
| Dependency: | This parameter is influenced by automatic calculations defined by P0340. | | | | | | | |
| Note: | The resonance circuit damps oscillations of the active current which frequently occur during no-load operation. In V/ f modes (see P1300), the resonance damping circuit is active in a range from approx. 6 % to 80 % of rated motor frequency (P0310). If the value of P1338 is too high, this will cause instability (forward control effect). | | | | | | | |
| P1340[0...2] | I_{max} controller proportional gain | 0.000 - 0.499 | 0.030 | U, T | - | DDS | Float | 3 |
| | Proportional gain of the I _{max} controller. The I _{max} controller reduces inverter current if the output current exceeds the maximum motor current (r0067). In linear V/f, parabolic V/f, FCC, and programmable V/f modes the I _{max} controller uses both a frequency controller (see P1340 and P1341) and a voltage controller (see P1345 and P1346). The frequency controller seeks to reduce current by limiting the inverter output frequency (to a minimum of the two times nominal slip frequency). If this action does not successfully remove the overcurrent condition, the inverter output voltage is reduced using the I _{max} voltage controller. When the overcurrent condition has been removed successfully, frequency limiting is removed using the ramp-up time set in P1120. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|----------------|-----------------|----------------|---------|----------|-----------|------------|
| | In linear V/f for textiles, FCC for textiles, or external V/f modes only the I_max voltage controller is used to reduce current (see P1345 and P1346). | | | | | | | |
| Note: | <p>The I_max controller can be disabled by setting the frequency controller integral time P1341 to zero. This disables both the frequency and voltage controllers.</p> <p>Note that when disabled, the I_max controller will take no action to reduce current but overcurrent warnings will still be generated, and the inverter will trip in excessive overcurrent or overload conditions.</p> | | | | | | | |
| P1341[0..2] | Imax controller integral time [s] | 0.000 - 50.000 | 0.300 | U, T | - | DDS | Float | 3 |
| | <p>Integral time constant of the I_max controller.</p> <ul style="list-style-type: none"> • P1341 = 0: I_max controller disabled • P1340 = 0 and P1341 > 0: frequency controller enhanced integral • P1340 > 0 and P1341 > 0: frequency controller normal PI control | | | | | | | |
| Dependency: | This parameter is influenced by automatic calculations defined by P0340. | | | | | | | |
| Note: | See P1340 for further information. The Factory setting depends on inverter power. | | | | | | | |
| r1343 | CO: Imax controller frequency output [Hz] | - | - | - | - | - | Float | 3 |
| | Displays effective frequency limitation. | | | | | | | |
| Dependency: | If I_max controller not in operation, parameter normally shows maximum frequency P1082. | | | | | | | |
| r1344 | CO: Imax controller voltage output [V] | - | - | - | - | - | Float | 3 |
| | Displays amount by which the I_max controller is reducing the inverter output voltage. | | | | | | | |
| P1345[0..2] | Imax voltage controller proportional gain | 0.000 - 5.499 | 0.250 | U, T | - | DDS | Float | 3 |
| | If the output current (r0068) exceeds the maximum current (r0067), the inverter is dynamically controlled by reducing the output voltage. This parameter sets the proportional gain of this controller. | | | | | | | |
| Dependency: | This parameter is influenced by automatic calculations defined by P0340. | | | | | | | |
| Note: | See P1340 for further information. The Factory setting depends on inverter power. | | | | | | | |
| P1346[0..2] | Imax voltage controller integral time [s] | 0.000 - 50.000 | 0.300 | U, T | - | DDS | Float | 3 |
| | <p>Integral time constant of the I_max voltage controller.</p> <ul style="list-style-type: none"> • P1341 = 0: I_max controller disabled • P1345 = 0 and P1346 > 0: I_max voltage controller enhanced integral • P1345 > 0 and P1346 > 0: I_max voltage controller normal PI control | | | | | | | |
| Dependency: | This parameter is influenced by automatic calculations defined by P0340. | | | | | | | |
| Note: | See P1340 for further information. The Factory setting depends on inverter power. | | | | | | | |
| r1348 | Economy mode factor [%] | - | - | - | PERCENT | - | Float | 2 |
| | Displays the calculated economy mode factor (range 80%-120%) applied to the demanded output volts. Economy mode is used to find the most efficient operating point for a given load. It does this by a continuous method of hill climbing optimization. Hill climbing optimization works by slightly changing the output volts either up or down and monitoring the change in input power. If the input power has decreased, the algorithm changes the output volts in the same direction. If the input power has increased then the algorithm adjusts the output volts in the other direction. Using this algorithm, the software should be able to find the minimum point on the graph between input power and output volts. | | | | | | | |
| Notice: | If this value is too low, the system may become unstable. | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | |
|--------------------|--|-----------------------------|-----------------|----------------|---------|-----------------|-----------------|------------|--|--|--|--|--|--|--|
| P1350[0...2] | Voltage soft start | 0 - 1 | 0 | U, T | - | DDS | U16 | 3 | | | | | | | |
| | Sets whether voltage is built up smoothly during magnetization time (ON) or whether it simply jumps to boost voltage (OFF). | | | | | | | | | | | | | | |
| | 0 | OFF | | | | | | | | | | | | | |
| | 1 | ON | | | | | | | | | | | | | |
| Note: | The settings for this parameter bring benefits and drawbacks: <ul style="list-style-type: none"> • P1350 = 0: OFF (jump to boost voltage) Benefit: flux is built up quickly Drawback: motor may move • P1350 = 1: ON (smooth voltage build-up) Benefit: motor less likely to move Drawback: flux build-up takes longer | | | | | | | | | | | | | | |
| P1780[0...2] | Control word of Rs/Rr-adaption | 0 - 1 | 1 | U, T | - | DDS | U16 | 3 | | | | | | | |
| | Enables thermal adaptation of stator and rotor resistance to reduce torque errors in speed / torque regulation with speed sensor, or speed errors in speed / torque regulation without speed sensor. | | | | | | | | | | | | | | |
| | Bit | Signal name | | | | 1 signal | 0 signal | | | | | | | | |
| | 00 | Enable thermal Rs/Rr-adapt. | | | | Yes | No | | | | | | | | |
| P1800[0...2] | Pulse frequency [kHz] | 2 - 16 | 4 | U, T | - | DDS | U16 | 2 | | | | | | | |
| | Sets pulse frequency of power switches in inverter. The frequency can be changed in steps of 2 kHz. | | | | | | | | | | | | | | |
| Dependency: | The minimum / maximum / default values of the pulse frequency are determined by the used power module. Furthermore the minimum pulse frequency depends on the parameterization of P1082 (maximum frequency) and P0310 (rated motor frequency). | | | | | | | | | | | | | | |
| Note: | If the pulse frequency is increased, maximum inverter current r0209 can be reduced (derating). The derating characteristic depends on the type and power of the inverter. If silent operation is not absolutely necessary, lower pulse frequencies may be selected to reduce inverter losses and radio-frequency emissions. Under certain circumstances, the inverter may reduce the pulse frequency to provide protection against overtemperature (see P0290 and P0291 bit 00). | | | | | | | | | | | | | | |
| r1801[0...1] | CO: Pulse frequency [kHz] | - | - | - | - | - | U16 | 3 | | | | | | | |
| | Displays information about pulse frequency of power switches in inverter. r1801[0] displays the actual inverter pulse frequency. r1801[1] displays the minimum inverter pulse frequency which can be reached when the functions "motor identification" or "inverter overload reaction" are active. If no PM is plugged this parameter is set to 0 kHz. | | | | | | | | | | | | | | |
| Index: | [0] | Actual pulse frequency | | | | | | | | | | | | | |
| | [1] | Minimum pulse frequency | | | | | | | | | | | | | |
| Notice: | Under certain conditions (inverter overtemperature, see P0290), this can differ from the values selected in P1800 (pulse frequency). | | | | | | | | | | | | | | |
| P1802 | Modulator mode | 1 - 3 | 3 | U, T | - | - | U16 | 3 | | | | | | | |
| | Selects inverter modulator mode. | | | | | | | | | | | | | | |
| | 1 | Asymmetric SVM | | | | | | | | | | | | | |
| | 2 | Space vector modulation | | | | | | | | | | | | | |
| | 3 | SVM / ASVM controlled mode | | | | | | | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | |
|--|---|--|----------------------------------|----------------|---------|----------|-----------|------------|--|--|--|--|--|--|--|
| Notice: | <ul style="list-style-type: none"> Asymmetric space vector modulation (ASVM) produces lower switching losses than space vector modulation (SVM), but may cause irregular rotation at very low speeds. Space vector modulation (SVM) with over-modulation may produce current waveform distortion at high output voltages. Space vector modulation (SVM) without over-modulation will reduce maximum output voltage available to motor. | | | | | | | | | | | | | | |
| P1803[0...2] | Maximum modulation [%] | 20.0 - 150.0 | 106.0 | U, T | - | DDS | Float | 3 | | | | | | | |
| Sets maximum modulation index. | | | | | | | | | | | | | | | |
| Note: | P1803 = 100 %: Limit for over-control (for ideal inverter without switching delay). | | | | | | | | | | | | | | |
| P1820[0...2] | Reverse output phase sequence | 0 - 1 | 0 | T | - | DDS | U16 | 2 | | | | | | | |
| Changes sequence of phases without changing setpoint polarity. | | | | | | | | | | | | | | | |
| 0 | | Forward | | | | | | | | | | | | | |
| 1 | | Reverse the Motor | | | | | | | | | | | | | |
| Note: | See P1000 | | | | | | | | | | | | | | |
| P1825 | On-state voltage of IGBT [V] | 0.0 - 20.0 | 0.9 | U, T | - | - | Float | 4 | | | | | | | |
| Corrects on-state voltage of the IGBTs. | | | | | | | | | | | | | | | |
| P1828 | Gating unit dead time [µs] | 0.00 - 3.98 | 0.01 | U, T | - | - | Float | 4 | | | | | | | |
| Sets compensation time of gating unit interlock. | | | | | | | | | | | | | | | |
| P1900 | Select motor data identification | 0 - 2 | 0 | C(1), T | - | - | U16 | 2 | | | | | | | |
| Performs motor data identification. | | | | | | | | | | | | | | | |
| 0 | | Disabled | | | | | | | | | | | | | |
| 2 | | Identification of all parameters in standstill | | | | | | | | | | | | | |
| Dependency: | <p>No measurement if motor data incorrect.</p> <p>P1900 = 2: Calculated value for stator resistance (see P0350) is overwritten.</p> | | | | | | | | | | | | | | |
| Notice: | <p>When the identification is finished P1900 is set to 0. When choosing the setting for measurement, observe the following:</p> <p>The value is actually adopted as P0350 parameter setting and applied to the control as well as being shown in the read-only parameters below. Ensure that the motor holding brake is not active when performing the motor identification.</p> | | | | | | | | | | | | | | |
| Note: | <p>Before selecting motor data identification, "Quick commissioning" has to be performed in advance. Since the cable length of the applications differs in a wide range, the preset resistor P0352 is only a rough estimation. Better results of the motor identification can be achieved by specifying the cable resistor before the start of the motor identification by measuring / calculating.</p> <p>Once enabled (P1900 > 0), A541 generates a warning that the next ON command will initiate measurement of motor parameters.</p> <p>Communications - both via USS as well as via the Modbus - are interrupted for the time that it takes to make internal calculations. These calculations can take up to one minute to complete.</p> | | | | | | | | | | | | | | |
| P1909[0...2] | Control word of motor data identification | - | 0101 1100 0000 0000 bin | U, T | - | DDS | U16 | 4 | | | | | | | |
| Control word of motor data identification. | | | | | | | | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | |
|----------------|--|--|-----------------|----------------|---------|----------|-----------|------------|--|--|--|--|--|--|--|
| | Bit | Signal name | | | | | 1 signal | 0 signal | | | | | | | |
| | 00 | Estimation of Xs | | | | | Yes | No | | | | | | | |
| | 01 | Motor ID at 2 kHz | | | | | Yes | No | | | | | | | |
| | 02 | Estimation of Tr | | | | | Yes | No | | | | | | | |
| | 03 | Estimation of Lsigma | | | | | Yes | No | | | | | | | |
| | 05 | Det. Tr meas. with 2 freq. | | | | | Yes | No | | | | | | | |
| | 06 | Measurement of on voltage | | | | | Yes | No | | | | | | | |
| | 07 | Deadtime detection from Rs measurement | | | | | Yes | No | | | | | | | |
| | 08 | MotID with hw deadtime comp activ | | | | | Yes | No | | | | | | | |
| | 09 | No deadtime detection with 2 freq | | | | | Yes | No | | | | | | | |
| | 10 | Detect Ls with LsBlock method | | | | | Yes | No | | | | | | | |
| | 11 | MotID adaption of magnetizing current | | | | | Yes | No | | | | | | | |
| | 12 | MotID adaption of main reactance | | | | | Yes | No | | | | | | | |
| | 13 | MotID switch off saturation curve optim. | | | | | Yes | No | | | | | | | |
| | 14 | MotID saturation curve optim. all framesizes | | | | | Yes | No | | | | | | | |
| | 15 | MotID saturation curve optim. big framesizes | | | | | Yes | No | | | | | | | |
| r1912[0] | Identified stator resistance [Ohm] | - | - | - | - | - | Float | 4 | | | | | | | |
| | Displays measured stator resistance value (line-to-line). This value also includes the cable resistances. | | | | | | | | | | | | | | |
| Index: | [0] | U_phase | | | | | | | | | | | | | |
| Notice: | If the value identified (Rs = stator resistance) does not lie within the range 0.1 % < Rs [p. u.] < 100 % fault message 41 (motor data identification failure) is issued. P0949 provides further information (fault value = 2 in this case). | | | | | | | | | | | | | | |
| Note: | This value is measured using P1900 = 2. | | | | | | | | | | | | | | |
| r1920[0] | Identified dynamic leakage inductance | - | - | - | - | - | Float | 4 | | | | | | | |
| | Displays identified total dynamic leakage inductance. | | | | | | | | | | | | | | |
| Index: | [0] | U_phase | | | | | | | | | | | | | |
| r1925[0] | Identified on-state voltage [V] | - | - | - | - | - | Float | 4 | | | | | | | |
| | Displays identified on-state voltage of IGBT. | | | | | | | | | | | | | | |
| Index: | [0] | U_phase | | | | | | | | | | | | | |
| Notice: | If the identified on-state voltage does not lie within the range 0.0V < 10V fault message 41 (motor data identification failure) is issued. P0949 provides further information (fault value = 20 in this case). | | | | | | | | | | | | | | |
| r1926 | Identified gating unit dead time [μs] | - | - | - | - | - | Float | 2 | | | | | | | |
| | Displays identified dead time of gating unit interlock. | | | | | | | | | | | | | | |
| P2000[0...2] | Reference frequency [Hz] | 1.00 - 599.00 | 50.00 | T | - | DDS | Float | 3 | | | | | | | |
| | P2000 represents the reference frequency for frequency values which are displayed / transferred as a percentage or a hexadecimal value. Where: <ul style="list-style-type: none">• hexadecimal 4000 H ==> P2000 (e.g.: USS-PZD)• percentage 100 % ==> P2000 (e.g.: AI) | | | | | | | | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | | | | | | | | | |
|--------------------|---|-----------|---------------------|----------------|---------|-------------------|-----------|------------|-------------------|---|-------|------------------|----|-------|-----------------|----------|--|--|--|--|--|--|--|
| Example: | If a BICO connection is made between two parameters or alternatively using P0719 or P1000, the 'unit' of the parameters (standardized (Hex) or physical (i.e. Hz) values) may differ. SINAMICS implicitly makes an automatic conversion to the target value. | | | | | | | | | | | | | | | | | | | | | | |
| | $y[\text{Hex}] = \frac{r0021[\text{Hz}]}{P2000[\text{Hz}]} \cdot 4000[\text{Hex}]$ $y[\text{Hz}] = \frac{r2018[1]}{4000[\text{Hex}]} \cdot P2000$ | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | When Quick Commissioning is carried out, P2000 is changed as follows: $P2000 = P1082$. | | | | | | | | | | | | | | | | | | | | | | |
| Caution: | <p>P2000 represents the reference frequency of the above mentioned interfaces. A maximum frequency setpoint of $2 \cdot P2000$ can be applied via the corresponding interface. Unlike P1082 (Maximum Frequency) this limits the inverter frequency internally independent of the reference frequency. By modification of P2000 it will also adapt the parameter to the new settings.</p> $f[\text{Hz}] = \frac{f(\text{Hex})}{4000(\text{Hex})} \cdot P2000 = \frac{f(\%)}{100\%} \cdot P2000$ $f_{\text{act},\text{limit}} = \min(P1082, f_{\text{act}})$ | | | | | | | | | | | | | | | | | | | | | | |
| Notice: | <p>Reference parameters are intended as an aid to presenting setpoint and actual value signals in a uniform manner. This also applies to fixed settings entered as a percentage. A value of 100 % corresponds to a process data value of 4000H, or 4000 0000H in the case of double values. In this respect, the following parameters are available:</p> <table border="1"> <tr> <td>P2000</td> <td>Reference frequency</td> <td>Hz</td> </tr> <tr> <td>P2001</td> <td>Reference voltage</td> <td>V</td> </tr> <tr> <td>P2002</td> <td>Reference current</td> <td>A</td> </tr> <tr> <td>P2003</td> <td>Reference torque</td> <td>Nm</td> </tr> <tr> <td>P2004</td> <td>Reference power</td> <td>kW hp</td> </tr> </table> <p style="text-align: right;">f(P0100)</p> | P2000 | Reference frequency | Hz | P2001 | Reference voltage | V | P2002 | Reference current | A | P2003 | Reference torque | Nm | P2004 | Reference power | kW hp | | | | | | | |
| P2000 | Reference frequency | Hz | | | | | | | | | | | | | | | | | | | | | |
| P2001 | Reference voltage | V | | | | | | | | | | | | | | | | | | | | | |
| P2002 | Reference current | A | | | | | | | | | | | | | | | | | | | | | |
| P2003 | Reference torque | Nm | | | | | | | | | | | | | | | | | | | | | |
| P2004 | Reference power | kW hp | | | | | | | | | | | | | | | | | | | | | |
| Note: | Changes to P2000 result in a new calculation of P2004. | | | | | | | | | | | | | | | | | | | | | | |
| P2001[0..2] | Reference voltage [V] | 10 - 2000 | 1000 | T | - | DDS | U16 | 3 | | | | | | | | | | | | | | | |
| | Full-scale output voltage (i.e. 100 %) used over serial link (corresponds to 4000H). | | | | | | | | | | | | | | | | | | | | | | |
| Example: | $y[\text{Hex}] = \frac{r0026[\text{V}]}{P2001[\text{V}]} \cdot 4000[\text{Hex}]$ | | | | | | | | | | | | | | | | | | | | | | |
| Note: | Changes to P2001 result in a new calculation of P2004. | | | | | | | | | | | | | | | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--|-----------------------|----------------|-----------------|----------------|---------|----------|-----------|------------|
| P2002[0...2] | Reference current [A] | 0.10 - 10000.0 | 0.10 | T | - | DDS | Float | 3 |
| Full-scale output current used over serial link (corresponds to 4000H). | | | | | | | | |
| Example: If a BICO connection is made between two parameters, the 'unit' of the parameters (standardized (Hex) or physical (i.e. A) values) may differ. In this case an automatic conversion to the target value is made. | | | | | | | | |
| | | | | | | | | |
| Dependency: This parameter is influenced by automatic calculations defined by P0340. | | | | | | | | |
| Note: Changes to P2002 result in a new calculation of P2004. | | | | | | | | |
| P2003[0...2] | Reference torque [Nm] | 0.10 - 99999.0 | 0.75 | T | - | DDS | Float | 3 |
| Full-scale reference torque used over the serial link (corresponds to 4000H). | | | | | | | | |
| Example: If a BICO connection is made between two parameters, the 'unit' of the parameters (standardized (Hex) or physical (i.e. Nm) values) may differ. In this case an automatic conversion to the target value is made. | | | | | | | | |
| | | | | | | | | |
| Dependency: This parameter is influenced by automatic calculations defined by P0340. | | | | | | | | |
| Note: Changes to P2003 result in a new calculation of P2004. | | | | | | | | |
| P2004[0...2] | Reference power | 0.01 - 2000.0 | 0.75 | T | - | DDS | Float | 3 |
| Full-scale reference power used over the serial link (corresponds to 4000H). | | | | | | | | |
| Example: If a BICO connection is made between two parameters, the 'unit' of the parameters (standardized (Hex) or physical (i.e. kW / hp) values) may differ. In this case an automatic conversion to the target value is made. | | | | | | | | |
| | | | | | | | | |
| P2010[0...1] | USS / MODBUS baudrate | 6 - 12 | 8 | U, T | - | - | U16 | 2 |
| Sets baud rate for USS / MODBUS communication. | | | | | | | | |
| | 6 | 9600 bps | | | | | | |
| | 7 | 19200 bps | | | | | | |
| | 8 | 38400 bps | | | | | | |
| | 9 | 57600 bps | | | | | | |
| | 10 | 76800 bps | | | | | | |
| | 11 | 93750 bps | | | | | | |
| | 12 | 115200 bps | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|----------------|--|-------------------------|-----------------|----------------|---------|----------|-----------|------------|
| Index: | [0] | USS / MODBUS on RS485 | | | | | | |
| | [1] | USS on RS232 (reserved) | | | | | | |
| Note: | This parameter, index 0, will alter the baudrate on RS485 regardless of the protocol selected in P2023. | | | | | | | |
| P2011[0...1] | USS address | 0 - 31 | 0 | U, T | - | - | U16 | 2 |
| | Sets unique address for inverter. | | | | | | | |
| Index: | [0] | USS / MODBUS on RS485 | | | | | | |
| | [1] | USS on RS232 (reserved) | | | | | | |
| Note: | You can connect up to a further 30 inverters via the serial link (i.e. 31 inverters in total) and control them with the USS serial bus protocol. | | | | | | | |
| P2012[0...1] | USS PZD length | 0 - 8 | 2 | U, T | - | - | U16 | 3 |
| | Defines the number of 16-bit words in PZD part of USS telegram. In this area, process data (PZD) are continually exchanged between the master and slaves. The PZD part of the USS telegram is used for the main setpoint, and to control the inverter. | | | | | | | |
| Index: | [0] | USS / MODBUS on RS485 | | | | | | |
| | [1] | USS on RS232 (reserved) | | | | | | |
| Notice: | USS protocol consists of PZD and PKW which can be changed by the user via P2012 and P2013 respectively. | | | | | | | |
| | <p>STX Start of text LGE Length ADR Address PKW Parameter ID value PZD Process data BCC Block check character</p> <p>PKE Parameter ID IND Sub-index PWE Parameter value</p> | | | | | | | |
| | PZD transmits a control word and setpoint or status word and actual values. The number of PZD-words in a USS-telegram are determined by P2012, where the first two words are either: a) control word and main setpoint or b) status word and actual value. When P2012 is greater or equal to 4 the additional control word is transferred as the 4th PZD-word (default setting). | | | | | | | |
| | <p>STW Control word ZSW Status word PZD Process data</p> <p>HSW Main setpoint HIW Main actual value</p> | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | |
|-----------------|--|--|-----------------|------------------------|---------|------------------------|-----------|------------|--|-----|--------------|-----|-----------|-----|-----------------|
| P2013[0...1] | USS PKW length | 0 - 127 | 127 | U, T | - | - | U16 | 3 | | | | | | | |
| | Defines the number of 16-bit words in PKW part of USS telegram. The PKW area can be varied. Depending on the particular requirement, 3-word, 4-word or variable word lengths can be parameterized. The PKW part of the USS telegram is used to read and write individual parameter values. | | | | | | | | | | | | | | |
| | 0 | No words | | | | | | | | | | | | | |
| | 3 | 3 words | | | | | | | | | | | | | |
| | 4 | 4 words | | | | | | | | | | | | | |
| | 127 | Variable | | | | | | | | | | | | | |
| Example: | | Data type | | | | | | | | | | | | | |
| | | U16 (16 Bit) | | U32 (32 Bit) | | Float (32 Bit) | | | | | | | | | |
| | P2013 = 3 | X | | Parameter access fault | | Parameter access fault | | | | | | | | | |
| | P2013 = 4 | X | | X | | X | | | | | | | | | |
| | P2013 = 127 | X | | X | | X | | | | | | | | | |
| Index: | [0] | USS / MODBUS on RS485 | | | | | | | | | | | | | |
| | [1] | USS on RS232 (reserved) | | | | | | | | | | | | | |
| Notice: | USS protocol consists of PZD and PKW which can be changed by the user via P2012 and P2013 respectively. P2013 determines the number of PKW-words in a USS-telegram. Setting P2013 to 3 or 4 determines the length of the PKW words (3 = three words and 4 = four words). When P2013 set to 127 automatically adjusts the length of the PKW words are required. | | | | | | | | | | | | | | |
| | P2013 = 3 | | | | | | | | | | | | | | |
| | P2013 = 4 | | | | | | | | | | | | | | |
| | | <table> <tr> <td>PKE</td><td>Parameter ID</td></tr> <tr> <td>IND</td><td>Sub-index</td></tr> <tr> <td>PWE</td><td>Parameter value</td></tr> </table> | | | | | | | | PKE | Parameter ID | IND | Sub-index | PWE | Parameter value |
| PKE | Parameter ID | | | | | | | | | | | | | | |
| IND | Sub-index | | | | | | | | | | | | | | |
| PWE | Parameter value | | | | | | | | | | | | | | |
| | If a fixed PKW length is selected only one parameter value can be transferred. | | | | | | | | | | | | | | |
| | In the case of indexed parameter, you must use the variable PKW length if you wish to have the values of all indices transferred in a single telegram. | | | | | | | | | | | | | | |
| | In selecting the fixed PKW length, it is important to ensure the value in question can be transferred using this PKW length. | | | | | | | | | | | | | | |
| | P2013 = 3, fixes PKW length, but does not allow access to many parameter values. | | | | | | | | | | | | | | |
| | A parameter fault is generated when an out-of-range value is used, the value will not be accepted but the inverter state will not be affected. | | | | | | | | | | | | | | |
| | Useful for applications where parameters are not changed, but MM3s are also used. | | | | | | | | | | | | | | |
| | Broadcast mode is not possible with this setting. | | | | | | | | | | | | | | |
| | P2013 = 4, fixes PKW length. | | | | | | | | | | | | | | |
| | Allows access to all parameters, but indexed parameters can only be read one index at a time. | | | | | | | | | | | | | | |
| | Word order for single word values are different to setting 3 or 127, see example below. | | | | | | | | | | | | | | |
| | P2013 = 127, most useful setting. | | | | | | | | | | | | | | |
| | PKW reply length varies depending on the amount of information needed. | | | | | | | | | | | | | | |
| | Can read fault information and all indices of a parameter with a single telegram with this setting. | | | | | | | | | | | | | | |
| | Example: Set P0700 to value 5 (P0700 = 2BC (hex)) | | | | | | | | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | |
|----------------|--|--|-----------------|----------------|---------------------|----------|---------------------|------------|--|
| | | P2013 = 3 | | | P2013 = 4 | | P2013 = 127 | | |
| | Master → SINAMICS | 22BC 0000 0006 | | | 22BC 0000 0000 0006 | | 22BC 0000 0006 0000 | | |
| | SINAMICS → Master | 12BC 0000 0006 | | | 12BC 0000 0000 0006 | | 12BC 0000 0006 | | |
| P2014[0...1] | USS / MODBUS telegram off time [ms] | 0 - 65535 | 2000 | T | - | - | U16 | 3 | |
| | | Index 0 defines a time T_off after which a fault will be generated (F72) if no telegram is received via the USS / MODBUS channel RS485. Index 1 defines a time T_off after which a fault will be generated (F71) if no telegram is received via the USS channel RS232 (reserved). | | | | | | | |
| Index: | [0] | USS / MODBUS on RS485 | | | | | | | |
| | [1] | USS on RS232 (reserved) | | | | | | | |
| Notice: | By default (time set to 0), no fault is generated (i.e. watchdog disabled). | | | | | | | | |
| Note: | The telegram off time will function on RS485 regardless of the protocol set in P2023. | | | | | | | | |
| r2018[0...7] | CO: PZD from USS / MODBUS on RS485 | - | - | - | 4000H | - | U16 | 3 | |
| | | Displays process data received via USS / MODBUS on RS485. | | | | | | | |
| | | <p>STX Start of text LGE Length ADR Address PKW Parameter ID value PZD Process data BCC Block check character STW Control word HSW Main setpoint</p> <p>USS on RS485</p> <p>PZD mapping to parameter r2018</p> | | | | | | | |
| Index: | [0] | Received word 0 | | | | | | | |
| | [1] | Received word 1 | | | | | | | |
| | ... | ... | | | | | | | |
| | [7] | Received word 7 | | | | | | | |
| Note: | <p>Restrictions:</p> <ul style="list-style-type: none"> If the above serial interface controls the inverter (P0700 or P0719) then the 1st control word must be transferred in the 1st PZD-word. If the setpoint source is selected via P1000 or P0719, then the main setpoint must be transferred in the 2nd PZD-word. When P2012 is greater than or equal to 4 the additional control word (2nd control word) must be transferred in the 4th PZD-word, if the above serial interface controls the inverter (P0700 or P0719). | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|----------------|--|--------------------|---|----------------|---------|----------|-----------|------------|
| P2019[0...7] | Ci: PZD to USS / MODBUS on RS485 | - | [0] 52[0] [1] 21[0] [2] 0 [3] 53[0] [4...7] 0 | T | 4000H | - | U32 / I16 | 3 |
| | Displays process data transmitted via USS / MODBUS on RS485. | | | | | | | |
| | | | | | | | | |
| Index: | [0] | Transmitted word 0 | | | | | | |
| | [1] | Transmitted word 1 | | | | | | |
| | ... | ... | | | | | | |
| | [7] | Transmitted word 7 | | | | | | |
| Note: | If r0052 not indexed, display does not show an index (".".0"). | | | | | | | |
| P2021 | Modbus address | 1 - 247 | 1 | T | - | - | U16 | 2 |
| | Sets unique address for inverter. | | | | | | | |
| P2022 | Modbus reply timeout [ms] | 0 - 10000 | 1000 | U, T | - | - | U16 | 3 |
| | The time in which the inverter is allowed to respond to the Modbus master. If the forming of a response needs more time than specified in this parameter, the processing is done, but no response is sent. | | | | | | | |
| P2023 | RS485 protocol selection | 0 - 2 | 1 | T | - | - | U16 | 1 |
| | Select the protocol which runs on the RS485 link. | | | | | | | |
| | 0 | None | | | | | | |
| | 1 | USS | | | | | | |
| | 2 | Modbus | | | | | | |
| Notice: | After changing P2023, powercycle the inverter. During the powercycle, wait until LED has gone off or the display has gone blank (may take a few seconds) before re-applying power. If P2023 has been changed via a PLC, make sure the change has been saved to EEPROM via P0971. | | | | | | | |
| r2024[0...1] | USS / MODBUS error-free telegrams | - | - | - | - | - | U16 | 3 |
| | Displays number of error-free USS / MODBUS telegrams received. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | |
|--------------------|---|-------------------------|-----------------|----------------|---------|----------|-----------|------------|--|
| Index: | [0] | USS / MODBUS on RS485 | | | | | | | |
| | [1] | USS on RS232 (reserved) | | | | | | | |
| Note: | The state of the telegram information on RS485 is reported regardless of the protocol set in P2023. | | | | | | | | |
| r2025[0...1] | USS / MODBUS rejected telegrams | - | - | - | - | - | U16 | 3 | |
| | Displays number of USS / MODBUS telegrams rejected. | | | | | | | | |
| Index: | See r2024 | | | | | | | | |
| Note: | See r2024 | | | | | | | | |
| r2026[0...1] | USS / MODBUS character frame error | - | - | - | - | - | U16 | 3 | |
| | Displays number of USS / MODBUS character frame errors. | | | | | | | | |
| Index: | See r2024 | | | | | | | | |
| Note: | See r2024 | | | | | | | | |
| r2027[0...1] | USS / MODBUS overrun error | - | - | - | - | - | U16 | 3 | |
| | Displays number of USS / MODBUS with overrun error. | | | | | | | | |
| Index: | See r2024 | | | | | | | | |
| Note: | See r2024 | | | | | | | | |
| r2028[0...1] | USS / MODBUS parity error | - | - | - | - | - | U16 | 3 | |
| | Displays number of USS / MODBUS telegrams with parity error. | | | | | | | | |
| Index: | See r2024 | | | | | | | | |
| Note: | See r2024 | | | | | | | | |
| r2029[0...1] | USS start not identified | - | - | - | - | - | U16 | 3 | |
| | Displays number of USS telegrams with unidentified start. | | | | | | | | |
| Index: | See r2024 | | | | | | | | |
| Note: | Not used on MODBUS. | | | | | | | | |
| r2030[0...1] | USS / MODBUS BCC / CRC error | - | - | - | - | - | U16 | 3 | |
| | Displays number of USS / MODBUS telegrams with BCC / CRC error. | | | | | | | | |
| Index: | See r2024 | | | | | | | | |
| Note: | See r2024 | | | | | | | | |
| r2031[0...1] | USS / MODBUS length error | - | - | - | - | - | U16 | 3 | |
| | Displays number of USS / MODBUS telegrams with incorrect length. | | | | | | | | |
| Index: | See r2024 | | | | | | | | |
| Note: | See r2024 | | | | | | | | |
| r2036.0...15 | BO: CtrlWrd1 from USS / MODBUS on RS485 | - | - | - | - | - | U16 | 3 | |
| | Displays control word 1 from USS / MODBUS on RS485 (i.e. word 1 within USS / MODBUS = PZD1). See r0054 for the bit field description. | | | | | | | | |
| Dependency: | See P2012 | | | | | | | | |
| r2037.0...15 | BO: CtrlWrd2 from USS on RS485 (USS) | - | - | - | - | - | U16 | 3 | |
| | Displays control word 2 from USS on RS485 (i.e. word 4 within USS = PZD4). See r0055 for the bit field description. | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|---|-------------------------|-----------------|----------------|---------|-----------------|-----------------|------------|
| Dependency: | See P2012 | | | | | | | |
| Note: | To enable the external fault (r2037 bit 13) facility via USS, the following parameters must be set: <ul style="list-style-type: none">• P2012 = 4• P2106 = 1 | | | | | | | |
| r2067.0...12 | CO / BO: Digital input values status | - | - | - | - | - | U16 | 3 |
| | Displays status of digital inputs. | | | | | | | |
| | Bit | Signal name | | | | 1 signal | 0 signal | |
| | 00 | Digital input 1 | | | | Yes | No | |
| | 01 | Digital input 2 | | | | Yes | No | |
| | 02 | Digital input 3 | | | | Yes | No | |
| | 03 | Digital input 4 | | | | Yes | No | |
| | 11 | Digital input AI1 | | | | Yes | No | |
| | 12 | Digital input AI2 | | | | Yes | No | |
| Note: | This is used for BICO connection without software intervention. | | | | | | | |
| P2100[0...2] | Alarm number selection | 0 - 65535 | 0 | T | - | - | U16 | 3 |
| | Selects up to 3 faults or warnings for non-default reactions. | | | | | | | |
| Example: | If, for example, an OFF3 is to be carried out instead of an OFF2 for a fault, the fault number has to be entered in P2100 and the desired reaction selected in P2101 (in this case (OFF3) P2101 = 3). | | | | | | | |
| Index: | [0] | Fault Number 1 | | | | | | |
| | [1] | Fault Number 2 | | | | | | |
| | [2] | Fault Number 3 | | | | | | |
| Note: | All fault codes have a default reaction to OFF2. Some fault codes caused by hardware trips (e.g. overcurrent) cannot be changed from the default reactions. | | | | | | | |
| P2101[0...2] | Stop reaction value | 0 - 3 | 0 | T | - | - | U16 | 3 |
| | Sets inverter stop reaction values for faults selected by P2100 (alarm number selection). This indexed parameter specifies the special reaction to the faults / warnings defined in P2100 indices 0 to 2. | | | | | | | |
| | 0 | No reaction, no display | | | | | | |
| | 1 | OFF1 stop reaction | | | | | | |
| | 2 | OFF2 stop reaction | | | | | | |
| | 3 | OFF3 stop reaction | | | | | | |
| Index: | [0] | Stop reaction value 1 | | | | | | |
| | [1] | Stop reaction value 2 | | | | | | |
| | [2] | Stop reaction value 3 | | | | | | |
| Note: | Settings 1 - 3 are only available for fault codes. Index 0 (P2101) refers to fault / warning in index 0 (P2100). | | | | | | | |
| P2103[0...2] | BI: 1. Faults acknowledgement | - | 722.2 | T | - | CDS | U32 / Bin | 3 |
| | Defines first source of fault acknowledgement. | | | | | | | |
| P2104[0...2] | BI: 2. Faults acknowledgement | - | 0 | T | - | CDS | U32 / Bin | 3 |
| | Selects second source of fault acknowledgement. | | | | | | | |
| P2106[0...2] | BI: External fault | - | 1 | T | - | CDS | U32 / Bin | 3 |
| | Selects source of external faults. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | |
|-----------------|--|----------------------------------|-----------------|----------------|---------|------------------|-----------|------------|--|
| r2110[0...3] | CO: Warning number | - | - | - | - | - | U16 | 2 | |
| | Displays warning information. A maximum of 2 active warnings (indices 0 and 1) and 2 historical warnings (indices 2 and 3) may be viewed. | | | | | | | | |
| Index: | [0] | Recent Warnings --, warning 1 | | | | | | | |
| | [1] | Recent Warnings --, warning 2 | | | | | | | |
| | [2] | Recent Warnings -1, warning 3 | | | | | | | |
| | [3] | Recent Warnings -1, warning 4 | | | | | | | |
| Notice: | Indices 0 and 1 are not stored. | | | | | | | | |
| Note: | The LED indicates the warning status in this case. The keypad will flash while a warning is active. | | | | | | | | |
| P2111 | Total number of warnings | 0 - 4 | 0 | T | - | - | U16 | 3 | |
| | Displays number of warning (up to 4) since last reset. Set to 0 to reset the warning history. | | | | | | | | |
| P2113[0...2] | Disable inverter warnings | 0 - 1 | 0 | T | - | - | U16 | 3 | |
| | Switches off reporting of inverter warnings. Can be used in conjunction with P0503 as an adjunct to keep-running operation. | | | | | | | | |
| | 1 | Inverter warnings disabled | | | | | | | |
| | 0 | Inverter warnings enabled | | | | | | | |
| Index: | [0] | Inverter data set 0 (DDS0) | | | | | | | |
| | [1] | Inverter data set 1 (DDS1) | | | | | | | |
| | [2] | Inverter data set 2 (DDS2) | | | | | | | |
| Note: | See also P0503 | | | | | | | | |
| r2114[0...1] | Run time counter | - | - | - | - | - | U16 | 3 | |
| | Displays run time counter. It is the total time the inverter has been powered up. When power is switched off, the value is saved, and then restored on powerup. The run time counter will be calculate as followed: Multiply the value in r2114[0] by 65536 and then add it to the value in r2114[1]. The resultant answer will be in seconds. This means that r2114[0] is not days. Total powerup time = 65536 * r2114[0] + r2114[1] seconds. | | | | | | | | |
| Example: | If r2114[0] = 1 and r2114[1] = 20864 We get 1 * 65536 + 20864 = 86400 seconds which equals 1 day. | | | | | | | | |
| Index: | [0] | System Time, Seconds, Upper Word | | | | | | | |
| | [1] | System Time, Seconds, Lower Word | | | | | | | |
| P2115[0...2] | Real time clock | 0 - 65535 | 257 | T | - | - | U16 | 4 | |
| | Displays real time. All inverters require an on-board clock function with which fault conditions may be time-stamped and logged. However, they have no battery backed Real Time Clock (RTC). Inverters may support a software driven RTC which requires synchronization with the RTC supplied via a serial interface. The time is stored in a word array parameter P2115. The time will be set by USS Protocol standard "word array parameter write" telegrams. Once the last word is received in index 2, the software will start running the timer itself using internal running 1 millisecond tic. Hence becoming like RTC. If power-cycle takes place, then the real time must be sent again to the inverter. Time is maintained in a word array parameter and encoded as follows - the same format will be used in fault report logs. | | | | | | | | |
| | Index | High Byte (MSB) | | | | Low Byte (LSB) | | | |
| | 0 | Seconds (0 - 59) | | | | Minutes (0 - 59) | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------------------|---|------------------------------|-----------------|----------------|---------|----------|------------------|------------|
| | 1 | | | Hours (0 - 23) | | | Days (1 - 31) | |
| | 2 | | | Month (1 - 12) | | | Years (00 - 250) | |
| The values are in binary form. | | | | | | | | |
| Index: | [0] | Real Time, Seconds + Minutes | | | | | | |
| | [1] | Real Time, Hours + Days | | | | | | |
| | [2] | Real Time, Month + Year | | | | | | |
| P2120 | Indication counter | 0 - 65535 | 0 | U, T | - | - | U16 | 4 |
| | Indicates total number of fault / warning events. This parameter is incremented whenever a fault / warning event occurs. | | | | | | | |
| P2150[0...2] | Hysteresis frequency f_hys [Hz] | 0.00 - 10.00 | 3.00 | U, T | - | DDS | Float | 3 |
| | Defines hysteresis level applied for comparing frequency and speed to threshold. | | | | | | | |
| Dependency: | See P1175. | | | | | | | |
| Note: | If P1175 is set, P2150 is also used to control the Dual Ramp function. | | | | | | | |
| P2151[0...2] | Cl: Speed setpoint for messages | - | 1170[0] | U, T | - | DDS | U32 / I32 | 3 |
| | Selects the source of setpoint frequency, actual frequency is compared with this frequency to detect frequency deviation (see monitoring bit r2197.7). | | | | | | | |
| P2155[0...2] | Threshold frequency f_1 [Hz] | 0.00 - 599.00 | 30.00 | U, T | - | DDS | Float | 3 |
| | Sets a threshold for comparing actual speed or frequency to threshold values f_1. This threshold controls status bits 4 and 5 in status word 2 (r0053). | | | | | | | |
| P2156[0...2] | Delay time of threshold freq f_1 [ms] | 0 - 10000 | 10 | U, T | - | DDS | U16 | 3 |
| | Sets delay time prior to threshold frequency f_1 comparison (P2155). | | | | | | | |
| P2157[0...2] | Threshold frequency f_2 [Hz] | 0.00 - 599.00 | 30.00 | U, T | - | DDS | Float | 2 |
| | Threshold_2 for comparing speed or frequency to thresholds. | | | | | | | |
| Dependency: | See P1175. | | | | | | | |
| Note: | If P1175 is set, P2157 is also used to control the Dual Ramp function. | | | | | | | |
| P2158[0...2] | Delay time of threshold freq f_2 [ms] | 0 - 10000 | 10 | U, T | - | DDS | U16 | 2 |
| | When comparing speed or frequency to threshold f_2 (P2157) this is the time delay before status bits are cleared. | | | | | | | |
| P2159[0...2] | Threshold frequency f_3 [Hz] | 0.00 - 599.00 | 30.00 | U, T | - | DDS | Float | 2 |
| | Threshold_3 for comparing speed or frequency to thresholds. | | | | | | | |
| Dependency: | See P1175. | | | | | | | |
| Note: | If P1175 is set, P2159 is also used to control the Dual Ramp function. | | | | | | | |
| P2160[0...2] | Delay time of threshold freq f_3 [ms] | 0 - 10000 | 10 | U, T | - | DDS | U16 | 2 |
| | When comparing speed or frequency to threshold f_3 (P2159) this is the time delay before status bits are set. | | | | | | | |
| P2162[0...2] | Hysteresis freq. for overspeed [Hz] | 0.00 - 25.00 | 3.00 | U, T | - | DDS | Float | 3 |
| | Hysteresis speed (frequency) for overspeed detection. For V/f control modes the hysteresis acts below the maximum frequency. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|--------------|-----------------|----------------|---------|----------|-----------|------------|
| P2164[0..2] | Hysteresis frequency deviation [Hz] | 0.00 - 10.00 | 3.00 | U, T | - | DDS | Float | 3 |
| | Hysteresis frequency for detecting permitted deviation (from setpoint) or frequency or speed. This frequency controls bit 8 in status word 1 (r0052). | | | | | | | |
| P2166[0..2] | Delay time ramp up completed [ms] | 0 - 10000 | 10 | U, T | - | DDS | U16 | 3 |
| | Delay time for signal that indicates completion of ramp-up. | | | | | | | |
| P2167[0..2] | Switch-off frequency f_off [Hz] | 0.00 - 10.00 | 1.00 | U, T | - | DDS | Float | 3 |
| | Defines the threshold of the monitoring function $ f_{act} > P2167 (f_{off})$. P2167 influences following functions: <ul style="list-style-type: none"> If the actual frequency falls below this threshold and the time delay has expired, bit 1 in status word 2 (r0053) is reset. If a OFF1 or OFF3 was applied and bit 1 is reset the inverter will disable the pulse (OFF2). | | | | | | | |
| P2168[0..2] | Delay time T_off [ms] | 0 - 10000 | 0 | U, T | - | DDS | U16 | 3 |
| | Defines time for which the inverter may operate below switch-off frequency (P2167) before switch off occurs. | | | | | | | |
| Dependency: | Active if holding brake (P1215) not parameterized. | | | | | | | |
| P2170[0..2] | Threshold current I_thresh [%] | 0.00 - 400.0 | 100.0 | U, T | - | DDS | Float | 3 |
| | Defines threshold current relative to P0305 (rated motor current) to be used in comparisons of I_act and I_Thresh. This threshold controls bit 3 in status word 3 (r0053). | | | | | | | |
| P2171[0..2] | Delay time current [ms] | 0 - 10000 | 10 | U, T | - | DDS | U16 | 3 |
| | Defines delay time prior to activation of current comparison. | | | | | | | |
| P2172[0..2] | Threshold DC-link voltage [V] | 0 - 2000 | 800 | U, T | - | DDS | U16 | 3 |
| | Defines DC link voltage to be compared to actual voltage. This voltage controls bits 7 and 8 in status word 3 (r0053). | | | | | | | |
| P2173[0..2] | Delay time DC-link voltage [ms] | 0 - 10000 | 10 | U, T | - | DDS | U16 | 3 |
| | Defines delay time prior to activation of threshold comparison. | | | | | | | |
| P2177[0..2] | Delay time for motor is blocked [ms] | 0 - 10000 | 10 | U, T | - | DDS | U16 | 3 |
| | Delay time for identifying that the motor is blocked. | | | | | | | |
| P2179 | Current limit for no load identified [%] | 0.00 - 10.0 | 3.0 | U, T | - | - | Float | 3 |
| | Threshold current for A922 (load missing) relative to P0305 (rated motor current). | | | | | | | |
| Notice: | If a motor setpoint cannot be entered and the current limit (P2179) is not exceeded, warning A922 (no load applied) is issued when delay time (P2180) expires. | | | | | | | |
| Note: | It may be that the motor is not connected (load missing) or a phase could be missing. | | | | | | | |
| P2180 | Delay time for load missing [ms] | 0 - 10000 | 2000 | U, T | - | - | U16 | 3 |
| | Delay time for identifying that the load is missing. | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | | | | | | | | |
|--------------------|--|---------------|-----------------|----------------|---------|----------|-----------|------------|---|---------------------------------|---|---------------------------------|---|----------------------------------|---|--|---|------------------------------|---|-------------------------------|---|-------------------------------------|
| P2181[0...2] | Belt failure detection mode | 0 - 6 | 0 | T | - | DDS | U16 | 3 | | | | | | | | | | | | | | |
| | <p>Sets belt failure detection mode.</p> <p>This function allows detection of mechanical failure of the inverter train, e.g. a broken inverter belt. It can also detect conditions which cause an overload, such as a jam. P2182 -P2190 are set to the following values when this parameter is changed from 0.</p> <p>P2182 = P1080 (Fmin) P2183 = P1082 (Fmax) * 0.8 P2184 = P1082 (Fmax) P2185 = r0333 (rated motor torque) * 1.1 P2186 = 0 P2187 = r0333 (rated motor torque) * 1.1 P2188 = 0 P2189 = r0333 (rated motor torque) * 1.1 P2190 = r0333 (rated motor torque) / 2</p> <p>This is achieved by comparing the actual frequency / torque curve with a programmed envelope (see P2182 - P2190). If the curve falls outside the envelope, a warning A952 or trip F452 is generated.</p> | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1"> <tr> <td>0</td><td>Belt failure detection disabled</td></tr> <tr> <td>1</td><td>Warning: Low torque / frequency</td></tr> <tr> <td>2</td><td>Warning: High torque / frequency</td></tr> <tr> <td>3</td><td>Warning: High / low torque / frequency</td></tr> <tr> <td>4</td><td>Trip: Low torque / frequency</td></tr> <tr> <td>5</td><td>Trip: High torque / frequency</td></tr> <tr> <td>6</td><td>Trip: High / low torque / frequency</td></tr> </table> | | | | | | | | 0 | Belt failure detection disabled | 1 | Warning: Low torque / frequency | 2 | Warning: High torque / frequency | 3 | Warning: High / low torque / frequency | 4 | Trip: Low torque / frequency | 5 | Trip: High torque / frequency | 6 | Trip: High / low torque / frequency |
| 0 | Belt failure detection disabled | | | | | | | | | | | | | | | | | | | | | |
| 1 | Warning: Low torque / frequency | | | | | | | | | | | | | | | | | | | | | |
| 2 | Warning: High torque / frequency | | | | | | | | | | | | | | | | | | | | | |
| 3 | Warning: High / low torque / frequency | | | | | | | | | | | | | | | | | | | | | |
| 4 | Trip: Low torque / frequency | | | | | | | | | | | | | | | | | | | | | |
| 5 | Trip: High torque / frequency | | | | | | | | | | | | | | | | | | | | | |
| 6 | Trip: High / low torque / frequency | | | | | | | | | | | | | | | | | | | | | |
| P2182[0...2] | Belt threshold frequency 1 [Hz] | 0.00 - 599.00 | 5.00 | U, T | - | DDS | Float | 3 | | | | | | | | | | | | | | |
| | <p>Sets the lower frequency threshold f_1 for defining the area where the belt failure detection is effective. The frequency torque envelope is defined by 9 parameters - 3 are frequency parameters (P2182 - P2184), and the other 6 define the low and high torque limits (P2185 - P2190) for each frequency.</p> | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | See P2181 for calculated default value. | | | | | | | | | | | | | | | | | | | | | |
| Note: | <p>Below the threshold in P2182 and above the threshold in P2184, belt failure detection mode is not active. In this case the values for normal operation with the torque limits given in P1521 and P1520 are valid.</p> | | | | | | | | | | | | | | | | | | | | | |
| P2183[0...2] | Belt threshold frequency 2 [Hz] | 0.00 - 599.00 | 30.00 | U, T | - | DDS | Float | 3 | | | | | | | | | | | | | | |
| | <p>Sets the frequency threshold f_2 for defining the envelope in which the torque values are valid. See P2182.</p> | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | See P2181 for calculated default value. | | | | | | | | | | | | | | | | | | | | | |
| P2184[0...2] | Belt threshold frequency 3 [Hz] | 0.00 - 599.00 | 50.00 | U, T | - | DDS | Float | 3 | | | | | | | | | | | | | | |
| | <p>Sets the upper frequency threshold f_3 for defining the area where the belt failure detection is effective. See P2182.</p> | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | See P2181 for calculated default value. | | | | | | | | | | | | | | | | | | | | | |
| P2185[0...2] | Upper torque threshold 1 [Nm] | 0.0 - 99999.0 | Value in r0333 | U, T | - | DDS | Float | 3 | | | | | | | | | | | | | | |
| | <p>Upper limit threshold value 1 for comparing actual torque.</p> | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | <p>This parameter is influenced by automatic calculations defined by P0340. See P2181 for calculated default value.</p> | | | | | | | | | | | | | | | | | | | | | |
| Note: | The factory setting depends on rating data of Power Module and Motor. | | | | | | | | | | | | | | | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|-------------------------------|-----------------|----------------|---------|-----------------|-----------------|------------|
| P2186[0..2] | Lower torque threshold 1 [Nm] | 0.0 - 99999.0 | 0.0 | U, T | - | DDS | Float | 3 |
| | Lower limit threshold value 1 for comparing actual torque. | | | | | | | |
| Dependency: | See P2181 for calculated default value. | | | | | | | |
| P2187[0..2] | Upper torque threshold 2 [Nm] | 0.0 - 99999.0 | Value in r0333 | U, T | - | DDS | Float | 3 |
| | Upper limit threshold value 2 for comparing actual torque. | | | | | | | |
| Dependency: | This parameter is influenced by automatic calculations defined by P0340. See P2181 for calculated default value. | | | | | | | |
| Note: | See P2185 | | | | | | | |
| P2188[0..2] | Lower torque threshold 2 [Nm] | 0.0 - 99999.0 | 0.0 | U, T | - | DDS | Float | 3 |
| | Lower limit threshold value 2 for comparing actual torque. | | | | | | | |
| Dependency: | See P2181 for calculated default value. | | | | | | | |
| P2189[0..2] | Upper torque threshold 3 [Nm] | 0.0 - 99999.0 | Value in r0333 | U, T | - | DDS | Float | 3 |
| | Upper limit threshold value 3 for comparing actual torque. | | | | | | | |
| Dependency: | This parameter is influenced by automatic calculations defined by P0340. See P2181 for calculated default value. | | | | | | | |
| Note: | See P2185 | | | | | | | |
| P2190[0..2] | Lower torque threshold 3 [Nm] | 0.0 - 99999.0 | 0.0 | U, T | - | DDS | Float | 3 |
| | Lower limit threshold value 3 for comparing actual torque. | | | | | | | |
| Dependency: | See P2181 for calculated default value. | | | | | | | |
| P2192[0..2] | Time delay for belt failure [s] | 0 - 65 | 10 | U, T | - | DDS | Float | 3 |
| | P2192 defines a delay before warning / trip becomes active. - It is used to eliminate events caused by transient conditions. - It is used for both methods of fault detection. | | | | | | | |
| r2197.0...12 | CO / BO: Monitoring word 1 | - | - | - | - | - | U16 | 3 |
| | Monitoring word 1 which indicates the state of monitor functions. Each bit represents one monitor function. | | | | | | | |
| | Bit | Signal name | | | | 1 signal | 0 signal | |
| | 00 | f_act <= P1080 (f_min) | | | | Yes | No | |
| | 01 | f_act <= P2155 (f_1) | | | | Yes | No | |
| | 02 | f_act > P2155 (f_1) | | | | Yes | No | |
| | 03 | f_act >= zero | | | | Yes | No | |
| | 04 | f_act >= setp. (f_set) | | | | Yes | No | |
| | 05 | f_act <= P2167 (f_off) | | | | Yes | No | |
| | 06 | f_act >= P1082 (f_max) | | | | Yes | No | |
| | 07 | f_act == setp. (f_set) | | | | Yes | No | |
| | 08 | Act. current r0027 >= P2170 | | | | Yes | No | |
| | 09 | Act. unfilt. Vdc < P2172 | | | | Yes | No | |
| | 10 | Act. unfilt. Vdc > P2172 | | | | Yes | No | |
| | 11 | Load missing | | | | Yes | No | |
| | 12 | f_act > P1082 with delay | | | | Yes | No | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|---|------------------------------------|-----------------|----------------|---------|----------|-----------|------------|
| r2198.0...12 | CO / BO: Monitoring word 2 | - | - | - | - | - | U16 | 3 |
| | Monitoring word 2 which indicates the state of monitor functions. Each bit represents one monitor function. | | | | | | | |
| | Bit | Signal name | | | | 1 signal | 0 signal | |
| | 00 | f_act <= P2157 (f_2) | | | | Yes | No | |
| | 01 | f_act > P2157 (f_2) | | | | Yes | No | |
| | 02 | f_act <= P2159 (f_3) | | | | Yes | No | |
| | 03 | f_act > P2159 (f_3) | | | | Yes | No | |
| | 04 | f_set < P2161 (f_min_set) | | | | Yes | No | |
| | 05 | f_set > 0 | | | | Yes | No | |
| | 06 | Motor blocked | | | | Yes | No | |
| | 07 | Motor pulled out | | | | Yes | No | |
| | 08 | I_act r0068 < P2170 | | | | Yes | No | |
| | 09 | Im_act > P2174 & setpoint reached | | | | Yes | No | |
| | 10 | Im_act > P2174 | | | | Yes | No | |
| | 11 | Belt failure warning | | | | Yes | No | |
| | 12 | Belt failure trip | | | | Yes | No | |
| P2200[0...2] | BI: Enable PID controller | - | 0 | U, T | - | CDS | U32 / Bin | 2 |
| | Allows user to enable / disable the PID controller. Setting to 1 enables the PID closed-loop controller. | | | | | | | |
| Dependency: | Setting 1 automatically disables normal ramp times set in P1120 and P1121 and the normal frequency setpoints. Following an OFF1 or OFF3 command, however, the inverter frequency will ramp down to zero using the ramp time set in P1121 (P1135 for OFF3). | | | | | | | |
| Notice: | The minimum and maximum motor frequencies (P1080 and P1082) as well as the skip frequencies (P1091 to P1094) remain active on the inverter output. However, enabling skip frequencies with PID control can produce instabilities. | | | | | | | |
| Note: | The PID setpoint source is selected using P2253. The PID setpoint and the PID feedback signal are interpreted as [%] values (not [Hz]). The output of the PID controller is displayed as [%] and then normalized into [Hz] through P2000 (reference frequency) when PID is enabled. The reverse command is not active when PID is active. Attention: P2200 and P2803 are locked parameter against each other. PID and FFB of the same data set cannot be active at same time. | | | | | | | |
| P2201[0...2] | Fixed PID setpoint 1 [%] | -200.00 - 200.00 | 10.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed PID setpoint 1. There are 2 types of fixed frequencies: 1. Direct selection (P2216 = 1): – In this mode of operation 1 Fixed Frequency selector (P2220...P2223) selects 1 fixed frequency. – If several inputs are active together, the selected frequencies are summed. E.g.: PID-FF1 + PID-FF2 + PID-FF3 + PID-FF4. 2. Binary coded selection (P2216 = 2): – Up to 16 different fixed frequency values can be selected using this method. | | | | | | | |
| Dependency: | P2200 = 1 required in user access level 2 to enable setpoint source. | | | | | | | |
| Note: | You may mix different types of frequencies; however, remember that they will be summed if selected together. P2201 = 100 % corresponds to 4000 hex. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------|----------------------------------|------------------|-----------------|----------------|---------|----------|-----------|------------|
| P2202[0...2] | Fixed PID setpoint 2 [%] | -200.00 - 200.00 | 20.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed PID setpoint 2. | | | | | | | |
| Note: | See P2201 | | | | | | | |
| P2203[0...2] | Fixed PID setpoint 3 [%] | -200.00 - 200.00 | 50.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed PID setpoint 3. | | | | | | | |
| Note: | See P2201 | | | | | | | |
| P2204[0...2] | Fixed PID setpoint 4 [%] | -200.00 - 200.00 | 100.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed PID setpoint 4. | | | | | | | |
| Note: | See P2201 | | | | | | | |
| P2205[0...2] | Fixed PID setpoint 5 [%] | -200.00 - 200.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed PID setpoint 5. | | | | | | | |
| Note: | See P2201 | | | | | | | |
| P2206[0...2] | Fixed PID setpoint 6 [%] | -200.00 - 200.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed PID setpoint 6. | | | | | | | |
| Note: | See P2201 | | | | | | | |
| P2207[0...2] | Fixed PID setpoint 7 [%] | -200.00 - 200.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed PID setpoint 7. | | | | | | | |
| Note: | See P2201 | | | | | | | |
| P2208[0...2] | Fixed PID setpoint 8 [%] | -200.00 - 200.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed PID setpoint 8. | | | | | | | |
| Note: | See P2201 | | | | | | | |
| P2209[0...2] | Fixed PID setpoint 9 [%] | -200.00 - 200.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed PID setpoint 9. | | | | | | | |
| Note: | See P2201 | | | | | | | |
| P2210[0...2] | Fixed PID setpoint 10 [%] | -200.00 - 200.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed PID setpoint 10. | | | | | | | |
| Note: | See P2201 | | | | | | | |
| P2211[0...2] | Fixed PID setpoint 11 [%] | -200.00 - 200.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed PID setpoint 11. | | | | | | | |
| Note: | See P2201 | | | | | | | |
| P2212[0...2] | Fixed PID setpoint 12 [%] | -200.00 - 200.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed PID setpoint 12. | | | | | | | |
| Note: | See P2201 | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------|--|-------------------------------|-----------------|----------------|---------|-----------------|-----------------|------------|
| P2213[0...2] | Fixed PID setpoint 13 [%] | -200.00 - 200.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed PID setpoint 13. | | | | | | | |
| Note: | See P2201 | | | | | | | |
| P2214[0...2] | Fixed PID setpoint 14 [%] | -200.00 - 200.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed PID setpoint 14. | | | | | | | |
| Note: | See P2201 | | | | | | | |
| P2215[0...2] | Fixed PID setpoint 15 [%] | -200.00 - 200.00 | 0.00 | U, T | - | DDS | Float | 2 |
| | Defines fixed PID setpoint 15. | | | | | | | |
| Note: | See P2201 | | | | | | | |
| P2216[0...2] | Fixed PID setpoint mode | 1 - 2 | 1 | T | - | DDS | U16 | 2 |
| | Fixed frequencies for PID setpoint can be selected in two different modes. P2216 defines the mode. | | | | | | | |
| | 1 | Direct selection | | | | | | |
| | 2 | Binary selection | | | | | | |
| P2220[0...2] | BI: Fixed PID setpoint select bit 0 | - | 722.3 | T | - | CDS | U32 / Bin | 3 |
| | Defines command source of fixed PID setpoint selection bit 0. | | | | | | | |
| P2221[0...2] | BI: Fixed PID setpoint select bit 1 | - | 722.4 | T | - | CDS | U32 / Bin | 3 |
| | Defines command source of fixed PID setpoint selection bit 1. | | | | | | | |
| P2222[0...2] | BI: Fixed PID setpoint select bit 2 | - | 722.5 | T | - | CDS | U32 / Bin | 3 |
| | Defines command source of fixed PID setpoint selection bit 2. | | | | | | | |
| P2223[0...2] | BI: Fixed PID setpoint select bit 3 | - | 722.6 | T | - | CDS | U32 / Bin | 3 |
| | Defines command source of fixed PID setpoint selection bit 3. | | | | | | | |
| r2224 | CO: Actual fixed PID setpoint [%] | - | - | - | - | - | Float | 2 |
| | Displays total output of PID fixed setpoint selection. | | | | | | | |
| Note: | r2224 = 100 % corresponds to 4000 hex. | | | | | | | |
| r2225.0 | BO: PID fixed frequency status | - | - | - | - | - | U16 | 3 |
| | Displays the status of PID fixed frequencies. | | | | | | | |
| | Bit | Signal name | | | | 1 signal | 0 signal | |
| | 00 | Status of FF | | | | Yes | No | |
| P2231[0...2] | PID-MOP mode | - | 0 | U, T | - | DDS | U16 | 2 |
| | PID-MOP mode specification | | | | | | | |
| | Bit | Signal name | | | | 1 signal | 0 signal | |
| | 00 | Setpoint store active | | | | Yes | No | |
| | 01 | No On-state for MOP necessary | | | | Yes | No | |
| Note: | Defines the operation mode of the motorized potentiometer. See P2240. | | | | | | | |
| P2232 | Inhibit reverse direction of PID-MOP | 0 - 1 | 1 | T | - | - | U16 | 2 |
| | Inhibits reverse setpoint selection of the PID-MOP. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|------------------|-----------------|------------------------------|---------|----------|-----------|------------|
| | 0 | | | Reverse direction is allowed | | | | |
| | 1 | | | Reverse direction inhibited | | | | |
| Note: | Setting 0 enables a change of motor direction using the motor potentiometer setpoint (increase / decrease frequency). | | | | | | | |
| P2235[0..2] | Bi: Enable PID-MOP (UP-cmd) | - | 19.13 | T | - | CDS | U32 / Bin | 3 |
| | Defines source of UP command. | | | | | | | |
| Dependency: | To change setpoint: - Configure a digital input as source - Use UP / DOWN key on operator panel. | | | | | | | |
| Notice: | If this command is enabled by short pulses of less than 1 second, the frequency is changed in steps of 0.2 % (P0310). When the signal is enabled longer than 1 second the ramp generator accelerates with the rate of P2247. | | | | | | | |
| P2236[0..2] | Bi: Enable PID-MOP (DOWN-cmd) | - | 19.14 | T | - | CDS | U32 / Bin | 3 |
| | Defines source of DOWN command. | | | | | | | |
| Dependency: | See P2235 | | | | | | | |
| Notice: | If this command is enabled by short pulses of less than 1 second, the frequency is changed in steps of 0.2 % (P0310). When the signal is enabled longer than 1 second the ramp generator decelerates with the rate of P2248. | | | | | | | |
| P2240[0..2] | Setpoint of PID-MOP [%] | -200.00 - 200.00 | 10.00 | U, T | - | DDS | Float | 2 |
| | Setpoint of the motor potentiometer. Allows user to set a digital PID setpoint in [%]. | | | | | | | |
| Note: | P2240 = 100 % corresponds to 4000 hex. The start value gets active (for the MOP output) only at the start of the MOP. P2231 influences the start value behavior as follows: <ul style="list-style-type: none">• P2231 = 0: P2240 gets immediately active in the OFF-state and when changed in the ON-state, it gets active after the next OFF and ON cycle.• P2231 = 1: The last MOP output before stop is stored as starting value, since storing is selected, so a change of P2240 while in ON-state has no effect. In OFF-state P2240 can be changed.• P2231 = 2: The MOP is active every time, so the change of P2240 affects after the next power cycle or a change of P2231 to 0. | | | | | | | |
| P2241[0..2] | Bi: PID-MOP select setpoint auto / manu | - | 0 | T | - | CDS | U32 / Bin | 3 |
| | Sets the signal source to change over from manual to automatic mode. If using the motorized potentiometer in the manual mode the setpoint is changed using two signals for up and down, e.g. P2235 and P2236. If using the automatic mode the setpoint must be interconnected via the connector input (P2242). 0: manually 1: automatically | | | | | | | |
| Notice: | Refer to: P2235, P1036, P2242 | | | | | | | |
| P2242[0..2] | Cl: PID-MOP auto setpoint | - | 0 | T | - | CDS | U32 / I32 | 3 |
| | Sets the signal source for the setpoint of the motorized potentiometer if automatic mode P2241 is selected. | | | | | | | |
| Notice: | Refer to: P2241 | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|-----------------|-----------------|----------------|---------|----------|-----------|------------|
| P2243[0...2] | BI: PID-MOP accept rampgenerator setpoint | - | 0 | T | - | CDS | U32 / Bin | 3 |
| | Sets the signal source for the setting command to accept the setting value for the motorized potentiometer. The value becomes effective for a 0/1 edge of the setting command. | | | | | | | |
| Notice: | Refer to: P2244 | | | | | | | |
| P2244[0...2] | Cl: PID-MOP rampgenerator setpoint | - | 0 | T | - | CDS | U32 / I32 | 3 |
| | Sets the signal source for the setpoint value for the MOP. The value becomes effective for a 0/1 edge of the setting command. | | | | | | | |
| Notice: | Refer to: P2243 | | | | | | | |
| r2245 | CO: PID-MOP input frequency of the RFG [%] | - | - | - | - | - | Float | 3 |
| | Displays the motorized potentiometer setpoint before it passed the PID-MOP RFG. | | | | | | | |
| P2247[0...2] | PID-MOP ramp-up time of the RFG [s] | 0.00 - 1000.0 | 10.00 | U, T | - | DDS | Float | 2 |
| | Sets the ramp-up time for the internal PID-MOP ramp-function generator. The setpoint is changed from zero up to limit defined in P1082 within this time. | | | | | | | |
| Notice: | Refer to: P2248, P1082 | | | | | | | |
| P2248[0...2] | PID-MOP ramp-down time of the RFG [s] | 0.00 - 1000.0 | 10.00 | U, T | - | DDS | Float | 2 |
| | Sets the ramp-down time for the internal PID-MOP ramp-function generator. The setpoint is changed from limit defined in P1082 down to zero within this time. | | | | | | | |
| Notice: | Refer to: P2247, P1082 | | | | | | | |
| r2250 | CO: Output setpoint of PID-MOP [%] | - | - | - | PERCENT | - | Float | 2 |
| | Displays output setpoint of motor potentiometer. | | | | | | | |
| P2251 | PID mode | 0 - 1 | 0 | T | - | - | U16 | 3 |
| | Enables function of PID controller. | | | | | | | |
| | 0 | PID as setpoint | | | | | | |
| | 1 | PID as trim | | | | | | |
| Dependency: | Active when PID loop is enabled (see P2200). | | | | | | | |
| P2253[0...2] | Cl: PID setpoint | - | 0 | U, T | 4000H | CDS | U32 / I16 | 2 |
| | Defines setpoint source for PID setpoint input. This parameter allows the user to select the source of the PID setpoint. Normally, a digital setpoint is selected either using a fixed PID setpoint or an active setpoint. | | | | | | | |
| P2254[0...2] | Cl: PID trim source | - | 0 | U, T | 4000H | CDS | U32 / I16 | 3 |
| | Selects trim source for PID setpoint. This signal is multiplied by the trim gain and added to the PID setpoint. | | | | | | | |
| P2255 | PID setpoint gain factor | 0.00 - 100.00 | 100.00 | U, T | - | - | Float | 3 |
| | Gain factor for PID setpoint. The PID setpoint input is multiplied by this gain factor to produce a suitable ratio between setpoint and trim. | | | | | | | |
| P2256 | PID trim gain factor | 0.00 - 100.00 | 100.00 | U, T | - | - | Float | 3 |
| | Gain factor for PID trim. This gain factor scales the trim signal, which is added to the main PID setpoint. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | |
|--------------------|--|--------------------------------|-----------------|----------------|---------|----------|-----------|------------|--|
| P2257 | Ramp-up time for PID setpoint [s] | 0.00 - 650.00 | 1.00 | U, T | - | - | Float | 2 | |
| | Sets the ramp-up time for the PID setpoint. | | | | | | | | |
| Dependency: | P2200 = 1 (PID control is enabled) disable normal ramp-up time (P1120). PID ramp time effective only on PID setpoint and only active when PID setpoint is changed or when RUN command is given (when PID setpoint uses this ramp to reach its value from 0 %). | | | | | | | | |
| Notice: | Setting the ramp-up time too short may cause the inverter to trip, on overcurrent for example. | | | | | | | | |
| P2258 | Ramp-down time for PID setpoint [s] | 0.00 - 650.00 | 1.00 | U, T | - | - | Float | 2 | |
| | Sets ramp-down time for PID setpoint. | | | | | | | | |
| Dependency: | P2200 = 1 (PID control is enabled) disables normal ramp-down time (P1121). PID setpoint ramp effective only on PID setpoint changes. P1121 (ramp-down time) and P1135 (OFF3 ramp-down time) define the ramp times used after OFF1 and OFF3 respectively. | | | | | | | | |
| Notice: | Setting the ramp-down time too short can cause the inverter to trip on overvoltage F2 / overcurrent F1. | | | | | | | | |
| r2260 | CO: PID setpoint after PID-RFG [%] | - | - | - | - | - | Float | 2 | |
| | Displays total active PID setpoint after PID-RFG. | | | | | | | | |
| Note: | r2260 = 100 % corresponds to 4000 hex. | | | | | | | | |
| P2261 | PID setpoint filter time constant [s] | 0.00 - 60.00 | 0.00 | U, T | - | - | Float | 3 | |
| | Sets a time constant for smoothing the PID setpoint. | | | | | | | | |
| Note: | P2261 = 0 = no smoothing. | | | | | | | | |
| r2262 | CO: Filtered PID setpoint after RFG [%] | - | - | - | - | - | Float | 3 | |
| | Displays filtered PID setpoint after PID-RFG. r2262 is the result of the value in r2260, filtered with PT1-Filter and the time constant given in P2261. | | | | | | | | |
| Note: | r2262 = 100 % corresponds to 4000 hex. | | | | | | | | |
| P2263 | PID controller type | 0 - 1 | 0 | T | - | - | U16 | 3 | |
| | Sets the PID controller type. | | | | | | | | |
| | 0 | D component on feedback signal | | | | | | | |
| | 1 | D component on error signal | | | | | | | |
| P2264[0..2] | Cl: PID feedback | - | 755[0] | U, T | 4000H | CDS | U32 / I16 | 2 | |
| | Selects the source of the PID feedback signal. | | | | | | | | |
| Note: | When analog input is selected, offset and gain can be implemented using P0756 to P0760 (AI scaling). | | | | | | | | |
| P2265 | PID feedback filter time constant [s] | 0.00 - 60.00 | 0.00 | U, T | - | - | Float | 2 | |
| | Defines time constant for PID feedback filter. | | | | | | | | |
| r2266 | CO: PID filtered feedback [%] | - | - | - | - | - | Float | 2 | |
| | Displays PID feedback signal. | | | | | | | | |
| Note: | r2266 = 100 % corresponds to 4000 hex. | | | | | | | | |
| P2267 | Maximum value for PID feedback [%] | -200.00 - 200.00 | 100.00 | U, T | - | - | Float | 3 | |
| | Sets the upper limit for the value of the feedback signal. | | | | | | | | |
| Notice: | When PID is enabled (P2200 = 1) and the signal rises above this value, the inverter will trip with F222. | | | | | | | | |
| Note: | P2267 = 100 % corresponds to 4000 hex. | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|---|----------------------------------|-----------------|----------------|---------|----------|-----------|------------|
| P2268 | Minimum value for PID feedback [%] | -200.00 - 200.00 | 0.00 | U, T | - | - | Float | 3 |
| | Sets lower limit for value of feedback signal. | | | | | | | |
| Notice: | When PID is enabled (P2200 = 1) and the signal drops below this value, the inverter will trip with F221. | | | | | | | |
| Note: | P2268 = 100 % corresponds to 4000 hex. | | | | | | | |
| P2269 | Gain applied to PID feedback | 0.00 - 500.00 | 100.00 | U, T | - | - | Float | 3 |
| | Allows the user to scale the PID feedback as a percentage value. A gain of 100.0 % means that feedback signal has not changed from its default value. | | | | | | | |
| P2270 | PID feedback function selector | 0 - 3 | 0 | U, T | - | - | U16 | 3 |
| | Applies mathematical functions to the PID feedback signal, allowing multiplication of the result by P2269. | | | | | | | |
| | 0 | Disabled | | | | | | |
| | 1 | Square root (root(x)) | | | | | | |
| | 2 | Square (x^2) | | | | | | |
| | 3 | Cube (x^3) | | | | | | |
| P2271 | PID transducer type | 0 - 1 | 0 | U, T | - | - | U16 | 2 |
| | Allows the user to select the transducer type for the PID feedback signal. | | | | | | | |
| | 0 | Disabled | | | | | | |
| | 1 | Inversion of PID feedback signal | | | | | | |
| Notice: | It is essential that you select the correct transducer type. If you are unsure whether 0 or 1 is applicable, you can determine the correct type as follows: 1. Disable the PID function (P2200 = 0). 2. Increase the motor frequency while measuring the feedback signal. 3. If the feedback signal increases with an increase in motor frequency, the PID transducer type should be 0. 4. If the feedback signal decreases with an increase in motor frequency the PID transducer type should be set to 1. | | | | | | | |
| r2272 | CO: PID scaled feedback [%] | - | - | - | - | - | Float | 2 |
| | Displays PID scaled feedback signal. | | | | | | | |
| Note: | r2272 = 100 % corresponds to 4000 hex. | | | | | | | |
| r2273 | CO: PID error [%] | - | - | - | - | - | Float | 2 |
| | Displays PID error (difference) signal between setpoint and feedback signals. | | | | | | | |
| Note: | r2273 = 100 % corresponds to 4000 hex. | | | | | | | |
| P2274 | PID derivative time [s] | 0.000 - 60.000 | 0.000 | U, T | - | - | Float | 2 |
| | Sets PID derivative time. P2274 = 0: The derivative term does not have any effect (it applies a gain of 1). | | | | | | | |
| P2280 | PID proportional gain | 0.000 - 65.000 | 3.000 | U, T | - | - | Float | 2 |
| | Allows user to set proportional gain for PID controller. The PID controller is implemented using the standard model. For best results, enable both P and I terms. | | | | | | | |
| Dependency: | P2280 = 0 (P term of PID = 0): The I term acts on the square of the error signal. P2285 = 0 (I term of PID = 0): PID controller acts as a P or PD controller respectively. | | | | | | | |
| Note: | If the system is prone to sudden step changes in the feedback signal, P term should normally be set to a small value (0.5) with a faster I term for optimum performance. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | |
|--------------------|--|--|-----------------|----------------|---------|----------|-----------|------------|--|
| P2285 | PID integral time [s] | 0.000 - 60.000 | 0.000 | U, T | - | - | Float | 2 | |
| | Sets integral time constant for PID controller. | | | | | | | | |
| Note: | See P2280 | | | | | | | | |
| P2291 | PID output upper limit [%] | -200.00 - 200.00 | 100.00 | U, T | - | - | Float | 2 | |
| | Sets upper limit for PID controller output | | | | | | | | |
| Dependency: | If f_max (P1082) is greater than P2000 (reference frequency), either P2000 or P2291 (PID output upper limit) must be changed to achieve f_max. | | | | | | | | |
| Note: | P2291 = 100 % corresponds to 4000 hex (as defined by P2000 (reference frequency)). | | | | | | | | |
| P2292 | PID output lower limit [%] | -200.00 - 200.00 | 0.00 | U, T | - | - | Float | 2 | |
| | Sets lower limit for the PID controller output. | | | | | | | | |
| Dependency: | A negative value allows bipolar operation of PID controller. | | | | | | | | |
| Note: | P2292 = 100 % corresponds to 4000 hex. | | | | | | | | |
| P2293 | Ramp-up / -down time of PID limit [s] | 0.00 - 100.00 | 1.00 | U, T | - | - | Float | 3 | |
| | Sets maximum ramp rate on output of PID. When PI is enabled, the output limits are ramped up from 0 to the limits set in P2291 (PID output upper limit) and P2292 (PID output lower limit). Limits prevent large step changes appearing on the output of the PID when the inverter is started. Once the limits have been reached, the PID controller output is instantaneous. These ramp times are used whenever a RUN command is issued. | | | | | | | | |
| Note: | If an OFF1 or OFF 3 are issued, the inverter output frequency ramps down as set in P1121 (ramp-down time) or P1135 (OFF3 ramp-down time). | | | | | | | | |
| r2294 | CO: Actual PID output [%] | - | - | - | - | - | Float | 2 | |
| | Displays PID output. | | | | | | | | |
| Note: | r2294 = 100 % corresponds to 4000 hex. | | | | | | | | |
| P2295 | Gain applied to PID output | -100.00 - 100.00 | 100.00 | U, T | - | - | Float | 3 | |
| | Allows the user to scale the PID output as a percentage value. A gain of 100.0 % means that output signal has not changed from its default value. | | | | | | | | |
| Note: | The ramp rate applied by the PID controller is clamped to a rate of 0.1s / 100% to protect the inverter. | | | | | | | | |
| P2350 | PID autotune enable | 0 - 4 | 0 | U, T | - | - | U16 | 2 | |
| | Enables autotune function of PID controller. | | | | | | | | |
| | 0 | PID autotuning disabled | | | | | | | |
| | 1 | PID autotuning via Ziegler Nichols (ZN) standard | | | | | | | |
| | 2 | PID autotuning as 1 plus some overshoot (O/S) | | | | | | | |
| | 3 | PID autotuning as 2 little or no overshoot (O/S) | | | | | | | |
| | 4 | PID autotuning PI only, quarter damped response | | | | | | | |
| Dependency: | Active when PID loop is enabled (see P2200). | | | | | | | | |
| Note: | <ul style="list-style-type: none"> • P2350 = 1 This is the standard Ziegler Nichols (ZN) tuning which should be a quarter damped response to a step. • P2350 = 2 This tuning will give some overshoot (O/S) but should be faster than option 1. • P2350 = 3 This tuning should give little or no overshoot but will not be as fast as option 2. | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------|---|--------------|-----------------|----------------|---------|----------|-----------|------------|
| | <ul style="list-style-type: none"> P2350 = 4 <p>This tuning only changes values of P and I and should be a quarter damped response. The option to be selected depends on the application but broadly speaking option 1 will give a good response, whereas if a faster response is desired option 2 should be selected. If no overshoot is desired then option 3 is the choice. For cases where no D term is wanted then option 4 can be selected.</p> <p>The tuning procedure is the same for all options. It is just the calculation of P and D values that is different. After autotune this parameter is set to zero (autotune completed).</p> | | | | | | | |
| P2354 | PID tuning timeout length [s] | 60 - 65000 | 240 | U, T | - | - | U16 | 3 |
| | This parameter determines the time that the autotuning code will wait before aborting a tuning run if no oscillation has been obtained. | | | | | | | |
| P2355 | PID tuning offset [%] | 0.00 - 20.00 | 5.00 | U, T | - | - | Float | 3 |
| | Sets applied offset and deviation for PID autotuning. | | | | | | | |
| Note: | This can be varied depending on plant conditions e.g. a very long system time constant might require a larger value. | | | | | | | |
| P2360[0...2] | Enable cavitation protection | 0 - 2 | 0 | U, T | - | DDS | U16 | 2 |
| | <p>Cavitation protection enabled. Will generate a fault / warning when cavitation conditions are deemed to be present.</p> <pre> graph TD A["Feedback flow / pressure sensor r2272"] --> B["<"] B --> C["Trip level 0.00...200.00 [%] P2361 (40.00)"] C --> D["Statusword 2 bit 10 PID minimum limit reached R53.10"] E["Statusword 2 bit 11 PID maximum limit reached R53.11"] --> F["≥1"] F --> G["Statusword1 bit 2 PID inverter running R52.02"] H["PID enable / disable P2200.CDS ≥(0)"] --> I[">"] I --> J["Cavitation protection enable 0..2 P2360 (0)"] J --> K["&"] L["Cavitation protection delay 0 ... 65000 [s] P2362 (30)"] --> M["T 0"] M --> N["Cavitation protection disabled Trigger cavitation fault F410 Trigger cavitation warning A930 Not used"] N --> O["0 0 0 1 1 0 1 1"] </pre> <p>Cavitation Protection Logic Diagram</p> | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | |
|-----------------|--|--|-----------------|----------------|---------|----------|-----------|------------|--|--|--|--|--|--|--|
| | 0 | Disable | | | | | | | | | | | | | |
| | 1 | Fault | | | | | | | | | | | | | |
| | 2 | Warn | | | | | | | | | | | | | |
| P2361[0..2] | Cavitation threshold [%] | 0.00 - 200.00 | 40.00 | U, T | - | DDS | Float | 2 | | | | | | | |
| | | Feedback threshold over which a fault / warning is triggered, as a percentage (%). | | | | | | | | | | | | | |
| P2362[0..2] | Cavitation protection time [s] | 0 - 65000 | 30 | U, T | - | DDS | U16 | 2 | | | | | | | |
| | | The time for which cavitation conditions have to be present before a fault / warning is triggered. | | | | | | | | | | | | | |
| P2365[0..2] | Hibernation enable / disable | 0 - 1 | 0 | U, T | - | DDS | U16 | 2 | | | | | | | |
| | | Enable or disable the hibernation functionality. 0 = disabled 1 = enabled | | | | | | | | | | | | | |
| P2366[0..2] | Delay before stopping motor [s] | 0 - 254 | 5 | U, T | - | DDS | U16 | 3 | | | | | | | |
| | | With hibernation enabled. If the frequency demand drops below the threshold there is a delay of P2366 seconds before the inverter is stopped. | | | | | | | | | | | | | |
| P2367[0..2] | Delay before starting motor [s] | 0 - 254 | 2 | U, T | - | DDS | U16 | 3 | | | | | | | |
| | | With hibernation enabled. If pulses have been disabled by the unit going into hibernation, and the frequency demand has increased to above the hibernation threshold, there will be a delay of P2367 seconds before the inverter restarts. | | | | | | | | | | | | | |
| P2370[0..2] | Motor staging stop mode | 0 - 1 | 0 | T | - | DDS | U16 | 3 | | | | | | | |
| | | Selects stop mode for external motors when motor staging is in use. | | | | | | | | | | | | | |
| | 0 | Normal stop | | | | | | | | | | | | | |
| | 1 | Sequence stop | | | | | | | | | | | | | |
| P2371[0..2] | Motor staging configuration | 0 - 3 | 0 | T | - | DDS | U16 | 3 | | | | | | | |
| | | Selects configuration of external motors (M1, M2) used for motor staging feature. | | | | | | | | | | | | | |
| | 0 | Motor staging disabled | | | | | | | | | | | | | |
| | 1 | M1 = 1 x MV, M2 = Not fitted | | | | | | | | | | | | | |
| | 2 | M1 = 1 x MV, M2 = 1 x MV | | | | | | | | | | | | | |
| | 3 | M1 = 1 x MV, M2 = 2 x MV | | | | | | | | | | | | | |
| Caution: | For this kind of motor application it is mandatory to disable negative frequency setpoint! | | | | | | | | | | | | | | |
| Note: | Motor staging allows the control of up to 2 additional staged pumps or fans, based on a PID control system. The complete system consists of one pump controlled by the inverter with up to 2 further pumps / fans controlled from contactors or motor starters. The contactors or motor starter are controlled by outputs from the inverter. | | | | | | | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-----------|--|-------|-----------------|----------------|---------|----------|-----------|------------|--|--|----|----|----|----|----|----|----|-----------|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|---|-------|----|-------|-------|-------|-------|-------|---|-------|----|----|-------|-------|-------|-------|--|--|--|--|--|--|--|
| | <p>The diagram below shows a typical pumping system. A similar system could be set up using fans and air ducts, instead of pumps and pipes.</p> <p>Mains</p> <p>By default the motor states are controlled from digital outputs (DO).</p> <p>In the text below, the following terminology will be used:</p> <ul style="list-style-type: none"> MV - Variable speed (Inverter controlled motor) M1 - Motor switched with digital output 1 (DO1) M2 - Motor switched with digital output 2 (DO2) <p>Staging: The process of starting one of the fixed speed motors.</p> <p>De-staging: The process of stopping one of the fixed speed motors.</p> <p>When the inverter is running at maximum frequency, and the PID feedback indicates that a higher speed is required, the inverter switches on (stages) one of the digital output controlled motors M1 and M2.</p> <p>At the same time, to keep the controlled variable as constant as possible, the inverter must ramp down to minimum frequency.</p> <p>Therefore, during the staging process, PID control must be suspended (see P2378 and diagram below).</p> <p>Staging of external motors (M1, M2)</p> <table style="width: 100%; text-align: center;"> <tr> <td style="width: 10%;"></td> <td colspan="7">Switch-on</td> </tr> <tr> <td></td> <td>1.</td> <td>2.</td> <td>3.</td> <td>4.</td> <td>5.</td> <td>6.</td> <td>7.</td> </tr> <tr> <td>P2371 = 0</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> </tr> <tr> <td>1</td> <td>-</td> <td>M1</td> <td>M1</td> <td>M1</td> <td>M1</td> <td>M1</td> <td>M1</td> </tr> <tr> <td>2</td> <td>-</td> <td>M1</td> <td>M1+M2</td> <td>M1+M2</td> <td>M1+M2</td> <td>M1+M2</td> <td>M1+M2</td> </tr> <tr> <td>3</td> <td>-</td> <td>M1</td> <td>M2</td> <td>M1+M2</td> <td>M1+M2</td> <td>M1+M2</td> <td>M1+M2</td> </tr> </table> | | Switch-on | | | | | | | | 1. | 2. | 3. | 4. | 5. | 6. | 7. | P2371 = 0 | - | - | - | - | - | - | - | 1 | - | M1 | M1 | M1 | M1 | M1 | M1 | 2 | - | M1 | M1+M2 | M1+M2 | M1+M2 | M1+M2 | M1+M2 | 3 | - | M1 | M2 | M1+M2 | M1+M2 | M1+M2 | M1+M2 | | | | | | | |
| | Switch-on | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 1. | 2. | 3. | 4. | 5. | 6. | 7. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P2371 = 0 | - | - | - | - | - | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | - | M1 | M1 | M1 | M1 | M1 | M1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | - | M1 | M1+M2 | M1+M2 | M1+M2 | M1+M2 | M1+M2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | - | M1 | M2 | M1+M2 | M1+M2 | M1+M2 | M1+M2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <p>When the inverter is running at minimum frequency, and the PID feedback indicates that a lower speed is required, the inverter switches off (de-stages) one of the digital output controlled motors M1 and M2.</p> <p>In this case, the inverter must ramp from minimum frequency to maximum frequency outside of PID control (see P2378 and diagram below).</p> <p>Destaging of external motors (M1, M2)</p> <table style="width: 100%; text-align: center;"> <tr> <td style="width: 10%;"></td> <td colspan="7">Switch-off</td> </tr> <tr> <td></td> <td>1.</td> <td>2.</td> <td>3.</td> <td>4.</td> <td>5.</td> <td>6.</td> <td>7.</td> </tr> <tr> <td>P2371 = 0</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> </tr> <tr> <td>1</td> <td>M1</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> </tr> <tr> <td>2</td> <td>M1+M2</td> <td>M1</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> </tr> <tr> <td>3</td> <td>M1+M2</td> <td>M2</td> <td>M1</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> </tr> </table> | | Switch-off | | | | | | | | 1. | 2. | 3. | 4. | 5. | 6. | 7. | P2371 = 0 | - | - | - | - | - | - | - | 1 | M1 | - | - | - | - | - | - | 2 | M1+M2 | M1 | - | - | - | - | - | 3 | M1+M2 | M2 | M1 | - | - | - | - | | | | | | | |
| | Switch-off | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 1. | 2. | 3. | 4. | 5. | 6. | 7. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P2371 = 0 | - | - | - | - | - | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | M1 | - | - | - | - | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | M1+M2 | M1 | - | - | - | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | M1+M2 | M2 | M1 | - | - | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

Parameter list


7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------|---|-------------|-----------------|----------------|---------|----------|-----------|------------|
| P2372[0..2] | Motor staging cycling | 0 - 1 | 0 | T | - | DDS | U16 | 3 |
| | Enables motor cycling for the motor staging feature. When enabled, the motor selected for staging / destaging is based on the hours run counter P2380. When staging, the motor with the least hours is switched on. When destaging, the motor with most hours is switched off. If staged motors are different sizes the choice of motor is first based on required motor size, and then if there is still a choice, on hours run. | | | | | | | |
| | 0 Disabled | | | | | | | |
| | 1 Enabled | | | | | | | |
| P2373[0..2] | Motor staging hysteresis [%] | 0.0 - 200.0 | 20.0 | U, T | PERCENT | DDS | Float | 3 |
| | P2373 as a percentage of PID setpoint that PID error P2273 must be exceeded before staging delay starts. | | | | | | | |
| Note: | The value of this parameter must always be smaller than delay override lockout timer P2377. | | | | | | | |
| P2374[0..2] | Motor staging delay [s] | 0 - 650 | 30 | U, T | - | DDS | U16 | 3 |
| | Time that PID error P2273 must exceed motor staging hysteresis P2373 before staging occurs. | | | | | | | |
| P2375[0..2] | Motor destaging delay [s] | 0 - 650 | 30 | U, T | - | DDS | U16 | 3 |
| | Time that PID error P2273 must exceed motor staging hysteresis P2373 before destaging occurs. | | | | | | | |
| P2376[0..2] | Motor staging delay override [%] | 0.0 - 200.0 | 25.0 | U, T | PERCENT | DDS | Float | 3 |
| | P2376 as a percentage of PID setpoint. When the PID error P2273 exceeds this value, a motor is staged / destaged irrespective of the delay timers. | | | | | | | |
| Note: | The value of this parameter must always be larger than staging hysteresis P2373. | | | | | | | |
| P2377[0..2] | Motor staging lockout timer [s] | 0 - 650 | 30 | U, T | - | DDS | U16 | 3 |
| | Time for which delay override is prevented after a motor has been staged or destaged. This prevents a second staging event immediately after a first, being caused by the transient conditions after the first staging event. | | | | | | | |
| P2378[0..2] | Motor staging frequency f_st [%] | 0.0 - 120.0 | 50.0 | U, T | PERCENT | DDS | Float | 3 |
| | The frequency as a percentage of maximum frequency. During a (de) staging event, as the inverter ramps from maximum to minimum frequency (or vice versa) this is the frequency at which the digital output (DO) is switched. | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|-----------|--|-------|-----------------|----------------|---------|----------|-----------|------------|
| | <p>This is illustrated by the following diagrams.</p> <p>Staging:</p> <p>Condition for staging:</p> <ul style="list-style-type: none"> ④ $f_{act} \geq P1082$ ⑤ $\Delta_{PID} \geq P2373$ ⑥ $t_{④⑤} > P2374$ <p>Equation for t_y:</p> $t_y = \left(1 - \frac{P2378}{100}\right) \cdot P1121$ | | | | | | | |
| | <p>Destaging:</p> <p>Condition for destaging:</p> <ul style="list-style-type: none"> ⑦ $f_{act} \leq P1080$ ⑧ $\Delta_{PID} \leq -P2373$ ⑨ $t_{⑦⑧} > P2375$ <p>Equation for t_x:</p> $t_x = \left(\frac{P2378 - P1080}{100} - \frac{P1080 - P1082}{100}\right) \cdot P1120$ | | | | | | | |

Parameter list


7.2 Parameter list



| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|----------------|-----------------|----------------|---------|----------|-----------|------------|
| | 1 | Level 1 | | | | | | |
| | 2 | Level 2 | | | | | | |
| | ... | ... | | | | | | |
| | 6 | Level 6 | | | | | | |
| Example: | P2801[3] = 2, P2801[4] = 2, P2802[3] = 3, P2802[4] = 2 FFBs will be calculated in following order: P2802[3], P2801[3], P2801[4], P2802[4] | | | | | | | |
| Index: | [0] | Enable AND 1 | | | | | | |
| | [1] | Enable AND 2 | | | | | | |
| | [2] | Enable AND 3 | | | | | | |
| | [3] | Enable OR 1 | | | | | | |
| | [4] | Enable OR 2 | | | | | | |
| | [5] | Enable OR 3 | | | | | | |
| | [6] | Enable XOR 1 | | | | | | |
| | [7] | Enable XOR 2 | | | | | | |
| | [8] | Enable XOR 3 | | | | | | |
| | [9] | Enable NOT 1 | | | | | | |
| | [10] | Enable NOT 2 | | | | | | |
| | [11] | Enable NOT 3 | | | | | | |
| | [12] | Enable D-FF 1 | | | | | | |
| | [13] | Enable D-FF 2 | | | | | | |
| | [14] | Enable RS-FF 1 | | | | | | |
| | [15] | Enable RS-FF 2 | | | | | | |
| | [16] | Enable RS-FF 3 | | | | | | |
| Dependency: | Set P2800 to 1 to enable function blocks. All active function blocks will be calculated in every 128 ms, if set to level 1 ... 3. Fast free function blocks (level 4 ... 6) will be calculated in every 8 ms. | | | | | | | |
| P2802[0...13] | Activate FFBs | 0 - 3 | 0 | U, T | - | - | U16 | 3 |
| | Enables free function blocks (FFB) and determines the chronological order of each function block. See P2801. | | | | | | | |
| | 0 | Not Active | | | | | | |
| | 1 | Level 1 | | | | | | |
| | 2 | Level 2 | | | | | | |
| | 3 | Level 3 | | | | | | |
| Index: | [0] | Enable timer 1 | | | | | | |
| | [1] | Enable timer 2 | | | | | | |
| | [2] | Enable timer 3 | | | | | | |
| | [3] | Enable timer 4 | | | | | | |
| | [4] | Enable ADD 1 | | | | | | |
| | [5] | Enable ADD 2 | | | | | | |
| | [6] | Enable SUB 1 | | | | | | |
| | [7] | Enable SUB 2 | | | | | | |
| | [8] | Enable MUL 1 | | | | | | |
| | [9] | Enable MUL 2 | | | | | | |
| | [10] | Enable DIV 1 | | | | | | |
| | [11] | Enable DIV 2 | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | | | | | | | | | |
|--------------------|---|-------------------------|-----------------|----------------|----------|----------|--------------|------------|----|---|---|---|---|---|---|---|--|--|--|--|--|--|--|
| | [12] | Enable CMP 1 | | | | | | | | | | | | | | | | | | | | | |
| | [13] | Enable CMP 2 | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | Set P2800 to 1 to enable function blocks. All active function blocks, enabled with P2802, will be calculated in every 128 ms. | | | | | | | | | | | | | | | | | | | | | | |
| P2803[0..2] | Enable Fast FFBs | 0 - 1 | 0 | U, T | - | CDS | U16 | 3 | | | | | | | | | | | | | | | |
| | Fast free function blocks (FFB) are enabled in two steps: 1. P2803 enables the use of fast free function blocks (P2803 = 1). 2. P2801 enables each fast free function block individually and determines the chronological order (P2801[x] = 4 ... 6). | | | | | | | | | | | | | | | | | | | | | | |
| | 0 | Disable | | | | | | | | | | | | | | | | | | | | | |
| | 1 | Enable | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | All active fast function blocks will be calculated in every 8 ms. | | | | | | | | | | | | | | | | | | | | | | |
| Note: | Attention: P2200 and P2803 are locked parameter against each other. PID and FFB of the same data set cannot be active at same time. | | | | | | | | | | | | | | | | | | | | | | |
| P2810[0..1] | BI: AND 1 | - | 0 | U, T | - | - | U32 / Bin | 3 | | | | | | | | | | | | | | | |
| | P2810[0], P2810[1] define inputs of AND 1 element, output is r2811. | | | | | | | | | | | | | | | | | | | | | | |
| |  | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th>A</th> <th>B</th> <th>C</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> </tr> </tbody> </table> | A | B | C | 0 | 0 | 0 | 0 | 1 | 0 | 1 | 0 | 0 | 1 | 1 | 1 | | | | | | | |
| A | B | C | | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | 0 | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | 0 | | | | | | | | | | | | | | | | | | | | | |
| 1 | 0 | 0 | | | | | | | | | | | | | | | | | | | | | |
| 1 | 1 | 1 | | | | | | | | | | | | | | | | | | | | | |
| Index: | [0] | Binector input 0 (BI 0) | | | | | | | | | | | | | | | | | | | | | |
| | [1] | Binector input 1 (BI 1) | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | P2801[0] assigns the AND element to the processing sequence. | | | | | | | | | | | | | | | | | | | | | | |
| r2811.0 | BO: AND 1 | - | - | - | - | - | U16 | 3 | | | | | | | | | | | | | | | |
| | Output of AND 1 element. Displays and logic of bits defined in P2810[0], P2810[1]. | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th>Bit</th> <th>Signal name</th> <th>1 signal</th> <th>0 signal</th> </tr> </thead> <tbody> <tr> <td>00</td> <td>Output of BO</td> <td>Yes</td> <td>No</td> </tr> </tbody> </table> | Bit | Signal name | 1 signal | 0 signal | 00 | Output of BO | Yes | No | | | | | | | | | | | | | | |
| Bit | Signal name | 1 signal | 0 signal | | | | | | | | | | | | | | | | | | | | |
| 00 | Output of BO | Yes | No | | | | | | | | | | | | | | | | | | | | |
| Dependency: | See P2810 | | | | | | | | | | | | | | | | | | | | | | |
| P2812[0..1] | BI: AND 2 | - | 0 | U, T | - | - | U32 / Bin | 3 | | | | | | | | | | | | | | | |
| | P2812[0], 2812[1] define inputs of AND 2 element, output is r2813. | | | | | | | | | | | | | | | | | | | | | | |
| Index: | See P2810 | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | P2801[1] assigns the AND element to the processing sequence. | | | | | | | | | | | | | | | | | | | | | | |
| r2813.0 | BO: AND 2 | - | - | - | - | - | U16 | 3 | | | | | | | | | | | | | | | |
| | Output of AND 2 element. Displays and logic of bits defined in P2812[0], P2812[1]. See r2811 for the bit field description. | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | See P2812 | | | | | | | | | | | | | | | | | | | | | | |
| P2814[0..1] | BI: AND 3 | - | 0 | U, T | - | - | U32 / Bin | 3 | | | | | | | | | | | | | | | |
| | P2814[0], P2814[1] define inputs of AND 3 element, output is r2815. | | | | | | | | | | | | | | | | | | | | | | |
| Index: | See P2810 | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | P2801[2] assigns the AND element to the processing sequence. | | | | | | | | | | | | | | | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | | | | | | | | | |
|--------------------|--|-------|-----------------|----------------|---------|----------|-----------|------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| r2815.0 | BO: AND 3 | - | - | - | - | - | U16 | 3 | | | | | | | | | | | | | | | |
| | Output of AND 3 element. Displays and logic of bits defined in P2814[0], P2814[1]. See r2811 for the bit field description. | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | See P2814 | | | | | | | | | | | | | | | | | | | | | | |
| P2816[0...1] | BI: OR 1 | - | 0 | U, T | - | - | U32 / Bin | 3 | | | | | | | | | | | | | | | |
| | P2816[0], P2816[1] define inputs of OR 1 element, output is r2817. <table border="1"> <thead> <tr> <th>A</th> <th>B</th> <th>C</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> </tr> </tbody> </table> | | | | | | | | A | B | C | 0 | 0 | 0 | 0 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 1 |
| A | B | C | | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | 0 | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | 1 | | | | | | | | | | | | | | | | | | | | | |
| 1 | 0 | 1 | | | | | | | | | | | | | | | | | | | | | |
| 1 | 1 | 1 | | | | | | | | | | | | | | | | | | | | | |
| Index: | See P2810 | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | P2801[3] assigns the OR element to the processing sequence. | | | | | | | | | | | | | | | | | | | | | | |
| r2817.0 | BO: OR 1 | - | - | - | - | - | U16 | 3 | | | | | | | | | | | | | | | |
| | Output of OR 1 element. Displays or logic of bits defined in P2816[0], P2816[1]. See r2811 for the bit field description. | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | See P2816 | | | | | | | | | | | | | | | | | | | | | | |
| P2818[0...1] | BI: OR 2 | - | 0 | U, T | - | - | U32 / Bin | 3 | | | | | | | | | | | | | | | |
| | P2818[0], P2818[1] define inputs of OR 2 element, output is r2819. | | | | | | | | | | | | | | | | | | | | | | |
| Index: | See P2810 | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | P2801[4] assigns the OR element to the processing sequence. | | | | | | | | | | | | | | | | | | | | | | |
| r2819.0 | BO: OR 2 | - | - | - | - | - | U16 | 3 | | | | | | | | | | | | | | | |
| | Output of OR 2 element. Displays or logic of bits defined in P2818[0], P2818[1]. See r2811 for the bit field description. | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | See P2818 | | | | | | | | | | | | | | | | | | | | | | |
| P2820[0...1] | BI: OR 3 | - | 0 | U, T | - | - | U32 / Bin | 3 | | | | | | | | | | | | | | | |
| | P2820[0], P2820[1] define inputs of OR 3 element, output is r2821. | | | | | | | | | | | | | | | | | | | | | | |
| Index: | See P2810 | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | P2801[5] assigns the OR element to the processing sequence. | | | | | | | | | | | | | | | | | | | | | | |
| r2821.0 | BO: OR 3 | - | - | - | - | - | U16 | 3 | | | | | | | | | | | | | | | |
| | Output of OR 3 element. Displays or logic of bits defined in P2820[0], P2820[1]. See r2811 for the bit field description. | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | See P2820 | | | | | | | | | | | | | | | | | | | | | | |
| P2822[0...1] | BI: XOR 1 | - | 0 | U, T | - | - | U32 / Bin | 3 | | | | | | | | | | | | | | | |
| | P2822[0], P2822[1] define inputs of XOR 1 element, output is r2823. <table border="1"> <thead> <tr> <th>A</th> <th>B</th> <th>C</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> </tr> <tr> <td>1</td> <td>1</td> <td>0</td> </tr> </tbody> </table> | | | | | | | | A | B | C | 0 | 0 | 0 | 0 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 0 |
| A | B | C | | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | 0 | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | 1 | | | | | | | | | | | | | | | | | | | | | |
| 1 | 0 | 1 | | | | | | | | | | | | | | | | | | | | | |
| 1 | 1 | 0 | | | | | | | | | | | | | | | | | | | | | |
| Index: | See P2810 | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | P2801[6] assigns the XOR element to the processing sequence. | | | | | | | | | | | | | | | | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | |
|--------------------|---|-------|-----------------|----------------|---------|----------|-----------|------------|---|---|---|---|---|---|
| r2823.0 | BO: XOR 1 | - | - | - | - | - | U16 | 3 | | | | | | |
| | Output of XOR 1 element. Displays exclusive-or logic of bits defined in P2822[0], P2822[1]. See r2811 for the bit field description. | | | | | | | | | | | | | |
| Dependency: | See P2822 | | | | | | | | | | | | | |
| P2824[0...1] | BI: XOR 2 | - | 0 | U, T | - | - | U32 / Bin | 3 | | | | | | |
| | P2824[0], P2824[1] define inputs of XOR 2 element, output is r2825. | | | | | | | | | | | | | |
| Index: | See P2810 | | | | | | | | | | | | | |
| Dependency: | P2801[7] assigns the XOR element to the processing sequence. | | | | | | | | | | | | | |
| r2825.0 | BO: XOR 2 | - | - | - | - | - | U16 | 3 | | | | | | |
| | Output of XOR 2 element. Displays exclusive-or logic of bits defined in P2824[0], P2824[1]. See r2811 for the bit field description. | | | | | | | | | | | | | |
| Dependency: | See P2824 | | | | | | | | | | | | | |
| P2826[0...1] | BI: XOR 3 | - | 0 | U, T | - | - | U32 / Bin | 3 | | | | | | |
| | P2826[0], P2826[1] define inputs of XOR 3 element, output is r2827. | | | | | | | | | | | | | |
| Index: | See P2810 | | | | | | | | | | | | | |
| Dependency: | P2801[8] assigns the XOR element to the processing sequence. | | | | | | | | | | | | | |
| r2827.0 | BO: XOR 3 | - | - | - | - | - | U16 | 3 | | | | | | |
| | Output of XOR 3 element. Displays exclusive-or logic of bits defined in P2826[0], P2826[1]. See r2811 for the bit field description. | | | | | | | | | | | | | |
| Dependency: | See P2826 | | | | | | | | | | | | | |
| P2828 | BI: NOT 1 | - | 0 | U, T | - | - | U32 / Bin | 3 | | | | | | |
| | P2828 defines input of NOT 1 element, output is r2829. | | | | | | | | | | | | | |
| | <pre> graph TD P2828[P2828 Index 0] -- A --> Inv(()) Inv -- C --> R2829[r2829] P2800 --- Inv P2801[9] --- Inv </pre> <table border="1"> <tr><td>A</td><td>C</td></tr> <tr><td>0</td><td>1</td></tr> <tr><td>1</td><td>0</td></tr> </table> | | | | | | | | A | C | 0 | 1 | 1 | 0 |
| A | C | | | | | | | | | | | | | |
| 0 | 1 | | | | | | | | | | | | | |
| 1 | 0 | | | | | | | | | | | | | |
| Dependency: | P2801[9] assigns the NOT element to the processing sequence. | | | | | | | | | | | | | |
| r2829.0 | BO: NOT 1 | - | - | - | - | - | U16 | 3 | | | | | | |
| | Output of NOT 1 element. Displays not logic of bit defined in P2828. See r2811 for the bit field description. | | | | | | | | | | | | | |
| Dependency: | See P2828 | | | | | | | | | | | | | |
| P2830 | BI: NOT 2 | - | 0 | U, T | - | - | U32 / Bin | 3 | | | | | | |
| | P2830 defines input of NOT 2 element, output is r2831. | | | | | | | | | | | | | |
| Dependency: | P2801[10] assigns the NOT element to the processing sequence. | | | | | | | | | | | | | |
| r2831.0 | BO: NOT 2 | - | - | - | - | - | U16 | 3 | | | | | | |
| | Output of NOT 2 element. Displays not logic of bit defined in P2830. See r2811 for the bit field description. | | | | | | | | | | | | | |
| Dependency: | See P2830 | | | | | | | | | | | | | |
| P2832 | BI: NOT 3 | - | 0 | U, T | - | - | U32 / Bin | 3 | | | | | | |
| | P2832 defines input of NOT 3 element, output is r2833. | | | | | | | | | | | | | |
| Dependency: | P2801[11] assigns the NOT element to the processing sequence. | | | | | | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--------------------|--|-----------------------------|-----------------|----------------|-----------------|----------|-----------|------------|-----|-------|---|-------|---|-----------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|-----------|-----------------|---|---|---|---|---|---|---|---|---|---|---|---|----------|--|--|--|---|---|
| r2833.0 | BO: NOT 3 | - | - | - | - | - | U16 | 3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Output of NOT 3 element. Displays not logic of bit defined in P2832. See r2811 for the bit field description. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | See P2832 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P2834[0...3] | BI: D-FF 1 | - | 0 | U, T | - | - | U32 / Bin | 3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | P2834[0], P2834[1], P2834[2], P2834[3] define inputs of D-FlipFlop 1, outputs are r2835, r2836. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1"> <tr> <th>SET</th> <th>RESET</th> <th>D</th> <th>STORE</th> <th>Q</th> <th>\bar{Q}</th> </tr> <tr> <td>1</td> <td>0</td> <td>x</td> <td>x</td> <td>1</td> <td>0</td> </tr> <tr> <td>0</td> <td>1</td> <td>x</td> <td>x</td> <td>0</td> <td>1</td> </tr> <tr> <td>1</td> <td>1</td> <td>x</td> <td>x</td> <td>Q_{n-1}</td> <td>\bar{Q}_{n-1}</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>↑</td> <td>1</td> <td>0</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>↑</td> <td>0</td> <td>1</td> </tr> <tr> <td colspan="4">POWER-ON</td><td>0</td><td>1</td></tr> </table> | | | | | | | | SET | RESET | D | STORE | Q | \bar{Q} | 1 | 0 | x | x | 1 | 0 | 0 | 1 | x | x | 0 | 1 | 1 | 1 | x | x | Q_{n-1} | \bar{Q}_{n-1} | 0 | 0 | 1 | ↑ | 1 | 0 | 0 | 0 | 0 | ↑ | 0 | 1 | POWER-ON | | | | 0 | 1 |
| SET | RESET | D | STORE | Q | \bar{Q} | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 0 | x | x | 1 | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | x | x | 0 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 1 | x | x | Q_{n-1} | \bar{Q}_{n-1} | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | 1 | ↑ | 1 | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | 0 | ↑ | 0 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| POWER-ON | | | | 0 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Index: | [0] | Binector input: Set | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | [1] | Binector input: D input | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | [2] | Binector input: Store pulse | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | [3] | Binector input: Reset | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | P2801[12] assigns the D-FlipFlop to the processing sequence. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| r2835.0 | BO: Q D-FF 1 | - | - | - | - | - | U16 | 3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Displays output of D-FlipFlop 1, inputs are defined in P2834[0], P2834[1], P2834[2], P2834[3]. See r2811 for the bit field description. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | See P2834 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| r2836.0 | BO: NOT-Q D-FF 1 | - | - | - | - | - | U16 | 3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Displays Not-output of D-FlipFlop 1, inputs are defined in P2834[0], P2834[1], P2834[2], P2834[3]. See r2811 for the bit field description. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | See P2834 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P2837[0...3] | BI: D-FF 2 | - | 0 | U, T | - | - | U32 / Bin | 3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | P2837[0], P2837[1], P2837[2], P2837[3] define inputs of D-FlipFlop 2, outputs are r2838, r2839. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Index: | See P2834 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | P2801[13] assigns the D-FlipFlop to the processing sequence. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| r2838.0 | BO: Q D-FF 2 | - | - | - | - | - | U16 | 3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Displays output of D-FlipFlop 2, inputs are defined in P2837[0], P2837[1], P2837[2], P2837[3]. See r2811 for the bit field description. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | See P2837 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | | | | | | | | | | | | | | | | | | |
|--------------------|---|-----------------------|-----------------|----------------|---------|----------|-----------|------------|-----|-------|---|-----------|---|---|-----------|-----------------|---|---|---|---|---|---|---|---|---|---|-----------|-----------------|----------|--|---|---|
| r2839.0 | BO: NOT-Q D-FF 2 | - | - | - | - | - | U16 | 3 | | | | | | | | | | | | | | | | | | | | | | | | |
| | Displays Not-output of D-FlipFlop 2, inputs are defined in P2837[0], P2837[1], P2837[2], P2837[3]. See r2811 for the bit field description. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | See P2837 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P2840[0...1] | BI: RS-FF 1 | - | 0 | U, T | - | - | U32 / Bin | 3 | | | | | | | | | | | | | | | | | | | | | | | | |
| | P2840[0], P2840[1] define inputs of RS-FlipFlop 1, outputs are r2841, r2842. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th>SET</th> <th>RESET</th> <th>Q</th> <th>\bar{Q}</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Q_{n-1}</td> <td>\bar{Q}_{n-1}</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>1</td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> <td>0</td> </tr> <tr> <td>1</td> <td>1</td> <td>Q_{n-1}</td> <td>\bar{Q}_{n-1}</td> </tr> <tr> <td colspan="2">POWER-ON</td><td>0</td><td>1</td></tr> </tbody> </table> | | | | | | | | SET | RESET | Q | \bar{Q} | 0 | 0 | Q_{n-1} | \bar{Q}_{n-1} | 0 | 1 | 0 | 1 | 1 | 0 | 1 | 0 | 1 | 1 | Q_{n-1} | \bar{Q}_{n-1} | POWER-ON | | 0 | 1 |
| SET | RESET | Q | \bar{Q} | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | Q_{n-1} | \bar{Q}_{n-1} | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | 0 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 0 | 1 | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 1 | Q_{n-1} | \bar{Q}_{n-1} | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| POWER-ON | | 0 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Index: | [0] | Binektor input: Set | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | [1] | Binektor input: Reset | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | P2801[14] assigns the RS-FlipFlop to the processing sequence. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| r2841.0 | BO: Q RS-FF 1 | - | - | - | - | - | U16 | 3 | | | | | | | | | | | | | | | | | | | | | | | | |
| | Displays output of RS-FlipFlop 1, inputs are defined in P2840[0], P2840[1]. See r2811 for the bit field description. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | See P2840 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| r2842.0 | BO: NOT-Q RS-FF 1 | - | - | - | - | - | U16 | 3 | | | | | | | | | | | | | | | | | | | | | | | | |
| | Displays Not-output of RS-FlipFlop 1, inputs are defined in P2840[0], P2840[1]. See r2811 for the bit field description. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | See P2840 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P2843[0...1] | BI: RS-FF 2 | - | 0 | U, T | - | - | U32 / Bin | 3 | | | | | | | | | | | | | | | | | | | | | | | | |
| | P2843[0], P2843[1] define inputs of RS-FlipFlop 2, outputs are r2844, r2845. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Index: | See P2840 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | P2801[15] assigns the RS-FlipFlop to the processing sequence. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| r2844.0 | BO: Q RS-FF 2 | - | - | - | - | - | U16 | 3 | | | | | | | | | | | | | | | | | | | | | | | | |
| | Displays output of RS-FlipFlop 2, inputs are defined in P2843[0], P2843[1]. See r2811 for the bit field description. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | See P2843 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| r2845.0 | BO: NOT-Q RS-FF 2 | - | - | - | - | - | U16 | 3 | | | | | | | | | | | | | | | | | | | | | | | | |
| | Displays Not-output of RS-FlipFlop 2, inputs are defined in P2843[0], P2843[1]. See r2811 for the bit field description. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | See P2843 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P2846[0...1] | BI: RS-FF 3 | - | 0 | U, T | - | - | U32 / Bin | 3 | | | | | | | | | | | | | | | | | | | | | | | | |
| | P2846[0], P2846[1] define inputs of RS-FlipFlop 3, outputs are r2847, r2848. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Index: | See P2840 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | P2801[16] assigns the RS-FlipFlop to the processing sequence. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| r2847.0 | BO: Q RS-FF 3 | - | - | - | - | - | U16 | 3 | | | | | | | | | | | | | | | | | | | | | | | | |
| | Displays output of RS-FlipFlop 3, inputs are defined in P2846[0], P2846[1]. See r2811 for the bit field description. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Dependency: | See P2846 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|-------|-----------------|----------------|---------|----------|-----------|------------|
| r2848.0 | BO: NOT-Q RS-FF 3 | - | - | - | - | - | U16 | 3 |
| | Displays Not-output of RS-FlipFlop 3, inputs are defined in P2846[0], P2846[1]. See r2811 for the bit field description. | | | | | | | |
| Dependency: | See P2846 | | | | | | | |
| P2849 | BI: Timer 1 | - | 0 | U, T | - | - | U32 / Bin | 3 |
| | Define input signal of timer 1. P2849, P2850, P2851 are the inputs of the timer, outputs are r2852, r2853. | | | | | | | |
| | | | | | | | | |
| Dependency: | P2802[0] assigns the timer to the processing sequence. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|---|--|---------------------------|-----------------|----------------|---------|----------|-----------|------------|
| P2850 | Delay time of timer 1 [s] | 0.0 - 9999.9 | 0.0 | U, T | - | - | Float | 3 |
| Defines delay time of timer 1. P2849, P2850, P2851 are the inputs of the timer, outputs are r2852, r2853. | | | | | | | | |
| Dependency: | See P2849 | | | | | | | |
| P2851 | Mode timer 1 | 0 - 13 | 0 | U, T | - | - | U16 | 3 |
| Selects mode of timer 1. P2849, P2850, P2851 are the inputs of the timer, outputs are r2852, r2853. | | | | | | | | |
| | 0 | ON delay (seconds) | | | | | | |
| | 1 | OFF delay (seconds) | | | | | | |
| | 2 | ON / OFF delay (seconds) | | | | | | |
| | 3 | Pulse generator (seconds) | | | | | | |
| | 10 | ON delay (minutes) | | | | | | |
| | 11 | OFF delay (minutes) | | | | | | |
| | 12 | ON / OFF delay (minutes) | | | | | | |
| | 13 | Pulse generator (minutes) | | | | | | |
| Dependency: | See P2849 | | | | | | | |
| r2852.0 | BO: Timer 1 | - | - | - | - | - | U16 | 3 |
| Displays output of timer 1. P2849, P2850, P2851 are the inputs of the timer, outputs are r2852, r2853. See r2811 for the bit field description. | | | | | | | | |
| Dependency: | See P2849 | | | | | | | |
| r2853.0 | BO: Nout timer 1 | - | - | - | - | - | U16 | 3 |
| Displays Not-output of timer 1. P2849, P2850, P2851 are the inputs of the timer, outputs are r2852, r2853. See r2811 for the bit field description. | | | | | | | | |
| Dependency: | See P2849 | | | | | | | |
| P2854 | BI: Timer 2 | - | 0 | U, T | - | - | U32 / Bin | 3 |
| Define input signal of timer 2. P2854, P2855, P2856 are the inputs of the timer, outputs are r2857, r2858. | | | | | | | | |
| Dependency: | P2802[1] assigns the timer to the processing sequence. | | | | | | | |
| P2855 | Delay time of timer 2 [s] | 0.0 - 9999.9 | 0.0 | U, T | - | - | Float | 3 |
| Defines delay time of timer 2. P2854, P2855, P2856 are the inputs of the timer, outputs are r2857, r2858. | | | | | | | | |
| Dependency: | See P2854 | | | | | | | |
| P2856 | Mode timer 2 | 0 - 13 | 0 | U, T | - | - | U16 | 3 |
| Selects mode of timer 2. P2854, P2855, P2856 are the inputs of the timer, outputs are r2857, r2858. See P2851 for value description. | | | | | | | | |
| Dependency: | See P2854 | | | | | | | |
| r2857.0 | BO: Timer 2 | - | - | - | - | - | U16 | 3 |
| Displays output of timer 2. P2854, P2855, P2856 are the inputs of the timer, outputs are r2857, r2858. See r2811 for the bit field description. | | | | | | | | |
| Dependency: | See P2854 | | | | | | | |
| r2858.0 | BO: Nout timer 2 | - | - | - | - | - | U16 | 3 |
| Displays Not-output of timer 2 P2854, P2855, P2856 are the inputs of the timer, outputs are r2857, r2858. See r2811 for the bit field description. | | | | | | | | |
| Dependency: | See P2854 | | | | | | | |
| P2859 | BI: Timer 3 | - | 0 | U, T | - | - | U32 / Bin | 3 |
| Define input signal of timer 3. P2859, P2860, P2861 are the inputs of the timer, outputs are r2862, r2863. | | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|---|--------------------------|-----------------|----------------|---------|----------|-----------|------------|
| Dependency: | P2802[2] assigns the timer to the processing sequence. | | | | | | | |
| P2860 | Delay time of timer 3 [s] | 0.0 - 9999.9 | 0.0 | U, T | - | - | Float | 3 |
| | Defines delay time of timer 3. P2859, P2860, P2861 are the inputs of the timer, outputs are r2862, r2863. | | | | | | | |
| Dependency: | See P2859 | | | | | | | |
| P2861 | Mode timer 3 | 0 - 13 | 0 | U, T | - | - | U16 | 3 |
| | Selects mode of timer 3. P2859, P2860, P2861 are the inputs of the timer, outputs are r2862, r2863. See P2851 for value description. | | | | | | | |
| Dependency: | See P2859 | | | | | | | |
| r2862.0 | BO: Timer 3 | - | - | - | - | - | U16 | 3 |
| | Displays output of timer 3. P2859, P2860, P2861 are the inputs of the timer, outputs are r2862, r2863. See r2811 for the bit field description. | | | | | | | |
| Dependency: | See P2859 | | | | | | | |
| r2863.0 | BO: Nout timer 3 | - | - | - | - | - | U16 | 3 |
| | Displays Not-output of timer 3. P2859, P2860, P2861 are the inputs of the timer, outputs are r2862, r2863. See r2811 for the bit field description. | | | | | | | |
| Dependency: | See P2859 | | | | | | | |
| P2864 | BI: Timer 4 | - | 0 | U, T | - | - | U32 / Bin | 3 |
| | Define input signal of timer 4. P2864, P2865, P2866 are the inputs of the timer, outputs are P2867, P2868. | | | | | | | |
| Dependency: | P2802[3] assigns the timer to the processing sequence. | | | | | | | |
| P2865 | Delay time of timer 4 [s] | 0.0 - 9999.9 | 0.0 | U, T | - | - | Float | 3 |
| | Defines delay time of timer 4. P2864, P2865, P2866 are the inputs of the timer, outputs are r2867, r2868. | | | | | | | |
| Dependency: | See P2864 | | | | | | | |
| P2866 | Mode timer 4 | 0 - 13 | 0 | U, T | - | - | U16 | 3 |
| | Selects mode of timer 4. P2864, P2865, P2866 are the inputs of the timer, outputs are r2867, r2868. See P2851 for value description. | | | | | | | |
| Dependency: | See P2864 | | | | | | | |
| r2867.0 | BO: Timer 4 | - | - | - | - | - | U16 | 3 |
| | Displays output of timer 4. P2864, P2865, P2866 are the inputs of the timer, outputs are r2867, r2868. See r2811 for the bit field description. | | | | | | | |
| Dependency: | See P2864 | | | | | | | |
| r2868.0 | BO: Nout timer 4 | - | - | - | - | - | U16 | 3 |
| | Displays Not-output of timer 4. P2864, P2865, P2866 are the inputs of the timer, outputs are r2867, r2868. See r2811 for the bit field description. | | | | | | | |
| Dependency: | See P2864 | | | | | | | |
| P2869[0...1] | CI: ADD 1 | - | 0 | U, T | 4000H | - | U32 / I16 | 3 |
| | Define inputs of Adder 1, result is in r2870. | | | | | | | |
| | <p style="text-align: center;">Result = $x_1 + x_2$</p> <p>If: $x_1 + x_2 > 200\% \rightarrow$ Result = 200%</p> <p>If: $x_1 + x_2 < -200\% \rightarrow$ Result = -200%</p> | | | | | | | |
| Index: | [0] | Connector input 0 (CI 0) | | | | | | |
| | [1] | Connector input 1 (CI 1) | | | | | | |

Parameter list


7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|---|-------|-----------------|----------------|---------|----------|-----------|------------|
| Dependency: | P2802[4] assigns the Adder to the processing sequence. | | | | | | | |
| r2870 | CO: ADD 1 | - | - | - | - | - | Float | 3 |
| | Result of Adder 1. | | | | | | | |
| Dependency: | See P2869 | | | | | | | |
| P2871[0...1] | Cl: ADD 2 | - | 0 | U, T | 4000H | - | U32 / I16 | 3 |
| | Define inputs of Adder 2, result is in r2872. | | | | | | | |
| Index: | See P2869 | | | | | | | |
| Dependency: | P2802[5] assigns the Adder to the processing sequence. | | | | | | | |
| r2872 | CO: ADD 2 | - | - | - | - | - | Float | 3 |
| | Result of Adder 2. | | | | | | | |
| Dependency: | See P2871 | | | | | | | |
| P2873[0...1] | Cl: SUB 1 | - | 0 | U, T | 4000H | - | U32 / I16 | 3 |
| | Define inputs of Subtractor 1, result is in r2874. | | | | | | | |
| | <p style="text-align: center;"> P2800 P2802[6] P2873 ┌─────────┐ Index 0 Index 1 └─────────┘ x1 → + → Result x2 → - → Result x1 - x2 → 200% → r2874 -200% </p> <p>Result = $x_1 - x_2$ If: $x_1 - x_2 > 200\% \rightarrow$ Result = 200% $x_1 - x_2 < -200\% \rightarrow$ Result = -200%</p> | | | | | | | |
| Index: | See P2869 | | | | | | | |
| Dependency: | P2802[6] assigns the Subtractor to the processing sequence. | | | | | | | |
| r2874 | CO: SUB 1 | - | - | - | - | - | Float | 3 |
| | Result of Subtractor 1. | | | | | | | |
| Dependency: | See P2873 | | | | | | | |
| P2875[0...1] | Cl: SUB 2 | - | 0 | U, T | 4000H | - | U32 / I16 | 3 |
| | Define inputs of Subtractor 2, result is in r2876. | | | | | | | |
| Index: | See P2869 | | | | | | | |
| Dependency: | P2802[7] assigns the Subtractor to the processing sequence. | | | | | | | |
| r2876 | CO: SUB 2 | - | - | - | - | - | Float | 3 |
| | Result of Subtractor 2. | | | | | | | |
| Dependency: | See P2875 | | | | | | | |
| P2877[0...1] | Cl: MUL 1 | - | 0 | U, T | 4000H | - | U32 / I16 | 3 |
| | Define inputs of Multiplier 1, result is in r2878. | | | | | | | |
| | <p style="text-align: center;"> P2800 P2802[8] P2877 ┌─────────┐ Index 0 Index 1 └─────────┘ x1 → × → Result x2 → - → Result x1 * x2 → 100% → r2878 -200% </p> <p>Result = $\frac{x_1 * x_2}{100\%}$ If: $\frac{x_1 * x_2}{100\%} > 200\% \rightarrow$ Result = 200% $\frac{x_1 * x_2}{100\%} < -200\% \rightarrow$ Result = -200%</p> | | | | | | | |
| Index: | See P2869 | | | | | | | |
| Dependency: | P2802[8] assigns the Multiplier to the processing sequence. | | | | | | | |
| r2878 | CO: MUL 1 | - | - | - | - | - | Float | 3 |
| | Result of Multiplier 1. | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|---|-------|-----------------|----------------|---------|----------|-----------|------------|
| Dependency: | See P2877 | | | | | | | |
| P2879[0...1] | Cl: MUL 2 | - | 0 | U, T | 4000H | - | U32 / I16 | 3 |
| | Define inputs of Multiplier 2, result is in r2880. | | | | | | | |
| Index: | See P2869 | | | | | | | |
| Dependency: | P2802[9] assigns the Multiplier to the processing sequence. | | | | | | | |
| r2880 | CO: MUL 2 | - | - | - | - | - | Float | 3 |
| | Result of Multiplier 2. | | | | | | | |
| Dependency: | See P2879 | | | | | | | |
| P2881[0...1] | Cl: DIV 1 | - | 0 | U, T | 4000H | - | U32 / I16 | 3 |
| | Define inputs of Divider 1, result is in r2882. | | | | | | | |
| | <p style="text-align: center;">Result = $\frac{x_1 * 100\%}{x_2}$</p> <p>If: $\frac{x_1 * 100\%}{x_2} > 200\% \rightarrow \text{Result} = 200\%$</p> <p>$\frac{x_1 * 100\%}{x_2} < -200\% \rightarrow \text{Result} = -200\%$</p> | | | | | | | |
| Index: | See P2869 | | | | | | | |
| Dependency: | P2802[10] assigns the Divider to the processing sequence. | | | | | | | |
| r2882 | CO: DIV 1 | - | - | - | - | - | Float | 3 |
| | Result of Divider 1. | | | | | | | |
| Dependency: | See P2881 | | | | | | | |
| P2883[0...1] | Cl: DIV 2 | - | 0 | U, T | 4000H | - | U32 / I16 | 3 |
| | Define inputs of Divider 2, result is in r2884. | | | | | | | |
| Index: | See P2869 | | | | | | | |
| Dependency: | P2802[11] assigns the Divider to the processing sequence. | | | | | | | |
| r2884 | CO: DIV 2 | - | - | - | - | - | Float | 3 |
| | Result of Divider 2. | | | | | | | |
| Dependency: | See P2883 | | | | | | | |
| P2885[0...1] | Cl: CMP 1 | - | 0 | U, T | 4000H | - | U32 / I16 | 3 |
| | Defines inputs of Comparator 1, output is r2886. | | | | | | | |
| | <p style="text-align: center;">Out = $x_1 \geq x_2 \rightarrow \text{Out} = 1$</p> <p>$x_1 < x_2 \rightarrow \text{Out} = 0$</p> | | | | | | | |
| Index: | See P2869 | | | | | | | |
| Dependency: | P2802[12] assigns the Comparator to the processing sequence. | | | | | | | |
| r2886.0 | BO: CMP 1 | - | - | - | - | - | Float | 3 |
| | Displays result bit of Comparator 1. See r2811 for the bit field description. | | | | | | | |
| Dependency: | See P2885 | | | | | | | |
| P2887[0...1] | Cl: CMP 2 | - | 0 | U, T | 4000H | - | U32 / I16 | 3 |
| | Defines inputs of Comparator 2, output is r2888. | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|------------------|-----------------|----------------|---------|----------|-----------|------------|
| Index: | See P2869 | | | | | | | |
| Dependency: | P2802[13] assigns the Comparator to the processing sequence. | | | | | | | |
| r2888.0 | BO: CMP 2 | - | - | - | - | - | U16 | 3 |
| | Displays result bit of Comparator 2. See r2811 for the bit field description. | | | | | | | |
| Dependency: | See P2887 | | | | | | | |
| P2889 | CO: Fixed setpoint 1 in [%] | -200.00 - 200.00 | 0.00 | U, T | - | - | Float | 3 |
| | Fixed percent setting 1. Connector Setting in %  Range: -200% ... 200% | | | | | | | |
| P2890 | CO: Fixed setpoint 2 in [%] | -200.00 - 200.00 | 0.00 | U, T | - | - | Float | 3 |
| | Fixed percent setting 2. | | | | | | | |
| P2940 | BI: Release wobble function | - | 0.0 | T | - | - | U32 | 2 |
| | Defines the source to release the wobble function. | | | | | | | |
| P2945 | Wobble signal frequency [Hz] | 0.001 - 10.000 | 1.000 | T | - | - | DECU 16 | 2 |
| | Sets the frequency of the wobble signal. | | | | | | | |
| P2946 | Wobble signal amplitude [%] | 0.000 - 0.200 | 0.000 | T | - | - | DECU 16 | 2 |
| | Sets the value for the amplitude of the wobble-signal as a proportion of the present ramp function generator (RFG) output. The value of P2946 is multiplied by the output value of the RFG then added to RFG output. For example, if the RFG output is 10 Hz, and P2946 has a value of 0.100, the wobble signal amplitude will be $0.100 * 10 = 1$ Hz. This means that the RFG output will therefore wobble between 9 Hz and 11 Hz. | | | | | | | |
| P2947 | Wobble signal decrement step | 0.000 - 1.000 | 0.000 | T | - | - | DECU 16 | 2 |
| | Sets the value for decrement step at the end of the positive signal period. The amplitude of the step is dependant upon the signal amplitude as follows: Amplitude of signal decrement step = $P2947 * P2946$ | | | | | | | |
| P2948 | Wobble signal increment step | 0.000 - 1.000 | 0.000 | T | - | - | DECU 16 | 2 |
| | Sets the value for the increment step at the end of the negative signal period. The amplitude of the increment step is dependant upon the signal amplitude as follows: Amplitude of signal increment step = $P2948 * P2946$ | | | | | | | |
| P2949 | Wobble signal pulse width [%] | 0 - 100 | 50 | T | - | - | U16 | 2 |
| | Sets the relative widths of the rising and falling pulses. The value in P2949 sets the proportion of the wobble period (determined by P2945) allocated to the rising pulse, the remainder of the time is allocation to the falling pulse. A value of 60% in P2949 means that 60% of the wobble period the wobble output will be rising. For the remaining 40% of the wobble period the wobble output will be falling. | | | | | | | |
| r2955 | CO: Wobble signal output [%] | - | - | - | - | - | DEC1 32 | 2 |
| | Displays the output of the wobble function. | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|---------------------------------------|--|------------------------------------|-----------------|----------------|---------|-----------------|-----------------|------------|
| r3113.0...15 | CO / BO: Fault bit array | - | - | - | - | - | U16 | 1 |
| Gives information about actual fault. | | | | | | | | |
| | Bit | Signal name | | | | 1 signal | 0 signal | |
| | 00 | Inverter error | | | | Yes | No | |
| | 01 | Power line failure | | | | Yes | No | |
| | 02 | Intermediate circuit power voltage | | | | Yes | No | |
| | 03 | Error power electronics | | | | Yes | No | |
| | 04 | Inverter overtemperature | | | | Yes | No | |
| | 05 | Earth leakage | | | | Yes | No | |
| | 06 | Motor overload | | | | Yes | No | |
| | 07 | Bus fault | | | | Yes | No | |
| | 09 | Reserved | | | | Yes | No | |
| | 10 | Fault internal communication | | | | Yes | No | |
| | 11 | Motor current limit | | | | Yes | No | |
| | 12 | Supply failure | | | | Yes | No | |
| | 13 | Reserved | | | | Yes | No | |
| | 14 | Reserved | | | | Yes | No | |
| | 15 | Other error | | | | Yes | No | |
| P3350[0...2] | Super torque modes | 0 - 3 | 0 | T | - | - | U16 | 2 |
| | Selects the super torque function. Three different super torque modes are available: | | | | | | | |
| | <ul style="list-style-type: none"> • Super Torque - applies a pulse of torque for a given time to help start the motor • Hammer Start - applies a sequence of torque pulses to help start the motor • Blockage Clearing - performs a reverse-forward operation to clear a pump blockage | | | | | | | |
| | Super Torque Operation: | | | | | | | |
| | <p>The graph illustrates the Super Torque Operation. The top plot shows the Boost (%) signal, which jumps to a constant level defined by parameter P3355 at the start of the operation. The bottom plot shows the Output frequency (Hz) signal, which starts at P3354 and ramps up during the 'Super torque ramp time' (P3353). After this initial ramp, the frequency continues to ramp up during the 'Ramp-up time' (P1120).</p> | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|-------------------------------------|--|-------|-----------------|----------------|---------|----------|-----------|------------|
| Hammer Start Operation: | | | | | | | | |
| | <p>The graph illustrates the Hammer Start Operation. The top part shows the Boost (%) signal, which consists of a constant level P3357 followed by a series of pulses P3359 and P3360. The bottom part shows the Output frequency (Hz) signal, which starts at P3354 and ramps up linearly over the Super torque ramp time (P3353). The total ramp-up time is indicated by P1120. The number of hammer cycles is defined by P3358.</p> | | | | | | | |
| Blockage Clearing Operation: | | | | | | | | |
| | <p>The graph illustrates the Blockage Clearing Operation. It shows the Output frequency (Hz) signal and the Setpoint signal. The Setpoint signal consists of a positive setpoint (solid line) and a negative setpoint (dashed line). The positive setpoint starts at P3361 and ramps up over the Ramp-up time (P1120). The negative setpoint starts at P3361 and ramps down over the Blockage clearing reverse time (P3362). The number of blockage clearing cycles is specified as e.g. P3364 = 2. A note indicates that the Super torque ramp time is active only when rapid ramp (P3363) is disabled.</p> | | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level | | | | | | | |
|--------------------|--|-------------------------------------|-----------------|----------------|---------|----------|-----------|------------|--|--|--|--|--|--|--|
| | 0 | Super torque modes disabled | | | | | | | | | | | | | |
| | 1 | Super torque enabled | | | | | | | | | | | | | |
| | 2 | Hammer start enabled | | | | | | | | | | | | | |
| | 3 | Blockage clearing enabled | | | | | | | | | | | | | |
| Index: | [0] | Inverter data set 0 (DDS0) | | | | | | | | | | | | | |
| | [1] | Inverter data set 1 (DDS1) | | | | | | | | | | | | | |
| | [2] | Inverter data set 2 (DDS2) | | | | | | | | | | | | | |
| Note: | When the value of P3350 is changed, the value of P3353 is changed as follows: | | | | | | | | | | | | | | |
| | <ul style="list-style-type: none"> • P3350 = 2: P3353 = 0.0s • P3350 ≠ 2: P3353 = default The ramp time of 0s gives an additional 'kicking' effect when hammer start is in use. This setting can be overridden by the operator. If blockage clearing mode is enabled (P3350 = 3), make sure that reverse direction is not inhibited, i.e. P1032 = P1110 = 0. | | | | | | | | | | | | | | |
| P3351[0...2] | BI: Super torque enable | - | 0 | T | - | CDS | U32 / Bin | 2 | | | | | | | |
| | Defines source of the super torque enable when P3352 = 2. | | | | | | | | | | | | | | |
| Dependency: | Applies only when P3352 = 2. | | | | | | | | | | | | | | |
| P3352[0...2] | Super torque startup mode | 0 - 2 | 1 | T | - | - | U16 | 2 | | | | | | | |
| | Defines when the super torque function becomes active. | | | | | | | | | | | | | | |
| | 0 | Enabled on first run after power-up | | | | | | | | | | | | | |
| | 1 | Enabled on every run | | | | | | | | | | | | | |
| | 2 | Enabled by digital input | | | | | | | | | | | | | |
| Index: | See P3350 | | | | | | | | | | | | | | |
| Dependency: | If P3352 = 2, enable source is defined by P3351 | | | | | | | | | | | | | | |
| P3353[0...2] | Super torque ramp time [s] | 0.0 - 650.0 | 5.0 | T | - | - | Float | 2 | | | | | | | |
| | Defines the ramp time to be used for all super torque functions. Overrides the P1120 / P1060 when inverter is ramping to super torque / hammer start frequency (P3354) or the blockage clearing frequency (P3361). | | | | | | | | | | | | | | |
| Index: | See P3350 | | | | | | | | | | | | | | |
| Dependency: | The value of this parameter is changed by the setting of P3350. See the description of P3350. | | | | | | | | | | | | | | |
| P3354[0...2] | Super torque frequency [Hz] | 0.0 - 599.0 | 5.0 | T | - | - | Float | 2 | | | | | | | |
| | Defines the frequency at which the additional boost is applied for super torque and hammer start modes. | | | | | | | | | | | | | | |
| Index: | See P3350 | | | | | | | | | | | | | | |
| P3355[0...2] | Super torque boost level [%] | 0.0 - 200.0 | 150.0 | T | PERCENT | - | Float | 2 | | | | | | | |
| | The magnitude of the Super Torque boost is calculated as follows: $V_{ST} = P0305 * Rsadj * (P3355 / 100)$ Note: Rsadj = stator resistance adjusted for temperature $Rsadj = (r0395 / 100) * (P0304 / (\sqrt{3} * P0305)) * P0305 * \sqrt{3}$ | | | | | | | | | | | | | | |
| Index: | See P3350 | | | | | | | | | | | | | | |
| Dependency: | Up to 200% of rated motor current (P0305) or limit of inverter. | | | | | | | | | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|--|-----------------|----------------|---------|----------|-----------|------------|
| Note: | The Super Torque boost is calculated in the same way as Continuous Boost (P1310). As the stator resistance is used, the calculated voltage is only accurate at 0 Hz. Thereafter, it will vary in the same way as Continuous Boost. Setting in P0640 (motor overload factor [%]) limits the boost. | | | | | | | |
| P3356[0..2] | Super torque boost time [s] | 0.0 - 20.0 | 5.0 | T | - | - | Float | 2 |
| | Sets the time for which the additional boost will be applied, when the output frequency is held at P3354 Hz. | | | | | | | |
| Index: | See P3350 | | | | | | | |
| P3357[0..2] | Hammer start boost level [%] | 0.0 - 200.0 | 150.0 | T | PERCENT | - | Float | 2 |
| | The magnitude of the Hammer Start boost is calculated as follows: $V_{HS} = P0305 * Rsadj * (P3357 / 100)$ Note: Rsadj = stator resistance adjusted for temperature $Rsadj = (r0395 / 100) * (P0304 / (\sqrt{3} * P0305)) * P0305 * \sqrt{3}$ | | | | | | | |
| Index: | See P3350 | | | | | | | |
| Dependency: | Up to 200% of rated motor current (P0305) or limit of inverter. | | | | | | | |
| Note: | The Hammer Start boost is calculated in the same way as Continuous Boost (P1310). As the stator resistance is used, the calculated voltage is only accurate at 0Hz. Thereafter, it will vary in the same way as Continuous Boost. Setting in P0640 (motor overload factor [%]) limits the boost. | | | | | | | |
| P3358[0..2] | Number of hammer cycles | 1 - 10 | 5 | C, T | - | - | U16 | 2 |
| | The number of times the hammer start boost level (P3357) is applied. | | | | | | | |
| Index: | See P3350 | | | | | | | |
| P3359[0..2] | Hammer on time [ms] | 0 - 1000 | 300 | T | - | - | U16 | 2 |
| | Time for which the additional boost is applied for each repetition. | | | | | | | |
| Index: | See P3350 | | | | | | | |
| Dependency: | The time must be at least 3 x motor magnetization time (P0346). | | | | | | | |
| P3360[0..2] | Hammer off Time [ms] | 0 - 1000 | 100 | T | - | - | U16 | 2 |
| | Time for which the additional boost is removed for each repetition. | | | | | | | |
| Index: | See P3350 | | | | | | | |
| Note: | During this time, the boost level drops to the level defined by P1310 (continuous boost). | | | | | | | |
| P3361[0..2] | Blockage clearing frequency [Hz] | 0.0 - 599.0 | 5.0 | T | - | - | Float | 2 |
| | Defines the frequency at which the inverter runs in the opposite direction to the setpoint during the blockage clearing reverse sequence. | | | | | | | |
| Index: | See P3350 | | | | | | | |
| P3362[0..2] | Blockage clearing reverse time [s] | 0.0 - 20.0 | 5.0 | T | - | - | Float | 2 |
| | Sets the time for which the inverter runs in the opposite direction to the setpoint during the reverse sequence. | | | | | | | |
| Index: | See P3350 | | | | | | | |
| P3363[0..2] | Enable rapid ramp | 0 - 1 | 0 | T | - | - | U16 | 2 |
| | Selects whether the inverter ramps to, or starts directly from, the blockage clearing frequency (P3361). | | | | | | | |
| | 0 | Disable rapid ramp for blockage clearing | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|---|--|-----------------|----------------|-----------------|----------|-----------------|------------|
| | 1 | Enable rapid ramp for blockage clearing | | | | | | |
| Index: | See P3350 | | | | | | | |
| Note: | If P3363 = 1, the output jumps to the reverse frequency - this introduces a "kicking" effect which helps to clear the blockage. | | | | | | | |
| P3364[0...2] | Number of blockage clearing cycles | 1 - 10 | 1 | T | - | - | U16 | 2 |
| | The number of times the blockage clearing reversing cycle is repeated. | | | | | | | |
| Index: | See P3350 | | | | | | | |
| r3365 | Status word: super torque | - | - | - | - | - | U16 | 2 |
| | Shows the operational status of the Super Torque function, while active. | | | | | | | |
| | Bit | Signal name | | | 1 signal | | 0 signal | |
| | 00 | Super Torque Active | | | Yes | | No | |
| | 01 | Super Torque Ramping | | | Yes | | No | |
| | 02 | Super Torque Boost On | | | Yes | | No | |
| | 03 | Super Torque Boost Off | | | Yes | | No | |
| | 04 | Blockage Clearing Reverse On | | | Yes | | No | |
| | 05 | Blockage Clearing Reverse Off | | | Yes | | No | |
| P3852[0...2] | BI: Enable frost protection | - | 0 | T | - | CDS | U32 / Bin | 2 |
| | Defines command source of protection enable command. If binary input is equal to one, then protection will be initiated. If inverter is stopped and protection signal becomes active, protection measure is applied as follows: | | | | | | | |
| | <ul style="list-style-type: none"> • If P3853 ≠ 0, frost protection is applied by applying the given frequency to the motor • If P3853 = 0, and P3854 ≠ 0, condensation protection is applied by applying the given current to the motor | | | | | | | |
| Note: | The protection function may be overridden under the following circumstances: | | | | | | | |
| | <ul style="list-style-type: none"> • If inverter is running and protection signal becomes active, signal is ignored • If inverter is turning motor due to active protection signal and a RUN command is received, RUN command overrides frost signal • Issuing an OFF command while protection is active will stop the motor | | | | | | | |
| P3853[0...2] | Frost protection frequency [Hz] | 0.00 - 599.00 | 5.00 | U, T | - | DDS | Float | 2 |
| | The frequency applied to the motor when frost protection is active. | | | | | | | |
| Dependency: | See also P3852. | | | | | | | |
| P3854[0...2] | Condensation protection current [%] | 0 - 250 | 100 | U, T | - | DDS | U16 | 2 |
| | The DC current (as a percentage of nominal current) which is applied to the motor when condensation protection is active. | | | | | | | |
| Dependency: | See also P3852. | | | | | | | |
| P3900 | End of quick commissioning | 0 - 3 | 0 | C(1) | - | - | U16 | 1 |
| | Performs calculations necessary for optimized motor operation. After completion of calculation, P3900 and P0010 (parameter groups for commissioning) are automatically reset to their original value 0. | | | | | | | |
| | 0 | No quick commissioning | | | | | | |
| | 1 | End quick commissioning with factory reset | | | | | | |
| | 2 | End quick commissioning | | | | | | |

Parameter list

7.2 Parameter list

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|--|-------------------------------|-----------------|---|---------|----------|-----------|------------|
| | 3 | | | End quick commissioning only for motor data | | | | |
| Dependency: | Changeable only when P0010 = 1 (quick commissioning). | | | | | | | |
| Note: | P3900 = 1: When setting 1 is selected, only the parameter settings carried out via the commissioning menu "Quick commissioning" are retained; all other parameter changes, including the I/O settings, are lost. Motor calculations are also performed. P3900 = 2: When setting 2 is selected, only those parameters, which depend on the parameters in the commissioning menu "Quick commissioning" (P0010 = 1) are calculated. The I/O settings are also reset to default and the motor calculations performed. P3900 = 3: When setting 3 is selected, only the motor and controller calculations are performed. Exiting quick commissioning with this setting saves time (for example, if only motor rating plate data have been changed). Calculates a variety of motor parameters, overwriting previous values. These include P0344 (motor weight), P0350 (stator resistance), P2000 (reference frequency), P2002 (reference current). When transferring P3900, the inverter uses its processor to carry out internal calculations. Communications - both via USS as well as via the Fieldbus - are interrupted for the time that it takes to make these calculations. This can result in the following error messages at the connected SIMATIC S7 control (communications via Fieldbus): | | | | | | | |
| | <ul style="list-style-type: none"> • Parameter fault 30 • Inverter fault 70 • Inverter fault 75 | | | | | | | |
| r3930[0...4] | Inverter data version | - | - | - | - | - | U16 | 3 |
| | Displays the A5E number and the inverter data versions. | | | | | | | |
| Index: | [0] | A5E 1st 4 digits | | | | | | |
| | [1] | A5E 2nd 4 digits | | | | | | |
| | [2] | Logistic Version | | | | | | |
| | [3] | Fixed Data Version | | | | | | |
| | [4] | Calib Data Version | | | | | | |
| P3950 | Access of hidden parameters | 0 - 255 | 0 | U, T | - | - | U16 | 4 |
| | Accesses special parameters for development (expert only) and factory functionality (calibration parameter). | | | | | | | |
| r3954[0...12] | CM info and GUI ID | - | - | - | - | - | U16 | 4 |
| | Used to classify firmware (only for SIEMENS internal purposes). | | | | | | | |
| Index: | [0] | CM label (increment / branch) | | | | | | |
| | [1] | CM label (counter) | | | | | | |
| | [2] | CM label | | | | | | |
| | [3...10] | GUI ID | | | | | | |
| | [11] | GUI ID major release | | | | | | |
| | [12] | GUI ID minor release | | | | | | |
| r3978 | BICO counter | - | - | - | - | - | U16 | 4 |
| | Counts the number of changed BICO links. | | | | | | | |
| P3981 | Reset active fault | 0 - 1 | 0 | T | - | - | U16 | 4 |
| | Resets active faults when changed from 0 to 1. | | | | | | | |
| | 0 | No fault reset | | | | | | |

| Parameter | Function | Range | Factory default | Can be changed | Scaling | Data set | Data type | Acc. Level |
|--------------------|---|---|-----------------|----------------|---------|----------|-----------|------------|
| | 1 | Reset fault | | | | | | |
| Note: | See P0947 (last fault code) Automatically reset to 0. | | | | | | | |
| P3984 | Client telegram off time [ms] | 100 - 10000 | 1000 | T | - | - | U16 | 3 |
| | Defines time after which a fault will be generated (F73) if no telegram is received from the client. | | | | | | | |
| Dependency: | Setting 0 = watchdog disabled | | | | | | | |
| r3986[0...1] | Number of parameters | - | - | - | - | - | U16 | 4 |
| | Number of parameters on the inverter. | | | | | | | |
| Index: | [0] | Read only | | | | | | |
| | [1] | Read & write | | | | | | |
| P7844 | Acceptance Test, Confirmation | 0 - 2 | 0 | T | - | - | U16 | 3 |
| | After an automatic download from MMC at startup, this parameter will be automatically set to 1. Also a fault F395 will be set. With setting to P7844 = 0 you quit F395 and confirm the parameter settings. Setting this parameter to 2 is only possible if an automatic download has been performed at startup. In this case the download will be undone and the previously stored parameters will be enabled. | | | | | | | |
| | 0 | Acceptance Test / Confirmation ok. | | | | | | |
| | 1 | Acceptance Test / Confirmation is pending | | | | | | |
| | 2 | Undo Clone | | | | | | |
| Note: | If no automatic download from MMC has been performed during startup the setting 2 is not possible. | | | | | | | |
| P8458 | Clone control | 0 - 2 | 2 | T | - | - | U16 | 3 |
| | This parameter specifies whether a cloning at startup will be performed. The File clone00.bin will be used. If no MMC is inserted there will be a normal startup. | | | | | | | |
| | 0 | No Startup Clone | | | | | | |
| | 1 | Once Startup Clone | | | | | | |
| | 2 | Always Startup Clone | | | | | | |
| Note: | Default value is 2. After first cloning the parameter is set to 0. If a MMC is inserted without a valid file the inverter will set a fault F61 / F63 / F64 which can only be cleared by a power-cycle. The fault is signaled by a flashing RUN LED (Commissioning). The SF LED is not activated. P8458 will not be changed by performing a factory reset. | | | | | | | |
| P8553 | Menu type | 0 - 1 | 0 | U, T | - | - | U16 | 1 |
| | Selects whether to have menus with no text or menus with some text on the BOP. | | | | | | | |
| | 0 | Menus with no text | | | | | | |
| | 1 | Menus with some text | | | | | | |

Fault and warning codes

NOTICE

If there are multiple active faults and alarms, the BOP first displays all faults one after another. Once all faults are displayed, it displays all alarms in succession.

Faults

Immediately when a fault occurs the fault icon  is lit and the display transitions to the faults screen. The faults screen displays the fault number proceeded by "F".

Acknowledging / clearing faults

- To navigate through the current list of faults, press  or .
- To clear / acknowledge the fault, press  or acknowledge externally if the inverter has been set up so.
- To ignore the fault, press .

After you acknowledge or ignore the fault, the screen returns to the previous display. The fault icon remains lit until the fault is cleared / acknowledge.

NOTICE

Under the following circumstances, the faults screen displays again:

- If the fault has not been cleared and the  button is pressed, the faults screen displays again.
- If there is no key press for 60 seconds.

If a fault is active and there has been no key press for 60 seconds, the backlight (P0070) flashes.

Fault code list

| Fault | Cause | Remedy |
|---------------------------------------|---|---|
| F1 Overcurrent | <ul style="list-style-type: none"> • Motor power (P0307) does not correspond to the inverter power (r0206). • Motor lead short circuit • Earth faults r0949 = 0: Hardware reported r0949 = 1: Software reported | Check the following: <ul style="list-style-type: none"> • Motor power (P0307) must correspond to inverter power (r0206). • Cable length limits must not be exceeded. • Motor cable and motor must have no short-circuits or earth faults. • Motor parameters must match the motor in use. • Value of stator resistance (P0350) must be correct. • Motor must not be obstructed or overloaded. • Increase ramp-up time (P1120) • Reduce starting boost level (P1312) |
| F2 Overvoltage | <ul style="list-style-type: none"> • Main supply voltage too high • Motor is in regenerative mode r0949 = 0: Hardware reported r0949 = 1 or 2: Software reported | Check the following: <ul style="list-style-type: none"> • Supply voltage (P0210) must lie within limits indicated on rating plate. • Ramp-down time (P1121) must match inertia of load. • Required braking power must lie within specified limits. • Vdc controller must be enabled (P1240) and parameterized properly. Note: Regenerative mode can be caused by fast ramp downs or if the motor is driven by an active load. Higher inertia requires longer ramp times; otherwise, apply braking resistor. |
| F3 Undervoltage | <ul style="list-style-type: none"> • Main supply failed. • Shock load outside specified limits. r0949 = 0: Hardware reported r0949 = 1 or 2: Software reported | Check supply voltage. |
| F4 Inverter overtemperature | <ul style="list-style-type: none"> • Inverter overloaded • Ventilation inadequate • Pulse frequency too high • Ambient temperature too high • Fan inoperative | Check the following: <ul style="list-style-type: none"> • Load or load cycle too high? • Motor power (P0307) must match inverter power (r0206) • Pulse frequency must be set to default value • Ambient temperature too high? • Fan must turn when inverter is running |
| F5 Inverter I^2t | <ul style="list-style-type: none"> • Inverter overloaded. • Load cycle too demanding. • Motor power (P0307) exceeds inverter power capability (r0206). | Check the following: <ul style="list-style-type: none"> • Load cycle must lie within specified limits. • Motor power (P0307) must match inverter power (r0206) |

| Fault | Cause | Remedy |
|--|---|--|
| F6 Chip temperature rise exceeds critical levels | <ul style="list-style-type: none"> Load at start-up is too high Load step is too high Ramp-up rate is too fast | Check the following: <ul style="list-style-type: none"> Load or load step too high? Increase ramp-up time (P1120). Motor power (P0307) must match inverter power (r0206). Use setting P0290 = 0 or 2 for preventing F6. |
| F11 Motor overtemperature | Motor overloaded | Check the following: <ul style="list-style-type: none"> Load or load step too high? Motor nominal overtemperatures (P0626 - P0628) must be correct Motor temperature warning level (P0604) must match |
| F12 Inverter temperature signal lost | Wire breakage of inverter temperature (heat sink) sensor. | |
| F20 DC ripple too high | The calculated DC ripple level has exceeded the safe threshold. This is commonly caused by loss of one of the mains input phases. | Check the mains supply wiring. |
| F35 Auto restart after n | Auto restart attempts exceed value of P1211. | |
| F41 Motor data identification failure | <p>Motor data identification failed.</p> <ul style="list-style-type: none"> r0949 = 0: Load missing r0949 = 1: Current limit level reached during identification. r0949 = 2: Identified stator resistance less than 0.1% or greater than 100%. r0949 = 30: Current controller at voltage limit r0949 = 40: Inconsistency of identified dataset, at least one identification failed <p>Percentage values based on the impedance $Z_b = V_{mot,nom} / \sqrt{3} / I_{mot,nom}$</p> | Check the following: <ul style="list-style-type: none"> r0949 = 0: is the motor connected to the inverter? r0949 = 1 - 49: are the motor data in P0304 - P0311 correct? Check what type of motor wiring is required (star, delta). |
| F51 Parameter EEPROM fault | Read or write failure while access to EEPROM. This can also be caused by the EEPROM being full, too many parameters have been changed. | <ul style="list-style-type: none"> Must be power cycled to cancel this bug as some parameters may not be read correct. Factory reset and new parameterization, if power cycle does not remove fault. Change some parameters back to default values if the EEPROM is full, then power cycle. Change inverter. |

| Fault | Cause | Remedy |
|---------------------------------------|--|---|
| | | <p>Note:</p> <ul style="list-style-type: none"> • r0949 = 1: EEPROM full • r0949 = 1000 + block No: reading data block failed • r0949 = 2000 + block No: reading data block timeout • r0949 = 3000 + block No: reading data block CRC failed • r0949 = 4000 + block No: writing data block failed • r0949 = 5000 + block No: writing data block timeout • r0949 = 6000 + block No: writing data block verify failed • r0949 = 7000 + block No: reading data block at wrong time • r0949 = 8000 + block No: writing data block at wrong time • r0949 = 9000 + block No: factory reset did not work because restart or power failure |
| F52 Inverter software fault | Read failure for inverter information or invalid data. | <p>Note:</p> <ul style="list-style-type: none"> • r0949 = 1: Failed reading inverter identity • r0949 = 2: Inverter identity wrong • r0949 = 3: Failed reading inverter version • r0949 = 4: Inverter version wrong • r0949 = 5: Start of Part 1 inverter data wrong • r0949 = 6: Inverter number of temperature sensor wrong • r0949 = 7: Inverter number of application wrong • r0949 = 8: Start of Part 3 inverter data wrong • r0949 = 9: Reading inverter data string wrong • r0949 = 10: Inverter CRC failed • r0949 = 11: Inverter is blank • r0949 = 15: Failed CRC of inverter block 0 • r0949 = 16: Failed CRC of inverter block 1 • r0949 = 17: Failed CRC of inverter block 2 • r0949 = 20: Inverter invalid • r0949 = 30: Directory size wrong • r0949 = 31: Directory ID wrong • r0949 = 32: Invalid block • r0949 = 33: File size wrong • r0949 = 34: Data section size wrong |

| Fault | Cause | Remedy |
|---|--|--|
| F52 (continued) | | <ul style="list-style-type: none"> • r0949 = 35: Block section size wrong • r0949 = 36: RAM size exceeded • r0949 = 37: Parameter size wrong • r0949 = 38: Device header wrong • r0949 = 39: Invalid file pointer • r0949 = 40: Scaling block version wrong • r0949 = 41: Calibration block version wrong • r0949 = 50: Wrong serial number format • r0949 = 51: Wrong serial number format start • r0949 = 52: Wrong serial number format end • r0949 = 53: Wrong serial number format month • r0949 = 54: Wrong serial number format day • r0949 = 1000 + addr: Inverter read data failed • r0949 = 2000 + addr: Inverter write data failed • r0949 = 3000 + addr: Inverter read data wrong time • r0949 = 4000 + addr: Inverter write data wrong time • r0949 = 5000 + addr: Inverter read data invalid • r0949 = 6000 + addr: Inverter write data invalid • Power-cycle inverter • Contact service department or change inverter |
| F60 Asic timeout | Internal communications failure. | <p>Check inverter. Fault appears sporadically:</p> <p>Note:</p> <ul style="list-style-type: none"> • r0949 = 0: Hardware reported link fail • r0949 = 1: Software reported link fail • r0949 = 6: Feedback is not disabled for reading inverter data • r0949 = 7: During inverter download, message didn't transmit to disable feedback • Communication failure due to EMC problems • Check - and if necessary - improve EMC • Use EMC filter |
| F61 MMC / SD card parameter cloning failed | <p>Parameter cloning failed.</p> <ul style="list-style-type: none"> • r0949 = 0: MMC / SD card not connected or incorrect card type or the card failed to initialize for automatic cloning • r0949 = 1: Inverter data cannot write to the card. • r0949 = 2: Parameter cloning file not available | <ul style="list-style-type: none"> • r0949 = 0: Use an MMC / SD card with FAT16 or FAT32 format , or fit an MMC / SD card to the inverter. • r0949 = 1: Check the MMC / SD card (e.g., is the card memory full?) - format the card again to FAT16 or FAT32. • r0949 = 2: Put the correct named file in the correct directory /USER/SINAMICS/DATA. • r0949 = 3: Make sure file is accessible - |

| Fault | Cause | Remedy |
|--|--|--|
| | <ul style="list-style-type: none"> r0949 = 3: The MMC / SD card cannot read the file r0949 = 4: Reading data from the clone file failed (e.g., reading failed, data or checksum wrong) | recreate file if possible. <ul style="list-style-type: none"> r0949 = 4: File has been changed - recreate file. |
| F62 Parameter cloning contents invalid | File exists but the contents are not valid control word corruption. | Recopy and ensure operation completes. |
| F63 Parameter cloning contents incompatible | File exists but was not the correct inverter type. | Ensure clone from compatible inverter type. |
| F64 Inverter attempted to do an automatic clone during startup | No Clone00.bin file in the correct directory /USER/SINAMICS/DATA. | If an automatic clone is required: <ul style="list-style-type: none"> Insert the MMC / SD card with correct file and power cycle. If no automatic clone is required: <ul style="list-style-type: none"> Remove the card if not needed and power cycle. Reset P8458 = 0 and power cycle. Note: Fault can only be cleared by a power cycle. |
| F71 USS setpoint fault | No setpoint values from USS during telegram off time | Check USS master |
| F72 USS / MODBUS setpoint fault | No setpoint values from USS / MODBUS during telegram off time | Check USS / MODBUS master |
| F80 AI lost input signal | <ul style="list-style-type: none"> Broken wire Signal out of limits | |
| F85 External fault | External fault triggered via command input via control word 2, bit 13. | <ul style="list-style-type: none"> Check P2106. Disable control word 2 bit 13 as command source. Disable terminal input for fault trigger. |
| F100 Watchdog reset | Software Error | Contact service department or change inverter. |
| F101 Stack overflow | Software error or processor failure. | Contact service department or change inverter. |
| F221 PID feedback below minimum value | PID feedback below minimum value P2268. | <ul style="list-style-type: none"> Change value of P2268. Adjust feedback gain. |
| F222 PID feedback above maximum value | PID feedback above maximum value P2267. | <ul style="list-style-type: none"> Change value of P2267. Adjust feedback gain. |
| F350 Configuration vector for the inverter failed | During startup the inverter checks if the configuration vector (SIZL vector) has been programmed correctly and if hardware matches the programmed vector. If not the inverter will trip. | Internal failures cannot be fixed. r0949 = 13 - Make sure the right power module is fitted. Note: Fault needs power cycle to be acknowledged. |

| Fault | Cause | Remedy |
|---|---|--|
| | <ul style="list-style-type: none"> r0949 = 1: Internal failure - no hardware configuration vector available. r0949 = 2: Internal failure - no software configuration vector available. r0949 = 11: Internal failure - inverter code not supported. r0949 = 12: Internal failure - software vector not possible. r0949 = 13: Wrong power module fitted. r0949 > 1000: Internal failure - wrong I/O board fitted. | |
| F395 Acceptance test / confirmation pending | <p>This fault occurs after a startup clone. It can also be caused by a faulty read from the EEPROM, see F51 for more details.</p> <p>A startup clone could have changed and might not match the application.</p> <p>This parameter set needs to be checked before the inverter can start a motor.</p> <ul style="list-style-type: none"> r0949 = 3/4: Inverter data change r0949 = 5: Startup clone via an MMC / SD card has been performed r0949 = 10: Previous startup clone was aborted | The current parameter set needs to be checked and confirmed by clearing the fault. |
| F410 Cavitation protection failure | Conditions exist for cavitation damage. Cavitation damage is damage caused to a pump in pumping systems when the fluid is not flowing sufficiently. This can lead to heat build up and subsequent damage to the pump. | If cavitation is not occurring, reduce the cavitation threshold P2361, or increase the cavitation protection delay. Ensure sensor feedback is working. |
| F452 Belt failure | <p>Load conditions on motor indicate belt failure or mechanical fault.</p> <ul style="list-style-type: none"> r0949 = 0: trip low torque / speed r0949 = 1: trip high torque / speed | <p>Check the following:</p> <ul style="list-style-type: none"> No breakage, seizure or obstruction of inverter train. Apply lubrication if required. <p>If using an external speed sensor, check the following parameters for correct function:</p> <ul style="list-style-type: none"> - P2192 (delay time for permitted deviation) - P2182 (threshold frequency f1) - P2183 (threshold frequency f2) - P2184 (threshold frequency f3) |

| Fault | Cause | Remedy |
|-------|-------|--|
| | | <p>If using a specific torque / speed range, check parameters:</p> <ul style="list-style-type: none"> - P2182 (threshold frequency 1) - P2183 (threshold frequency 2) - P2184 (threshold frequency 3) - P2185 (upper torque threshold 1) - P2186 (lower torque threshold 1) - P2187 (upper torque threshold 2) - P2188 (lower torque threshold 2) - P2189 (upper torque threshold 3) - P2190 (lower torque threshold 3) - P2192 (delay time for permitted deviation) |

Alarms

If an alarm is activated the alarm icon  is immediately lit and then the display shows the alarm code proceeded by "A".

NOTICE

Note that alarms cannot be acknowledged. They are cleared automatically once the warning has been rectified.

Alarm code list

| Alarm | Cause | Remedy |
|----------------------------------|--|--|
| A501 Current limit | <ul style="list-style-type: none"> • Motor power does not correspond to the inverter power • Motor leads are too long • Earth faults | <p>Check the following: See F1.</p> |
| A502 Overvoltage limit | Overvoltage limit is reached. This warning can occur during ramp down, if the Vdc controller is disabled (P1240 = 0). | If this warning is displayed permanently, check inverter input voltage. |
| A503 Undervoltage limit | <ul style="list-style-type: none"> • Main supply failed. • Main supply and consequently DC-link voltage (r0026) below specified limit. | Check main supply voltage. |
| A504 Inverter overtemperature | Warning level of inverter heat sink temperature, warning level of chip junction temperature, or allowed change in temperature on chip junction is exceeded, resulting in pulse frequency reduction and / or output frequency reduction (depending on parameterization in P0290). | <p>Note:</p> <p>r0037 = 0: Heat sink temperature r0037 = 1: Chip junction temperature (includes heat sink)</p> <p>Check the following:</p> <ul style="list-style-type: none"> • Ambient temperature must lie within specified limits |

| Alarm | Cause | Remedy |
|---|--|--|
| | | <ul style="list-style-type: none"> • Load conditions and load steps must be appropriate • Fan must turn when inverter is running |
| A505 Inverter I^2t | Warning level exceeded, current will be reduced if parameterized (P0610 = 1). | Check that load cycle lies within specified limits. |
| A506 IGBT junction temperature rise warning | Overload warning. Difference between heat sink and IGBT junction temperature exceeds warning limits. | Check that load steps and shock loads lie within specified limits. |
| A507 Inverter temperature signal lost | Inverter heat sink temperature signal loss. Possible sensor fallen off. | Contact service department or change inverter. |
| A511 Motor overtemperature I^2t | <ul style="list-style-type: none"> • Motor overloaded. • Load cycles or load steps too high. | <p>Independently of the kind of temperature determination check:</p> <ul style="list-style-type: none"> • P0604 motor temperature warning threshold • P0625 motor ambient temperature • Check if name plate data is correct. If not, perform quick commissioning. Accurate equivalent circuit data can be found by performing motor identification (P1900 = 2). • Check if motor weight (P0344) is reasonable. Change if necessary. • With P0626, P0627, and P0628 the standard overtemperature can be changed, If the motor is not a SIEMENS standard motor. |
| A535 Braking resistor overload | <p>The braking energy is too large.</p> <p>The braking resistor is not suited for the application.</p> | <p>Reduce the braking energy.</p> <p>Use a braking resistor with a higher rating.</p> |
| A541 Motor data identification active | Motor data identification (P1900) selected or running. | |
| A600 RTOS overrun warning | Internal time slice overrun | Contact service department. |
| A910 Vdc_max controller deactivated | <p>Occurs</p> <ul style="list-style-type: none"> • if main supply voltage (P0210) is permanently too high. • if motor is driven by an active load, causing motor to go into regenerative mode. • at very high load inertias, when ramping down. | <p>Check the following:</p> <ul style="list-style-type: none"> • Input voltage must lie within range. • Load must be match. • In certain cases apply braking resistor. |


| Alarm | Cause | Remedy |
|---|---|--|
| | If warning A910 occurs while the inverter is in standby (output pulses disabled) and an ON command is subsequently given, the Vdc_max controller (A911) will not be activated unless warning A910 is rectified. | |
| A911 Vdc_max controller active | The Vdc_max controller works to keep the DC-link voltage (r0026) below the level specified in r1242. | <p>Check the following:</p> <ul style="list-style-type: none"> Supply voltage must lie within limits indicated on rating plate. Ramp-down time (P1121) must match inertia of load. <p>Note: Higher inertia requires longer ramp times; otherwise, apply braking resistor.</p> |
| A912 Vdc_min controller active | <p>The Vdc_min controller will be activated if the DC-link voltage (r0026) falls below the level specified in r1246.</p> <p>The kinetic energy of the motor is used to buffer the DC-link voltage, thus causing deceleration of the inverter! So short mains failures do not necessarily lead to an undervoltage trip.</p> <p>Note that this warning may also occur on fast ramp-ups.</p> | |
| A921 AO parameters not set properly | AO parameters (P0777 and P0779) should not be set to identical values, since this would produce illogical results. | <p>Check the following:</p> <ul style="list-style-type: none"> Parameter settings for output identical Parameter settings for input identical Parameter settings for output do not correspond to AO type <p>Set P0777 and P0779 to different values.</p> |
| A922 No load applied to inverter | No Load is applied to the inverter. As a result, some functions may not work as under normal load conditions. | Check that motor is connected to inverter. |
| A923 Both JOG left and JOG right are requested | Both JOG right and JOG left (P1055 / P1056) have been requested. This freezes the RFG output frequency at its current value. | Do not press JOG right and left simultaneously. |
| A930 Cavitation protection warn | Conditions exist for possible cavitation damage. | See F410. |
| A936 PID autotuning active | PID autotuning (P2350) selected or running | Warning disappears when PID autotuning has finished. |
| A952 Belt failure detected | Load conditions on motor indicate belt failure or mechanical fault. | See F452. |

A

Technical specifications

Electrical specifications

Line supply characteristics

| Three phase 400 V inverters | | | | | | | | | | | | | | | |
|----------------------------------|--|-------------|--------------------|-----|-----|-----|-----|-----|----|-----|----|-----|----|-----|----|
| Voltage range | 380 ... 480 V AC (tolerance: -15 % ... +10 %) 47 ... 63 Hz Current derating at high input voltages: Output current [%] | | | | | | | | | | | | | | |
| |  <table border="1"><caption>Data points estimated from the graph</caption><thead><tr><th>Voltage (V)</th><th>Output current [%]</th></tr></thead><tbody><tr><td>323</td><td>100</td></tr><tr><td>400</td><td>100</td></tr><tr><td>420</td><td>98</td></tr><tr><td>460</td><td>92</td></tr><tr><td>500</td><td>85</td></tr><tr><td>528</td><td>75</td></tr></tbody></table> | Voltage (V) | Output current [%] | 323 | 100 | 400 | 100 | 420 | 98 | 460 | 92 | 500 | 85 | 528 | 75 |
| Voltage (V) | Output current [%] | | | | | | | | | | | | | | |
| 323 | 100 | | | | | | | | | | | | | | |
| 400 | 100 | | | | | | | | | | | | | | |
| 420 | 98 | | | | | | | | | | | | | | |
| 460 | 92 | | | | | | | | | | | | | | |
| 500 | 85 | | | | | | | | | | | | | | |
| 528 | 75 | | | | | | | | | | | | | | |
| Overvoltage category | EN 60664-1 Category III | | | | | | | | | | | | | | |
| Permissible supply configuration | TN, TT, IT ¹⁾ , TT earthed line | | | | | | | | | | | | | | |
| Supply environment | Second environment (private power network) | | | | | | | | | | | | | | |

¹⁾ Note that only unfiltered inverters can be operated on IT power system.

Overload capability

| | |
|------------------------|---|
| Average output current | 100 % rated |
| Overload current | 150 % rated for 60 seconds |
| Maximum overload cycle | 150 % rated for 60 seconds followed by 94.5 % rated for 540 seconds (average 100 % rated) |

EMC requirements

| NOTICE |
|---|
| Install all inverters in accordance with the manufacturer's guidelines and in accordance with good EMC practices. |
| Use screened cable type CY. The maximal cable length is 10 m for frame size A or 25 m for frame size B...D. |
| Do not exceed the default switching frequency 4 kHz. |

| Three phase 400 V inverters | |
|-----------------------------|--------------------------------------|
| ESD | EN 61800-3 Category C3 |
| Radiated immunity | |
| Burst | |
| Surge | |
| Conducted immunity | |
| Voltage distortion immunity | |
| | Three phase 400 V filtered inverters |
| Conducted emissions | EN 61800-3 Category C3 |
| Radiated emissions | |

Output current deratings at different PWM frequencies and ambient temperatures

| Three phase 400 V inverters | | | | | | | | | | | | | |
|-----------------------------|-------------------|-------------------------------------|-------|-------|-------------|-------|-------|-------|-------|-------|-------|-------|-------|
| Frame size | Power rating [kW] | Current rating [A] at PWM frequency | | | | | | | | | | | |
| | | 2 kHz | | | 4 kHz | | | 6 kHz | | | 8 kHz | | |
| | | 40 °C | 50 °C | 60 °C | 40 °C | 50 °C | 60 °C | 40 °C | 50 °C | 60 °C | 40 °C | 50 °C | 60 °C |
| A | 0.37 | 1.3 | 1.0 | 0.7 | 1.3 | 1.0 | 0.7 | 1.1 | 0.8 | 0.5 | 0.9 | 0.7 | 0.5 |
| A | 0.55 | 1.7 | 1.3 | 0.9 | 1.7 | 1.3 | 0.9 | 1.4 | 1.0 | 0.7 | 1.2 | 0.9 | 0.6 |
| A | 0.75 | 2.2 | 1.8 | 1.1 | 2.2 | 1.8 | 1.1 | 1.9 | 1.3 | 0.9 | 1.5 | 1.1 | 0.8 |
| A | 1.1 | 3.1 | 2.6 | 1.6 | 3.1 | 2.6 | 1.6 | 2.6 | 1.9 | 1.3 | 2.2 | 1.6 | 1.1 |
| A | 1.5 | 4.1 | 3.4 | 2.1 | 4.1 | 3.4 | 2.1 | 3.5 | 2.5 | 1.7 | 2.9 | 2.1 | 1.4 |
| A | 2.2 | 5.6 | 4.6 | 2.8 | 5.6 | 4.6 | 2.8 | 4.8 | 3.4 | 2.4 | 3.9 | 2.8 | 2.0 |
| B | 3.0 | 7.3 | 6.3 | 3.7 | 7.3 | 6.3 | 3.7 | 6.2 | 4.4 | 3.1 | 5.1 | 3.7 | 2.6 |
| B | 4.0 | 8.8 | 8.2 | 4.4 | 8.8 | 8.2 | 4.4 | 7.5 | 5.3 | 3.7 | 6.2 | 4.4 | 3.1 |
| C | 5.5 | 12.5 | 10.8 | 6.3 | 12.5 | 10.8 | 6.3 | 10.6 | 7.5 | 5.3 | 8.8 | 6.3 | 4.4 |
| D | 7.5 | 16.5 | 14.5 | 8.3 | 16.5 | 14.5 | 8.3 | 14.0 | 9.9 | 6.9 | 11.6 | 8.3 | 5.8 |
| D | 11 | 25.0 | 21.0 | 12.5 | 25.0 | 21.0 | 12.5 | 21.3 | 15.0 | 10.5 | 17.5 | 12.5 | 8.8 |
| D | 15 | 31.0 | 28.0 | 15.5 | 31.0 | 28.0 | 15.5 | 26.4 | 18.6 | 13.0 | 21.7 | 15.5 | 10.9 |

| Three phase 400 V inverters | | | | | | | | | | | | | |
|---|--------------------------|--|--------------|--------------|---------------|--------------|--------------|---------------|--------------|--------------|---------------|--------------|--------------|
| Frame size | Power rating [kW] | Current rating [A] at PWM frequency | | | | | | | | | | | |
| PWM frequency range: 2 ... 16 kHz (default: 4 kHz) | | | | | | | | | | | | | |
| | | 10 kHz | | | 12 kHz | | | 14 kHz | | | 16 kHz | | |
| | | 40 °C | 50 °C | 60 °C | 40 °C | 50 °C | 60 °C | 40 °C | 50 °C | 60 °C | 40 °C | 50 °C | 60 °C |
| A | 0.37 | 0.8 | 0.5 | 0.4 | 0.7 | 0.5 | 0.3 | 0.6 | 0.4 | 0.3 | 0.5 | 0.4 | 0.3 |
| A | 0.55 | 1.0 | 0.7 | 0.5 | 0.9 | 0.6 | 0.4 | 0.8 | 0.5 | 0.4 | 0.7 | 0.5 | 0.3 |
| A | 0.75 | 1.3 | 0.9 | 0.7 | 1.1 | 0.8 | 0.6 | 1.0 | 0.7 | 0.5 | 0.9 | 0.6 | 0.4 |
| A | 1.1 | 1.9 | 1.3 | 0.9 | 1.6 | 1.1 | 0.8 | 1.4 | 1.0 | 0.7 | 1.2 | 0.9 | 0.6 |
| A | 1.5 | 2.5 | 1.7 | 1.2 | 2.1 | 1.4 | 1.0 | 1.8 | 1.3 | 0.9 | 1.6 | 1.1 | 0.8 |
| A | 2.2 | 3.4 | 2.4 | 1.7 | 2.8 | 2.0 | 1.4 | 2.5 | 1.7 | 1.2 | 2.2 | 1.6 | 1.1 |
| B | 3.0 | 4.4 | 3.1 | 2.2 | 3.7 | 2.6 | 1.8 | 3.3 | 2.3 | 1.6 | 2.9 | 2.0 | 1.5 |
| B | 4.0 | 5.3 | 3.7 | 2.6 | 4.4 | 3.1 | 2.2 | 4.0 | 2.7 | 1.9 | 3.5 | 2.5 | 1.8 |
| C | 5.5 | 7.5 | 5.3 | 3.8 | 6.3 | 4.4 | 3.1 | 5.6 | 3.9 | 2.8 | 5.0 | 3.5 | 2.5 |
| D | 7.5 | 9.9 | 6.9 | 5.0 | 8.3 | 5.8 | 4.1 | 7.4 | 5.1 | 3.6 | 6.6 | 4.6 | 3.3 |
| D | 11 | 15.0 | 10.5 | 7.5 | 12.5 | 8.8 | 6.3 | 11.3 | 7.8 | 5.5 | 10.0 | 7.0 | 5.0 |
| D | 15 | 18.6 | 13.0 | 9.3 | 15.5 | 10.9 | 7.8 | 14.0 | 9.6 | 6.8 | 12.4 | 8.7 | 6.2 |

Motor control

| | |
|-------------------------------|---|
| Control methods | Linear V/F, quadratic V/F, multi-point V/F, V/F with FCC |
| Output frequency range | Default range: 0 ... 599 Hz Resolution: 0.01 Hz |
| Maximum overload cycle | 150 % rated for 60 seconds followed by 94.5 % rated for 540 seconds (average 100 % rated) |

Mechanical specifications

| | | 3 AC 400 V | | | | | | |
|-------------------------|------------|---|-------------|--------------|--------------|--------------|-------|-------|
| | | Frame size A | | Frame size B | Frame size C | Frame size D | | |
| | | With fan | Without fan | | | 7.5 kW | 11 kW | 15 kW |
| Outline dimensions (mm) | W | 90 | 90 | 140 | 184 | 240 | | |
| | H | 166 | 150 | 160 | 182 | 206.5 | | |
| | D | 145.5 | 145.5 | 164.5 | 169 | 172.5 | | |
| Net weight (kg) | unfiltered | 1.0 | 0.9 | 1.6 | 2.4 | 3.7 | 3.7 | 3.9 |
| | filtered | 1.1 | 1.0 | 1.8 | 2.6 | 4.0 | 4.1 | 4.3 |
| Gross weight (kg) | | 1.4 | | 2.1 | 3.0 | 5.0 | | |
| Mounting methods | | <ul style="list-style-type: none"> • Cabinet panel mounting (frame sizes A ... D) • Push-through mounting (frame sizes B ... D) | | | | | | |

Environmental conditions

| | |
|----------------------------|--|
| Ambient temperature | 0 ... 40 °C: without derating 40 ... 60 °C: with derating |
| Storage temperature | -40 ... + 70 °C |
| Protection class | IP 20 |
| Maximum humidity level | 95 % (non-condensing) |
| Shock and vibration | Long-term storage in the transport packaging according to EN 60721-3-1 Class 1M2 Transport in the transport packaging according to EN 60721-3-2 Class 2M3 Vibration during operation according to EN 60721-3-3 Class 3M2 |
| Operating altitude | Up to 4000 m above sea level 1000 ... 4000 m: output current derating 2000 ... 4000 m: input voltage derating |
| Environmental classes | Pollution class: 3S2 Gas class: 3C2 (SO ₂ , H ₂ S) Climate class: 3K3 |
| Minimum mounting clearance | Top: 100 mm Bottom: 100 mm (85 mm for fan-cooled frame size A) Side: 0 mm |

Standards


| | |
|---------------------------|--|
| CE marking | European Low Voltage Directive (EN61800 -5-1 and EN 60204-1) |
| | European EMC Directive (EN 61800 - 3) |
| UL certification (UL508C) | |
| CTick marking | |
| ISO 9001 | |

Options and spare parts

B.1 Options

B.1.1 Parameter Loader

Order number: 6SL3255-0VE00-0UA0



Outline dimensions (mm)



Functionality

The Parameter Loader provides the ability to upload/download parameter sets between the inverter and an MMC / SD card. It is only a commissioning tool and has to be removed during normal operation.

NOTICE

To clone saved parameter settings from one inverter to another, a Parameter Loader or BOP Interface Module is required. For detailed information about clone steps with the selected option, see the data transferring steps described in respective sections (Appendix B.1.1 or B.1.2).

During parameter cloning, make sure you either connect the PE terminal to earth or observe ESD protective measures.

MMC / SD card socket

The Parameter Loader contains an MMC/ SD card socket which is connected directly to the expansion port on the inverter.


Battery power supply

In addition to the memory card interface, the Parameter Loader can hold two AA batteries which allow the inverter to be powered directly from this option module when the mains power is not available. If the inverter can be supplied from the mains power, it is not necessary to power the Parameter Loader from the batteries.

DC 5 V power supply socket

The Parameter Loader contains a DC 5 V power supply socket for connection to an external DC power supply. When mains power is not available to the inverter, it is possible to power the Parameter Loader from this DC supply rather than using batteries.

Fitting the Parameter Loader to the inverter



Recommended MMC / SD cards

The following MMC / SD cards are recommended:

- MMC card (order number: 6SL3254-0AM00-0AA0)
- SD card (order number: 6ES7954-8LB01-0AA0)

Using memory cards from other manufacturers

Requirements for MMC / SD cards:

- Supported file format: FAT16 and FAT 32
- Maximum card capacity: 2 GB
- Minimum card space for parameter transfer: 8 KB

CAUTION

You use memory cards from other manufacturers at your own risk. Depending on the card manufacturer, not all functions are supported (e.g. download).

Methods to power on the inverter

Use one of the following methods to power on the inverter for downloading / uploading parameters:

- Power on from the mains supply.
- Power on from the built-in battery power supply. Press the power button on the Parameter Loader and the inverter is powered on.
- Power on from an external DC 5 V power supply that is connected to the Parameter Loader. Press the power button on the Parameter Loader and the inverter is powered on.

Transferring data from inverter to MMC / SD card

1. Fit the option module to the inverter.
2. Power on the inverter.
3. Insert the card into the option module.
4. Set P0003 (user access level) = 3.
5. Set P0010 (commissioning parameter) = 30.
6. Set P0804 (select clone file). This step is necessary only when the card contains the data files that you do not desire to be overwritten.
P0804 = 0 (default): file name is clone00.bin
P0804 = 1: file name is clone01.bin
...
P0804 = 99: file name is clone99.bin
7. Set P0802 (transfer data from inverter to card) = 2.

The inverter displays "8 8 8 8 8" during transfer and the LED is lit up orange and flashes at 1 Hz. After a successful transfer, both P0010 and P0802 are automatically reset to 0. If any faults occur during the transfer, see Chapter "Fault and warning codes (Page 233)" for possible reasons and remedies.

Transferring data from MMC / SD card to inverter

There are two ways to perform a data transfer.

Method 1:

(Precondition: Inverter is to be powered up after inserting the card)

1. Fit the option module to the inverter.
2. Insert the card into the option module. Make sure the card contains the file "clone00.bin".
3. Power on the inverter.

Data transfer starts automatically. Then the fault code F395 displays which means "Cloning has occurred. Do you want to keep the clone edits?".

4. To save the clone edits, press **OK** and the fault code is cleared. When the clone file is written to EEPROM, the LED is lit up orange and flashes at 1Hz.

If you do not wish to keep the clone edits, remove the card or the option module and restart the inverter. The inverter will power up with the fault code F395 and r0949 = 10 indicating that the previous cloning was aborted. To clear the fault code, press **OK**.

Method 2:

(Precondition: Inverter is powered up before inserting the card)

1. Fit the option module to the powered inverter.
2. Insert the card into the option module.
3. Set P0003 (user access level) = 3.
4. Set P0010 (commissioning parameter) = 30.
5. Set P0804 (select clone file). This step is necessary only when the card does not contain the file "clone00.bin". The inverter copies by default the file "clone00.bin" from the card.
6. Set P0803 (transfer data from card to inverter) = 2.

The inverter displays "8 8 8 8 8" during transfer and the LED is lit up orange and flashes at 1 Hz. After a successful transfer, both P0010 and P0803 are automatically reset to 0.

Note that fault code F395 only occurs with power-up cloning.

B.1.2 External BOP and BOP Interface Module

External BOP

Order number: 6SL3255-0VA00-4BA0


The external BOP is used for remote control of the inverter operation.

Components

- External BOP unit
- 4 x M3 screws


Rating plate

The rating plate for the external BOP is located on the back side of the BOP.



Panel layout

The SINAMICS V20 supports an external BOP for remote control of inverter operation. The external BOP connects to the inverter through an optional BOP Interface Module.



Button functions

| Button | Description |
|--------|--|
| | Stops the inverter Button functions the same as the button on the built-in BOP. |
| | Starts the inverter Button functions the same as the button on the built-in BOP. |
| | Multi-function button Button functions the same as the button on the built-in BOP. |
| | Pressing the button: Button functions the same as the button on the built-in BOP. Turning clockwise: Button functions the same as the button on the built-in BOP. Fast turning functions the same as long press of the button on the built-in BOP. Turning counter-clockwise: Button functions the same as the button on the built-in BOP. Fast turning functions the same as long press of the button on the built-in BOP. |
| | Button functions the same as the + buttons on the built-in BOP. |

Inverter status icons

| | |
|--|---|
| | These icons have the same meaning as the corresponding icons on the built-in BOP. |
| | |
| | |
| | |
| | |
| | Commissioning icon. The inverter is in commissioning mode (P0010 = 1). |

Screen display

The display of the external BOP is identical to the built-in BOP, except that the external BOP has a commissioning icon which is used to indicate that the inverter is in commissioning mode.

On inverter power-up, the inverter-connected external BOP first displays "BOP.20" (BOP for the SINAMICS V20) and then the firmware version of the BOP. After that it detects and displays the baudrate and the USS communication address of the inverter automatically.


See the following table for settable baudrate and address values. To change the baudrate, set P2010[1]. To change the USS communication address, set P2011[1].

| Baudrate (bps) | Communication address | Display example |
|-------------------|-----------------------|---|
| 9600 | 0 ... 31 |  |
| 19200 | 0 ... 31 | |
| 38400 | 0 ... 31 | |
| 57600 | 0 ... 31 | |
| 76800 | 0 ... 31 | |
| 93750 | 0 ... 31 | |
| 115200 | 0 ... 31 | |

In case of any communication errors, the screen displays "noCon" which means that no communication connection has been detected. The inverter then automatically restarts baudrate and address detection. In this case, check that the cable is correctly connected.

Mounting dimensions of the external BOP

The outline dimensions, drill pattern and cut-out dimensions of the external BOP are shown below:



Unit: mm

Fixings:

4 x M3 screws (length: 12 ... 18 mm)

Tightening torque: 0.8 Nm ± 10%

BOP Interface Module

Order number: 6SL3255-0VA00-2AA0


Functionality

This module can be used as an interface module for the external BOP, thus realizing the remote control over the inverter by the external BOP. In addition, this module provides the ability to upload / download parameter sets between the inverter and an MMC / SD card.

The module contains a communication interface for connecting the external BOP to the inverter, a plug connector for connection to the expansion port on the inverter, and an MMC / SD card slot. The module connects the external BOP to the inverter and provides the ability of parameter cloning between the inverter and MMC / SD card.

Options and spare parts

B.1 Options



NOTICE

To clone saved parameter settings from one inverter to another, a Parameter Loader or BOP Interface Module is required. For detailed information about clone steps with the selected option, see the data transferring steps described in respective sections (Appendix B.1.1 or B.1.2).

Outline dimensions (mm)



Transferring parameter sets

The steps to transfer parameter sets between the inverter and the MMC / SD card using the BOP Interface Module are the same as those using the Parameter Loader.


See Section "Parameter Loader (Page 247)" for detailed description of the MMC / SD card and the data transferring steps.

NOTICE

During transfer of parameter sets to or from the MMC / SD card, communications between the BOP and the inverter is temporarily suspended.

Mounting (SINAMICS V20 + BOP Interface Module + external BOP)**NOTICE**


Connecting the BOP Interface Module to the external BOP is required only when you desire to control the inverter operation remotely with the external BOP. The BOP Interface Module needs to be screwed to the inverter with a tightening torque of 1.5 Nm (tolerance: $\pm 10\%$).




B.1.3 Connecting cable (external BOP to BOP Interface Module)

Order number: 6SL3256-0VP00-0VA0

To: BOP interface module



Connecting the external BOP to the BOP interface module



B.1.4 Dynamic braking module

Order number: 6SL3201-2AD20-8VA0


NOTICE

This module is applicable for frame sizes A to C only.

Functionality

The dynamic braking module is typically used in applications in which dynamic motor behavior is required at different speed or continuous direction changes, for example, for conveyor drives or hoisting gear.

Dynamic braking converts the regenerative energy, which is released when the motor brakes, into heat. Dynamic braking activity is limited by the duty cycle selected with the control knob.



Status LEDs

| LED | Color | Description |
|------------|--------|---|
| POWER | Yellow | Module is powered up. |
| PROTECTION | Red | Module is in protection mode. |
| ACTIVE | Green | Module is releasing regenerative energy produced when the motor brakes into heat. |

Duty cycle selection



Incorrect setting for the duty cycle / voltage could damage the attached braking resistor.

Use the control knob to select the rated duty cycle of the braking resistor.

Value labels on the module have the following meanings:

| Label | Meaning |
|-------|---|
| 230 V | Duty cycle values labeled are for 230 V inverters |
| 400 V | Duty cycle values labeled are for 400 V inverters |
| 5 | 5% duty cycle |
| 10 | 10% duty cycle |
| 20 | 20% duty cycle |
| 50 | 50% duty cycle |
| 100 | 100% duty cycle |

Technical specifications

| | |
|----------------------------------|---|
| Maximum power rating | 3.0 kW (230 V inverters) / 5.5 kW (400 V inverters) |
| Outline dimensions (L x W x D) | 150 x 90 x 88 (mm) |
| Mounting | Cabinet panel mounting (4 x M4 screws) |
| Maximum brake chopper duty cycle | 100 % |
| Protection functions | Short-circuit protection, over-temperature protection |
| Maximum cable length | Braking module to inverter: 1 m Braking module to braking resistor: 10 m |

B.1.5 Braking resistor

Functionality

An external braking resistor can be used to "dump" the power generated by the motor, thus giving greatly improved braking and deceleration capability.

A braking resistor which is required for dynamic braking can be used with all frame sizes of inverters. Frame size D is designed with an internal braking chopper, allowing you to connect the braking resistor directly to the inverter. However, for frame sizes A to C, an additional dynamic braking module is required for connecting the braking resistor to the inverter.

| Frame size | Inverter power rating (kW) | Resistor (order number) |
|-----------------------------|----------------------------|-------------------------|
| 3 AC 400 V inverters | | |
| Frame size A | 0.37 | 6SE6400-4BD11-0AA0 |
| | 0.55 | |
| | 0.75 | |
| | 1.1 | |
| | 1.5 | |
| | 2.2 | |
| Frame size B | 3 | 6SE6400-4BD12-0BA0 |
| | 4 | |
| Frame size C | 5.5 | 6SE6400-4BD16-5CA0 |
| Frame size D | 7.5 | 6SE6400-4BD21-2DA0 |
| | 11 | |
| | 15 | |

B.1.6 Input choke

| Frame size | Inverter power rating (kW) | Line choke (order number) |
|-----------------------------|----------------------------|---------------------------|
| 3 AC 400 V inverters | | |
| Frame size A | 0.37 | 6SE6400-3CC00-2AD3 |
| | 0.55 | |
| | 0.75 | |
| | 1.1 | |
| | 1.5 | |
| | 2.2 | |
| Frame size B | 3 | 6SE6400-3CC01-4BD3 |
| | 4 | |
| Frame size C | 5.5 | 6SE6400-3CC02-2CD3 |
| Frame size D | 7.5 | 6SE6400-3CC03-5CD3 |
| | 11 | |
| | 15 | |

B.1 Options

B.1.7 Output choke

Make sure you use a shielded cable (maximum length: 100 m) to connect the output choke.


| Frame size | Inverter power rating (kW) | Output choke (order number) |
|-----------------------------|----------------------------|-----------------------------|
| 3 AC 400 V inverters | | |
| Frame size A | 0.37 | 6SE6400-3TC00-4AD2 |
| | 0.55 | |
| | 0.75 | |
| | 1.1 | |
| | 1.5 | |
| Frame size B | 2.2 | 6SE6400-3TC01-0BD3 |
| | 3 | |
| | 4 | |
| Frame size C | 5.5 | 6SE6400-3TC03-2CD3 |
| Frame size D | 7.5 | |
| | 11 | |
| | 15 | |




B.1.8 Screening plate kit

Functionality

The screening plate kit is supplied as an option for each frame size. It allows easy and efficient connection of the necessary screening to achieve EMC-compliant installation of the inverter (see Section "EMC-compliant installation (Page 27)" for details).

Components

| Inverter variant | Screening plate kit | Components |
|------------------|---|---|
| | Illustration | Components |
| Frame size A | Order number: 6SL3266-1AA00-0VA0  | ① Screening plate ② 3 × cable screen clamps ③ 4 × M4 screws (tightening torque: 1.8 Nm ± 10%) |

| Inverter variant | Screening plate kit | Components |
|------------------|--|--|
| | Illustration | |
| Frame size B | Order number: 6SL3266-1AB00-0VA0  | ① Screening plate ② 2 × clips ¹⁾ ③ 3 × cable screen clamps ④ 7 × M4 screws (tightening torque: 1.8 Nm ± 10%) |
| Frame size C | Order number: 6SL3266-1AC00-0VA0  | ① Screening plate ② 2 × clips ¹⁾ ③ 3 × cable screen clamps ④ 7 × M4 screws (tightening torque: 1.8 Nm ± 10%) ²⁾ |
| Frame size D | Order number: 6SL3266-1AD00-0VA0  | ① Screening plate ② 2 × clips ¹⁾ ③ 4 × cable screen clamps ④ 8 × M4 screws (tightening torque: 1.8 Nm ± 10%) ²⁾ |


¹⁾ The clips are required only when fixing the screening plate to the cabinet panel-mounted inverter.

²⁾ For "push-through" applications, you must use two M5 screws and nuts (tightening torque: 2.5 Nm ± 10%) rather than two M4 screws ("A" in the illustration) to fix the screening plate to the inverter.

Options and spare parts

B.1 Options


Outline dimensions (mm)



Fixing the screening plate kit to the inverter

If the inverter applies cabinet-panel mounting mode:

Fixing to frame size A




① Loosen the PE screw and slide the screening plate from below, then retighten the screw to 1.8 Nm (tolerance: $\pm 10\%$).

② Clamp the heatsink between the screening plate and the cabinet panel and tighten the screws and nuts to 1.8 Nm (tolerance: $\pm 10\%$).

③ Fold the cable screen clamp to suit the cable diameter during inverter installation.

Fixing to frame size B / C / D




① Clamp the heatsink between the clip and the screening plate and tighten the screw to 1.8 Nm (tolerance: $\pm 10\%$).

② Fold the cable screen clamp to suit the cable diameter during inverter installation.

If the inverter applies push-through mounting mode:

Fixing to frame size B / C / D



Note that the clips are not required in this case.

① Clamp the heatsink between the screening plate and the cabinet panel, and use two mating nuts instead of the clips to tighten the screws (M4 screws if frame size B or M5 screws if frame size C or D) from the back of the cabinet panel. Screw tightening torque: M4 = 1.8 Nm $\pm 10\%$; M5 = 2.5 Nm $\pm 10\%$

② Fold the cable screen clamp to suit the cable diameter during inverter installation.

B.1.9 Memory card

Functionality

The memory card can be used on the Parameter Loader or the BOP Interface Module and allows you to upload / download parameter sets to / from the inverter. For detailed use of the memory card, refer to Appendices "Parameter Loader (Page 247)" and "External BOP and BOP Interface Module (Page 251)".

Order number

The MMC / SD cards with the following order numbers are recommended.

- MMC card: 6SL3254-0AM00-0AA0
- SD card: 6ES7954-8LB01-0AA0

B.1.10 User documentation

Operating Instructions (Chinese version)

Order number: 6SL3298-0AV02-0FP0

B.2 Spare parts - replacement fans

Order numbers

Replacement fan for frame size A: 6SL3200-0UF01-0AA0

Replacement fan for frame size B: 6SL3200-0UF02-0AA0


Replacement fan for frame size C: 6SL3200-0UF03-0AA0

Replacement fan for frame size D: 6SL3200-0UF04-0AA0


Replacing fans

Proceed as illustrated below to remove the fan from the inverter. To re-assemble the fan, proceed in reverse order. When re-assembling the fan, make sure that the arrow symbol ("A" in the illustration) on the fan points to the inverter rather than the fan housing, the position for the fan cable exit point ("B") as well as the mounting orientation and position of the cable connector ("C") are sufficient for connecting the fan cable to the inverter.

Replacing the fan from frame size A



Replacing the fan(s) from frame size B, C or D



Index

A

Advanced functions

Automatic restart, 93
Blockage clearing, 87
Cavitation protection, 101
Condensation protection, 95
Dual ramp function, 103
Economy mode, 89
Flying start, 92
Free functions blocks (FFBs), 91
Frost protection, 94
Hammer start, 85
Motor staging, 98
Sleep mode, 96
Super torque, 83
UL508C-compliant motor overheat protection, 90
User default parameter set, 102
Wobble function, 97

Alarm code list, 240

P0848[0...2], 154
P0849[0...2], 154
P0852[0...2], 154
P0881[0...2], 154
P0882[0...2], 154
P0883[0...2], 154
P1020[0...2], 161
P1021[0...2], 161
P1022[0...2], 161
P1023[0...2], 161
P1035[0...2], 162
P1036[0...2], 162
P1041[0...2], 162
P1043[0...2], 163
P1055[0...2], 163
P1056[0...2], 163
P1074[0...2], 164
P1110[0...2], 166
P1113[0...2], 167
P1124[0...2], 167
P1140[0...2], 169
P1141[0...2], 169

P1142[0...2], 169
P1175[0...2], 169
P1218[0...2], 172
P1230[0...2], 173
P2103[0...2], 193
P2104[0...2], 193
P2106[0...2], 193
P2200[0...2], 199
P2220[0...2], 201
P2221[0...2], 201

P2222[0...2], 201
P2223[0...2], 201
P2235[0...2], 202
P2236[0...2], 202
P2241[0...2], 202
P2243[0...2], 203
P2810[0...1], 214
P2812[0...1], 214
P2814[0...1], 214
P2816[0...1], 215
P2818[0...1], 215

B

Basic functions

Boost functions, 64
Braking functions, 69
Imax controller, 79
JOG function, 63
Load torque monitoring, 82
OFF functions, 61
PID controller, 67
Ramp time, 77
Vdc controller, 81

BI

P0731[0...2], 147
P0732[0...2], 147
P0806, 152
P0810, 152
P0811, 153
P0820, 153
P0821, 153
P0840[0...2], 153
P0842[0...2], 153
P0844[0...2], 153
P0845[0...2], 153

- P2820[0...1], 215
P2822[0...1], 215
P2824[0...1], 216
P2826[0...1], 216
P2828, 216
P2830, 216
P2832, 216
P2834[0...3], 217
P2837[0...3], 217
P2840[0...1], 218
P2843[0...1], 218
P2846[0...1], 218
P2849, 219
P2854, 220
P2859, 220
P2864, 221
P2940, 224
P3351[0...2], 227
P3852[0...2], 229
- BO**
- r0807.0, 152
r1025.0, 161
r2036.0...15, 192
r2037.0...15, 192
r2225.0, 201
r2811.0, 214
r2813.0, 214
r2815.0, 215
r2817.0, 215
r2819.0, 215
r2821.0, 215
r2823.0, 216
r2825.0, 216
r2827.0, 216
r2829.0, 216
r2831.0, 216
r2833.0, 217
r2835.0, 217
r2836.0, 217
r2838.0, 217
r2839.0, 218
r2841.0, 218
r2842.0, 218
r2844.0, 218
r2845.0, 218
r2847.0, 218
r2848.0, 219
r2852.0, 220
r2853.0, 220
r2857.0, 220
r2858.0, 220
r2862.0, 221
- r2863.0, 221
r2867.0, 221
r2868.0, 221
r2886.0, 223
r2888.0, 224
- Built-in BOP**
- Button functions, 29
Operating modes Hand / Jog / Auto, 30
Screen displays, 34
Status icons, 30
Status LEDs, 36
- C**
- CDS**
- P0700[0...2], 142
P0701[0...2], 142
P0702[0...2], 143
P0703[0...2], 143
P0704[0...2], 143
P0712 [0...2], 143
P0713[0...2], 143
P0719[0...2], 144
P0727[0...2], 145
P0731[0...2], 147
P0732[0...2], 147
P0840[0...2], 153
P0842[0...2], 153
P0844[0...2], 153
P0845[0...2], 153
P0848[0...2], 154
P0849[0...2], 154
P0852[0...2], 154
P0881[0...2], 154
P0882[0...2], 154
P0883[0...2], 154
P0886[0...2], 154
P1000[0...2], 158
P1020[0...2], 161
P1021[0...2], 161
P1022[0...2], 161
P1023[0...2], 161
P1035[0...2], 162
P1036[0...2], 162
P1041[0...2], 162
P1042[0...2], 163
P1043[0...2], 163
P1044[0...2], 163
P1055[0...2], 163
P1056[0...2], 163
P1070[0...2], 164
P1071[0...2], 164

- P1074[0...2], 164
 P1075[0...2], 164
 P1076[0...2], 164
 P1110[0...2], 166
 P1113[0...2], 167
 P1124[0...2], 167
 P1140[0...2], 169
 P1141[0...2], 169
 P1142[0...2], 169
 P1175[0...2], 169
 P1218[0...2], 172
 P1230[0...2], 173
 P1330[0...2], 180
 P2103[0...2], 193
 P2104[0...2], 193
 P2106[0...2], 193
 P2200[0...2], 199
 P2220[0...2], 201
 P2221[0...2], 201
 P2222[0...2], 201
 P2223[0...2], 201
 P2235[0...2], 202
 P2236[0...2], 202
 P2241[0...2], 202
 P2242[0...2], 202
 P2243[0...2], 203
 P2244[0...2], 203
 P2253[0...2], 203
 P2254[0...2], 203
 P2264[0...2], 204
 P2803[0...2], 214
 P3351[0...2], 227
 P3852[0...2], 229
- CI**
- P0095[0...9], 130
 P0771[0], 150
 P1042[0...2], 163
 P1044[0...2], 163
 P1070[0...2], 164
 P1071[0...2], 164
 P1075[0...2], 164
 P1076[0...2], 164
 P1330[0...2], 180
 P2019[0...7], 191
 P2151[0...2], 195
 P2242[0...2], 202
 P2244[0...2], 203
 P2253[0...2], 203
 P2254[0...2], 203
 P2264[0...2], 204
 P2869[0...1], 221
 P2871[0...1], 222
- P2873[0...1], 222
 P2875[0...1], 222
 P2877[0...1], 222
 P2879[0...1], 223
 P2881[0...1], 223
 P2883[0...1], 223
 P2885[0...1], 223
 P2887[0...1], 223
- Clone saved parameter settings, 248, 254
- CO**
- P2889, 224
 P2890, 224
 r0020, 124
 r0021, 124
 r0024, 124
 r0025, 124
 r0026[0], 124
 r0027, 124
 r0028, 124
 r0031, 125
 r0032, 125
 r0035[0...2], 125
 r0036, 125
 r0037[0...1], 125
 r0038, 125
 r0039, 125
 r0051[0...1], 126
 r0066, 128
 r0067, 129
 r0068, 129
 r0069[0...5], 129
 r0070, 129
 r0071, 129
 r0072, 129
 r0074, 129
 r0078, 129
 r0080, 129
 r0084, 129
 r0085, 130
 r0086, 130
 r0087, 130
 r0395, 139
 r0512, 140
 r0623[0...2], 141
 r0630[0...2], 142
 r0631[0...2], 142
 r0632[0...2], 142
 r0633[0...2], 142
 r0755[0...1], 148
 r0947[0...63], 155
 r0949[0...63], 155
 r1024, 161

- r1045, 163
r1050, 163
r1078, 164
r1079, 164
r1114, 167
r1119, 167
r1170, 169
r1242, 175
r1246[0...2], 176
r1315, 179
r1337, 181
r1343, 182
r1344, 182
r1801[0...1], 183
r2018[0...7], 190
r2110[0...3], 194
r2224, 201
r2245, 203
r2250, 203
r2260, 204
r2262, 204
r2266, 204
r2272, 205
r2273, 205
r2294, 206
r2870, 222
r2872, 222
r2874, 222
r2876, 222
r2878, 222
r2880, 223
r2882, 223
r2884, 223
r2955, 224
- CO/BO
r0019.0...14, 124
r0050, 126
r0052.0...15, 126
r0053.0...15, 127
r0054.0...15, 127
r0055.0...15, 127
r0056.0...15, 128
r0722.0...12, 144
r0747.0...1, 147
r0751.0...9, 147
r0785.0, 151
r0885.0...4, 154
r1199.7...12, 170
r2067.0...12, 193
r2197.0...12, 198
r2198.0...12, 199
r2379.0...2, 212
- r3113.0...15, 225
Communication
Modbus communication, 109
USS communication, 105
Connecting
Recommended fuse types, 22
Terminal layout, 23
Typical system connections, 21
Wiring diagram, 22
- D**
- DDS
P0291[0...2], 133
P0304[0...2], 133
P0305[0...2], 134
P0307[0...2], 135
P0308[0...2], 135
P0309[0...2], 135
P0310[0...2], 135
P0311[0...2], 135
P0314[0...2], 135
P0320[0...2], 136
P0335[0...2], 136
P0340[0...2], 136
P0341[0...2], 137
P0342[0...2], 137
P0344[0...2], 137
P0346[0...2], 138
P0347[0...2], 138
P0350[0...2], 138
P0352[0...2], 138
P0354[0...2], 138
P0356[0...2], 138
P0358[0...2], 138
P0360[0...2], 139
P0604[0...2], 140
P0610[0...2], 141
P0622[0...2], 141
P0625[0...2], 141
P0626[0...2], 141
P0627[0...2], 142
P0628[0...2], 142
P0640[0...2], 142
P1001[0...2], 159
P1002[0...2], 160
P1003[0...2], 160
P1004[0...2], 160
P1005[0...2], 160
P1006[0...2], 160
P1007[0...2], 160
P1008[0...2], 160

- P1009[0...2], 160
P1010[0...2], 160
P1011[0...2], 160
P1012[0...2], 160
P1013[0...2], 161
P1014[0...2], 161
P1015[0...2], 161
P1016[0...2], 161
P1031[0...2], 161
P1040[0...2], 162
P1047 [0...2], 163
P1048[0...2], 163
P1058[0...2], 163
P1060[0...2], 164
P1061[0...2], 164
P1080[0...2], 165
P1082[0...2], 165
P1091[0...2], 166
P1092[0...2], 166
P1093[0...2], 166
P1094[0...2], 166
P1101[0...2], 166
P1120[0...2], 167
P1121[0...2], 167
P1130[0...2], 168
P1131[0...2], 168
P1132[0...2], 168
P1133[0...2], 168
P1134[0...2], 168
P1135[0...2], 168
P1202[0...2], 170
P1227[0...2], 172
P1232[0...2], 173
P1233[0...2], 173
P1234[0...2], 173
P1236[0...2], 173
P1240[0...2], 175
P1243[0...2], 175
P1245[0...2], 176
P1247[0...2], 176
P1250[0...2], 176
P1251[0...2], 176
P1252[0...2], 176
P1253[0...2], 176
P1256[0...2], 176
P1257[0...2], 177
P1300[0...2], 177
P1310[0...2], 178
P1311[0...2], 179
P1312[0...2], 179
P1316[0...2], 179
P1320[0...2], 180
P1321[0...2], 180
P1322[0...2], 180
P1323[0...2], 180
P1324[0...2], 180
P1325[0...2], 180
P1333[0...2], 180
P1334[0...2], 180
P1335[0...2], 181
P1336[0...2], 181
P1338[0...2], 181
P1340[0...2], 181
P1341[0...2], 182
P1345[0...2], 182
P1346[0...2], 182
P1350[0...2], 183
P1780[0...2], 183
P1800[0...2], 183
P1803[0...2], 184
P1820[0...2], 184
P1909[0...2], 184
P2000[0...2], 185
P2001[0...2], 186
P2002[0...2], 187
P2003[0...2], 187
P2004[0...2], 187
P2150[0...2], 195
P2151[0...2], 195
P2155[0...2], 195
P2156[0...2], 195
P2157[0...2], 195
P2158[0...2], 195
P2159[0...2], 195
P2160[0...2], 195
P2162[0...2], 195
P2164[0...2], 196
P2166[0...2], 196
P2167[0...2], 196
P2168[0...2], 196
P2170[0...2], 196
P2171[0...2], 196
P2172[0...2], 196
P2173[0...2], 196
P2177[0...2], 196
P2181[0...2], 197
P2182[0...2], 197
P2183[0...2], 197
P2184[0...2], 197
P2185[0...2], 197
P2186[0...2], 198
P2187[0...2], 198
P2188[0...2], 198
P2189[0...2], 198

P2190[0...2], 198
P2192[0...2], 198
P2201[0...2], 199
P2202[0...2], 200
P2203[0...2], 200
P2204[0...2], 200
P2205[0...2], 200
P2206[0...2], 200
P2207[0...2], 200
P2208[0...2], 200
P2209[0...2], 200
P2210[0...2], 200
P2211[0...2], 200
P2212[0...2], 200
P2213[0...2], 201
P2214[0...2], 201
P2215[0...2], 201
P2216[0...2], 201
P2231[0...2], 201
P2240[0...2], 202
P2247[0...2], 203
P2248[0...2], 203
P2360[0...2], 207
P2361[0...2], 208
P2362[0...2], 208
P2365[0...2], 208
P2366[0...2], 208
P2367[0...2], 208
P2370[0...2], 208
P2371[0...2], 208
P2372[0...2], 210
P2373[0...2], 210
P2374[0...2], 210
P2375[0...2], 210
P2376[0...2], 210
P2377[0...2], 210
P2378[0...2], 210
P3853[0...2], 229
P3854[0...2], 229
r0035[0...2], 125
r0313[0...2], 135
r0330[0...2], 136
r0331[0...2], 136
r0332[0...2], 136
r0333[0...2], 136
r0345[0...2], 137
r0370[0...2], 139
r0372[0...2], 139
r0373[0...2], 139
r0374[0...2], 139
r0376[0...2], 139
r0377[0...2], 139
r0382[0...2], 139
r0384[0...2], 139
r0386[0...2], 139
r0623[0...2], 141
r0630[0...2], 142
r0631[0...2], 142
r0632[0...2], 142
r0633[0...2], 142
r1246[0...2], 176

F

Fault code list, 234

I

Inverter functions

 Overview of main functions, 59

Inverter menu structure

 50 / 60 Hz selection menu, 37

 Display menu, 32

 Main menu, 31

 Parameter menu, 31, 56

 Setup menu, 39, 40, 41, 52, 55

M

Macros

 Application macros, 52

 Connection macros, 41

Mounting

 Cabinet panel mounting, 16

 Push-through mounting, 18

Mounting clearance, 15

Mounting orientation, 15

O

Order number

 Inverters, 13

P

Parameter resets, 104

Parameters

 Access levels, 119

 BICO parameters, 118

 C(1), U, T, 121

 Data set, 117

 Digit-by-digit editing, 33

Normal editing of parameters, 33
Parameter types, 32
Scaling, 120

Q

Quick commissioning
through the parameter menu, 56
through the setup menu, 38

T

Technical support, 3
Text menu
for common parameters, 55
for motor parameters, 40

U

User documentation components, 3

